

Original operating instructions

BCL 308*i* Bar code readers



© 2021

Leuze electronic GmbH & Co. KG

In der Braike 1

D-73277 Owen / Germany

Phone: +49 7021 573-0

Fax: +49 7021 573-199

<http://www.leuze.com>

info@leuze.com

1	General information	7
1.1	Explanation of symbols	7
1.2	Declaration of Conformity	7
2	Safety	8
2.1	Intended use	8
2.2	Foreseeable misuse	8
2.3	Competent persons	9
2.4	Exemption of liability	9
2.5	Laser safety notices	9
3	Fast commissioning / operating principle	11
3.1	Mounting the BCL 308/	11
3.2	Device arrangement and selection of the mounting location	11
3.3	BCL 308/electrical connection	11
3.4	Preparatory settings – Ethernet	16
3.4.1	Manual configuration of the IP address	16
3.4.2	Automatically setting the IP address	17
3.4.3	Setting the Ethernet host communication	18
3.4.4	TCP/IP	18
3.4.5	UDP	18
3.5	Further settings	18
3.6	Starting the device	20
3.7	Bar code reading	22
4	Device description	23
4.1	About the bar code readers of the BCL 300/series	23
4.2	Characteristics of the bar code readers of the BCL 300/series	23
4.3	Device construction	25
4.4	Reading techniques	27
4.4.1	Line scanner (single line)	27
4.4.2	Line scanner with oscillating mirror	28
4.4.3	Raster scanner (raster line)	28
4.5	Fieldbus systems	29
4.5.1	Ethernet	29
4.6	Heating	29
4.7	External parameter memory in the MS 308 / MK 308 and ME 308	30
4.8	autoReflAct	30
4.9	Reference codes	30
4.10	autoConfig	30
5	Technical data	31
5.1	General specifications of the bar code readers	31
5.1.1	Line scanner / raster scanner	31
5.1.2	Oscillating-mirror scanner	32
5.1.3	Line / raster scanner with deflecting mirror	33
5.2	Heating models of the bar code readers	33
5.2.1	Line scanner / raster scanner with heating	34
5.2.2	Oscillating-mirror scanner with heating	34
5.2.3	Line scanner / raster scanner with deflecting mirror and heating	35
5.3	Dimensioned drawings	36
5.3.1	Dimensioned drawing of complete overview of the BCL 308/with MS 3xx / MK 3xx / ME 3xx	36

5.3.2	Dimensioned drawing of line scanner with / without heating	37
5.3.3	Dimensioned drawing of deflecting mirror scanner with / without heating	38
5.3.4	Dimensioned drawing of oscillating-mirror scanner with / without heating	39
5.3.5	Dimensioned drawings of MS 3xx / ME 3xx / MK 3xx connection hoods	40
5.4	Reading field curves / optical data	41
5.4.1	Bar code characteristics	41
5.4.2	Raster scanner	42
5.5	Reading field curves	43
5.5.1	High Density (N) - optics: BCL 308/S/R1 N 102 (H)	44
5.5.2	High Density (N) - optics: BCL 308/S/R1 N 100 (H)	44
5.5.3	Medium Density (M) - optics: BCL 308/S/R1 M 102 (H)	45
5.5.4	Medium Density (M) - optics: BCL 308/S/R1 M 100 (H)	45
5.5.5	Medium Density (M) - optics: BCL 308/O M 100 (H)	46
5.5.6	Low Density (F) - optics: BCL 308/S/R1 F 102 (H)	46
5.5.7	Low Density (F) - optics: BCL 308/S/R1 F 100 (H)	47
5.5.8	Low Density (F) - optics: BCL 308/O F 100 (H)	47
5.5.9	Ultra Low Density (L) - optics: BCL 308/S L 102 (H)	48
5.5.10	Ultra Low Density (L) - optics: BCL 308/S L 100 (H)	48
5.5.11	Ultra Low Density (L) - optics: BCL 308/O L 100 (H)	49
5.5.12	Ink Jet (J) - optics: BCL 308/R1 J 100	50
6	Installation and mounting	51
6.1	Storage, transportation	51
6.2	Mounting the BCL 308/	51
6.2.1	Mounting via M4 x 5 screws	52
6.2.2	Mounting devices BT 56 and BT 56-1	53
6.2.3	BT 59 mounting device	54
6.2.4	BT 300 - 1, BT 300 W mounting devices	55
6.3	Device arrangement	56
6.3.1	Selecting a mounting location	56
6.3.2	Avoiding total reflection – Line scanner	56
6.3.3	Avoiding total reflection – deflecting mirror scanner	57
6.3.4	Avoiding total reflection – oscillating-mirror scanner	57
6.3.5	Mounting location.	57
6.3.6	Devices with integrated heating.	58
6.3.7	Possible read angles between BCL 308/and bar code	58
6.4	Cleaning.	58
7	Electrical connection	59
7.1	Safety notices for the electrical connection	59
7.2	BCL 308/electrical connection	61
7.2.1	MS 308 connector hood with 3 integrated M12 connectors.	61
7.2.2	ME 308 103 connection hood with M12 connection cables.	61
7.2.3	ME 308 104 connection hood with M8/M12 connection cables.	62
7.2.4	ME 308 214 connection hood with M8/M12/RJ45 connection cables	63
7.2.5	MK 308 terminal hood with spring-cage terminals.	64
7.3	Detailed description of the connections	66
7.3.1	PWR / SW IN/OUT - Voltage supply and switching input/output 1 and 2	66
7.3.2	SENSOR - direct connection of an external sensor (ME 308 xx4 only).	67
7.3.3	SERVICE – USB interface (Mini-B type)	68
7.3.4	HOST / BUS IN for BCL 308/.	69
7.3.5	BUS OUT for the BCL 308/.	70
7.4	Ethernet topologies	70
7.4.1	Ethernet wiring.	71
7.5	Cable lengths and shielding.	72
8	Display elements and display	73

8.1	BCL 308/LED indicators	73
8.2	MS 308/ME 308.../MK 308 LED indicators	75
8.3	BCL 308/display	76
9	Leuze webConfig tool	78
9.1	Connecting the SERVICE USB interface	78
9.2	Installing the required software	79
9.2.1	System requirements	79
9.2.2	Installing the USB driver	79
9.3	Starting the webConfig tool	79
9.4	Short description of the webConfig tool	80
9.4.1	Module overview in the Configuration menu	81
10	Commissioning and configuration	82
10.1	Measures to be performed prior to the initial commissioning	82
10.2	Starting the device	83
10.3	Setting the communication parameters	83
10.3.1	Manual configuration of the IP address	83
10.3.2	Automatically setting the IP address	83
10.3.3	Ethernet host communication	84
10.3.4	TCP/IP	84
10.3.5	UDP	84
10.4	Additional settings for the BCL 308/	85
10.4.1	Decoding and processing the read data	85
10.4.2	Control of the decoding	86
10.4.3	Control of the switching outputs	87
10.5	Transmitting configuration data	88
10.5.1	Via the webConfig tool	88
10.5.2	Replacing a defective BCL 308/	88
11	Online commands	89
11.1	Overview of commands and parameters	89
11.1.1	General online commands	89
11.1.2	Online commands for system control	95
11.1.3	Online commands for configuring the switching inputs/outputs	95
11.1.4	Online commands for the parameter set operations	98
12	Diagnostics and troubleshooting	102
12.1	General causes of errors	102
12.2	Interface errors	102
12.3	Service and support	103
13	Type overview and accessories	104
13.1	Part number code	104
13.2	BCL 308/type overview	105
13.3	Accessories – Connection hoods	106
13.4	Accessories – Connectors	106
13.5	Accessories – USB cable	106
13.6	Accessories – Mounting device	106
13.7	Accessory - Reflector for AutoReflAct	107
14	Maintenance	108
14.1	General maintenance information	108

14.2	Repairs, servicing	108
14.3	Disassembling, packing, disposing	108
15	Appendix	109
15.1	ASCII character set	109
15.2	Bar code samples	113
15.2.1	Module 0.3.....	113
15.2.2	Module 0.5.....	114

Figure 2.1:	Laser apertures, laser warning signs.....	10
Figure 3.1:	BCL 308/- MS 308 connection hood with M12 connectors.....	12
Figure 3.2:	BCL 308/- ME 308 103 connection hood with M12 connection cables.....	13
Figure 3.3:	BCL 308/- ME 308 104 connection hood with M8/M12 connection cables.....	14
Figure 3.4:	BCL 308/- ME 308 214 connection hood with M8/M12/RJ45 connection cables.....	15
Figure 3.5:	BCL 308/- MK 308 terminal hood with spring-cage terminals.....	16
Figure 3.6:	Cable fabrication for MK 308 terminal hood.....	16
Figure 4.1:	Line scanner, line scanner with deflecting mirror and oscillating-mirror scanner.....	23
Figure 4.2:	Possible bar code orientation.....	24
Figure 4.3:	BCL 308/-device construction - line scanner.....	25
Figure 4.4:	Device construction BCL 308/- Line scanner with deflecting mirror.....	25
Figure 4.5:	BCL 308/-device construction - oscillating-mirror scanner.....	26
Figure 4.6:	Device construction - MS 308 connector hood.....	26
Figure 4.7:	Device construction MK 308 hood with integrated connectors.....	26
Figure 4.8:	Device construction - MS 308 103 / MS 308 104 connector hood.....	27
Figure 4.9:	Deflection principle for the line scanner.....	27
Figure 4.10:	Deflection principle for the line scanner with oscillating mirror add-on.....	28
Figure 4.11:	Deflection principle for the raster scanner.....	29
Figure 4.12:	Reflector arrangement for autoReflAct.....	30
Table 5.1:	Technical data of the BCL 308/-line/raster scanners without heating.....	31
Table 5.2:	Technical data of the BCL 308/-oscillating-mirror scanners with heating.....	32
Table 5.3:	Technical data of the BCL 308/-deflecting mirror scanners without heating.....	33
Table 5.4:	Technical data of the BCL 308/-line / raster scanners with heating.....	34
Table 5.6:	Specifications of the BCL 308/-oscillating-mirror scanners with heating.....	34
Table 5.7:	Technical data of the BCL 308/-deflecting mirror scanners with heating.....	35
Figure 5.1:	Dimensioned drawing of complete overview of the BCL 308/-with MS 3xx / MK 3xx / ME 3xx.....	36
Figure 5.2:	Dimensioned drawing of BCL 308/-S...102 line scanner.....	37
Figure 5.3:	Dimensioned drawing of BCL 308/-S...100 with deflecting mirror.....	38
Figure 5.4:	Dimensioned drawing of BCL 308/-O...100 oscillating-mirror scanner.....	39
Figure 5.5:	Dimensioned drawing of MS 3xx connector hood / ME 3xx connection hood.....	40
Figure 5.6:	Dimensioned drawing of MK 3xx terminal hood.....	41
Figure 5.7:	The most important characteristics of a bar code.....	41
Table 5.8:	Raster line cover dependent on the distance.....	42
Figure 5.8:	Zero position of the reading distance.....	43
Table 5.9:	Reading conditions.....	43
Figure 5.9:	"High Density" reading field curve for line scanner without deflecting mirror.....	44
Figure 5.10:	"High Density" reading field curve for line scanner with deflecting mirror.....	44
Figure 5.11:	"Medium Density" reading field curve for line scanner without deflecting mirror.....	45
Figure 5.12:	"Medium Density" reading field curve for line scanner with deflecting mirror.....	45
Figure 5.13:	"Medium Density" reading field curve for oscillating-mirror scanners.....	46
Figure 5.14:	Lateral "Medium Density" reading field curve for oscillating-mirror scanners.....	46
Figure 5.15:	"Low Density" reading field curve for line scanner without deflecting mirror.....	46
Figure 5.16:	"Low Density" reading field curve for line scanner with deflecting mirror.....	47
Figure 5.17:	"Low Density" reading field curve for oscillating-mirror scanners.....	47
Figure 5.18:	Lateral "Low Density" reading field curve for oscillating-mirror scanners.....	47
Figure 5.19:	"Ultra Low Density" reading field curve for line scanner without deflecting mirror.....	48
Figure 5.20:	"Ultra Low Density" reading field curve for line scanner with deflecting mirror.....	48
Figure 5.21:	"Ultra Low Density" reading field curve for oscillating-mirror scanners.....	49
Figure 5.22:	Lateral "Ultra Low Density" reading field curve for oscillating-mirror scanners.....	49
Figure 5.23:	"Ink Jet" reading field curve for line scanner with deflecting mirror.....	50
Figure 6.1:	Device name plate BCL 308/-.....	51
Figure 6.2:	Fastening options using M4x5 threaded holes.....	52

Figure 6.3:	Mounting devices BT 56 and BT 56-1	53
Figure 6.4:	Mounting example of BCL 308 <i>i</i> /with BT 56.....	54
Figure 6.5:	BT 59 mounting device	54
Figure 6.6:	BT 300 - 1, BT 300 W mounting devices	55
Figure 6.7:	Total reflection – line scanner	56
Figure 6.8:	Total reflection – line scanner	57
Figure 6.9:	Total reflection – BCL 308 <i>i</i> /with oscillating-mirror scanner	57
Figure 6.10:	Reading angle for the line scanner	58
Figure 7.1:	Location of the electrical connections	59
Figure 7.2:	BCL 308 <i>i</i> - MS 308 connection hood with M12 connectors	61
Figure 7.3:	BCL 308 <i>i</i> - ME 308 103 connection hood with M12 connection cables	62
Figure 7.4:	BCL 308 <i>i</i> - ME 308 104 connection hood with M8/M12 connection cables	63
Figure 7.5:	BCL 308 <i>i</i> - ME 338 214 connection hood with M8/M12/RJ45 connection cables	64
Figure 7.6:	BCL 308 <i>i</i> - MK 308 terminal hood with spring-cage terminals	65
Figure 7.7:	Cable fabrication for MK 308 terminal hood	65
Table 7.1:	PWR / SW IN/OUT pin assignment	66
Figure 7.8:	Switching input connection diagram SWIO_1 and SWIO_2	67
Figure 7.9:	Switching output connection diagram SWIO_1 / SWIO_2	67
Table 7.2:	SENSOR pin assignment	68
Table 7.3:	SERVICE pin assignment – Mini-B type USB interface	68
Table 7.4:	Pin assignment HOST / BUS IN for BCL 308 <i>i</i>	69
Figure 7.10:	HOST / BUS IN cable assignments on RJ-45	69
Table 7.5:	Pin assignment BUS OUT for BCL 308 <i>i</i>	70
Figure 7.11:	Ethernet in a star topology	70
Figure 7.12:	Ethernet in a linear topology	71
Table 7.6:	Cable lengths and shielding.....	72
Figure 8.1:	BCL 308 <i>i</i> - LED indicators	73
Figure 8.2:	MS 308/ME 308.../MK 308 - LED indicators	75
Figure 8.3:	BCL 308 <i>i</i> - Display	76
Figure 9.1:	Connecting the SERVICE USB interface.....	78
Figure 9.2:	The start page of the webConfig tool	80
Figure 9.3:	Module overview in the webConfig tool	81
Figure 10.1:	Storing configuration data in the webConfig tool	88
Table 12.1:	General causes of errors	102
Table 12.2:	Interface error	102
Table 13.1:	BCL 308 <i>i</i> /part number code.....	104
Table 13.2:	BCL 308 <i>i</i> /type overview	105
Table 13.3:	Connection hoods for the BCL 308 <i>i</i>	106
Table 13.4:	Connectors for the BCL 308 <i>i</i>	106
Table 13.5:	Service cable for the BCL 308 <i>i</i>	106
Table 13.6:	Mounting devices for the BCL 308 <i>i</i>	106
Table 13.7:	Reflector for autoRefIAct operation.....	107
Figure 15.1:	Bar code sample labels (module 0.3)	113
Figure 15.2:	Bar code sample labels (module 0.5)	114

1 General information

1.1 Explanation of symbols

The symbols used in this technical description are explained below.

⚠ ATTENTION!	
	This symbol precedes text messages which must strictly be observed. Failure to observe the provided instructions could lead to personal injury or damage to equipment.

⚠ ATTENTION LASER!	
	This symbol warns of possible danger caused by hazardous laser radiation.

NOTE	
	This symbol indicates text passages containing important information.

1.2 Declaration of Conformity

The bar code readers of the BCL 300*i* series have been developed and manufactured in accordance with the applicable European standards and directives.

The manufacturer of the product, Leuze electronic GmbH & Co. KG in D-73277 Owen, possesses a certified quality assurance system in accordance with ISO 9001.



2 Safety

The bar code readers of the BCL 3xx/i series were developed, manufactured and tested in accordance with the applicable safety standards. They correspond to the state of the art.

2.1 Intended use

Bar code readers of the BCL 3xx/i series are conceived as stationary, high-speed scanners with integrated decoder for all current bar codes used for automatic object detection.

Areas of application

The bar code readers of the BCL 3xx/i series are especially designed for the following areas of application:

- Storage and conveying technologies, in particular for object identification on fast-moving conveyor belts
- Pallet transport systems
- Automobile sector
- Omnidirectional reading

⚠ CAUTION!	
	<p>Observe intended use!</p> <p>↳ Only operate the device in accordance with its intended use. The protection of personnel and the device cannot be guaranteed if the device is operated in a manner not complying with its intended use.</p> <p>Leuze electronic GmbH + Co. KG is not liable for damages caused by improper use.</p> <p>↳ Read the technical description before commissioning the device. Knowledge of this technical description is an element of proper use.</p>

NOTE	
	<p>Comply with conditions and regulations!</p> <p>↳ Observe the locally applicable legal regulations and the rules of the employer's liability insurance association.</p>

⚠ ATTENTION!	
	<p>For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).</p>

2.2 Foreseeable misuse

Any use other than that defined under "Intended use" or which goes beyond that use is considered improper use.

In particular, use of the device is not permitted in the following cases:

- in rooms with explosive atmospheres
- as stand-alone safety component in accordance with the machinery directive ¹⁾
- for medical purposes

NOTE	
	<p>Do not modify or otherwise interfere with the device!</p> <p>↳ Do not carry out modifications or otherwise interfere with the device.</p> <p>The device must not be tampered with and must not be changed in any way.</p> <p>The device must not be opened. There are no user-serviceable parts inside.</p> <p>Repairs must only be performed by Leuze electronic GmbH + Co. KG.</p>

¹⁾ Use as safety-related component within the safety function is possible, if the component combination is designed correspondingly by the machine manufacturer.

2.3 Competent persons

Connection, mounting, commissioning and adjustment of the device must only be carried out by competent persons.

Prerequisites for competent persons:

- They have a suitable technical education.
- They are familiar with the rules and regulations for occupational safety and safety at work.
- They are familiar with the technical description of the device.
- They have been instructed by the responsible person on the mounting and operation of the device.

Certified electricians

Electrical work must be carried out by a certified electrician.

Due to their technical training, knowledge and experience as well as their familiarity with relevant standards and regulations, certified electricians are able to perform work on electrical systems and independently detect possible dangers.

In Germany, certified electricians must fulfill the requirements of accident-prevention regulations DGUV V3 (e.g. electrician foreman). In other countries, there are respective regulations that must be observed.

2.4 Exemption of liability

Leuze electronic GmbH + Co. KG is not liable in the following cases:

- The device is not being used properly.
- Reasonably foreseeable misuse is not taken into account.
- Mounting and electrical connection are not properly performed.
- Changes (e.g., constructional) are made to the device.

2.5 Laser safety notices

⚠ ATTENTION, LASER RADIATION – CLASS 1 LASER PRODUCT	
	<p>The device satisfies the requirements of IEC/EN 60825-1:2014 safety regulations for a product of laser class 1 and complies with 21 CFR 1040.10 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.</p> <ul style="list-style-type: none"> ↳ Observe the applicable statutory and local laser protection regulations. ↳ The device must not be tampered with and must not be changed in any way. <p style="padding-left: 20px;">There are no user-serviceable parts inside the device.</p> <p style="padding-left: 20px;">Repairs must only be performed by Leuze electronic GmbH + Co. KG.</p> <p>CAUTION: Opening the device can lead to dangerous exposure to radiation!</p>




Figure 2.1: Laser apertures, laser warning signs

3 Fast commissioning / operating principle

Below you will find a short description for the initial commissioning of the BCL 308/. Detailed explanations for all listed points can be found throughout this technical description.

3.1 Mounting the BCL 308/

The BCL 308/ bar code readers can be mounted in two different ways:

- Via four M4x6 screws on the device bottom.
- Via a BT 56 mounting device in the fastening groove on the housing bottom.

3.2 Device arrangement and selection of the mounting location

In order to select the right mounting location, several factors must be considered:

- Size, orientation, and position tolerance of the bar codes on the objects to be scanned.
- The reading field of the BCL 308/ in relation to the bar code module width.
- The resulting minimum and maximum reading distance from the respective reading field.
- The permissible cable lengths between the BCL 308/ and the host system depending on which interface is used.
- The correct time for data output. The BCL 308/ should be positioned in such a way that, taking into consideration the time required for data processing and the conveyor belt speed, there is sufficient time to e.g. initiate sorting operations on the basis of the read data.
- The display and control panel should be very visible and accessible.
- For configuring and commissioning with the webConfig tool, the USB interface should be easily accessible.

For specific information, please refer to Chapter 6 and Chapter 7.

NOTE	
	<p>The beam of the BCL 308/ exits:</p> <ul style="list-style-type: none"> • Parallel to the housing base in the case of the line scanner • At 105 degrees from the housing base in the case of the deflecting mirror • Perpendicular to the housing base in the case of the oscillating mirror <p>In each case, the housing base is the black area in Figure 6.2. The best read results are obtained when:</p> <ul style="list-style-type: none"> • The BCL 308/ is mounted in such a way that the scanning beam is incident on the bar code at an angle of inclination greater than $\pm 10^\circ \dots 15^\circ$ to vertical. • The reading distance lies in the middle area of the reading field. • The bar code labels are of good print quality and have good contrast ratios. • You do not use high-gloss labels. • There is no direct sunlight.

3.3 BCL 308/ electrical connection

For the electrical connection of the BCL 308/, 2 connection variants are available.

The **voltage supply** (18 ... 30VDC) is connected acc. to the connection type selected.

2 freely programmable switching inputs/outputs for individual adaptation to the respective application are also available here. Detailed information on this topic can be found in Chapter 7.

MS 308 connector hood with 2 integrated M12 connectors




Figure 3.1: BCL 308/i- MS 308 connection hood with M12 connectors

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the MS 308. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet linear topology, the network is interrupted when the BCL 308/i is removed from the MS 308.

ME 308 103 connection hood with M12 connection cables

Connection hood
ME 308 103




Figure 3.2: BCL 308/i- ME 308 103 connection hood with M12 connection cables

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the ME 308 103. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet line topology, the network is interrupted when the BCL 308/i is removed from the ME 308 103.

ME 308 104 connection hood with M8/M12 connection cables

Connection hood
ME 308 104





Figure 3.3: BCL 308/i- ME 308 104 connection hood with M8/M12 connection cables


NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the ME 308 104. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet line topology, the network is interrupted when the BCL 308/i is removed from the ME 308 104.

ME 308 214 connection hood with M8/M12/RJ45 connection cables


Connection hood
ME 308 214




M12 connector
(A-coded)




Ethernet 0
RJ45 socket




Mini-B USB socket
(behind protective cap)



② SENSOR



④ HOST / BUS IN



M8 socket
(ext. sensor)

Ethernet 1
RJ45 socket

Figure 3.4: BCL 308/i- ME 308 214 connection hood with M8/M12/RJ45 connection cables

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the ME308 214. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet line topology, the network is interrupted when the BCL 308/i is removed from the ME 308 214.

MK 308 terminal hood with spring-cage terminals




Figure 3.5: BCL 308*i*- MK 308 terminal hood with spring-cage terminals

NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308 <i>i</i> is located in the MK 308. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet linear topology, the network is interrupted when the BCL 308 <i>i</i> is removed from the MK 308.

Cable fabrication and shielding connection

Remove approx. 78 mm of the connection cable sheathing. 15 mm of sheath of the shielded line must be freely accessible.




Figure 3.6: Cable fabrication for MK 308 terminal hood

The shield is automatically contacted when the cable is lead into the metal screw fitting and fastened when the cord grip is closed. Then lead the individual wires into the terminals according to the diagram. Wire end sleeves are not necessary.

3.4 Preparatory settings – Ethernet

➤ Connect the +18 ... 30VDC supply voltage (typ. +24VDC); the BCL 308*i* starts up.

As a first step, you need to set the communication parameters of the BCL 308*i*. You can make the necessary settings via the webConfig tool. Further information can be found in Chapter 10.

3.4.1 Manual configuration of the IP address

If your system does not include a DHCP server or if the IP addresses of the devices are to be set permanently, proceed as follows:

- Have the network administrator specify the data for IP address, net mask and gateway address of the BCL 308*i*.
- Set these values on the BCL 308*i*.

Via webConfig:

Configuration > Communication > Ethernet interface

NOTE

If the setting is performed via the webConfig tool, the BCL 308*i* **must** be restarted. The set IP address is only accepted and active after this restart.

3.4.2 Automatically setting the IP address

If your system includes a DHCP server that is to be used to assign the IP addresses, proceed as follows:

↳ Activate the DHCP client mode in the BCL 308*i*.

Via webConfig:

Configuration > Communication > Ethernet interface

Activate the DHCP = ON setting there.

3.4.3 Setting the Ethernet host communication

The Ethernet host communication enables the configuration of connections to an external host system. Both UDP as well as TCP/IP (in either client or server mode) can be used. The connection-free UDP protocol is used primarily to transfer process data to the host (monitor operation). The connection-oriented TCP/IP protocol can also be used to transfer commands from the host to the device. With this connection, the data is backed up by the TCP/IP protocol itself.

If you would like to use the TCP/IP protocol, you must also define whether the BCL 308/i is to operate as a TCP client or as a TCP server.

Both protocols can be activated simultaneously and used in parallel.

☞ Contact your network administrator to determine which communication protocol is used.

3.4.4 TCP/IP

☞ Activate the TCP/IP protocol

☞ Set the TCP/IP mode of the BCL 308/i

In **TCP client mode**, the BCL 308/i actively establishes the connection to the superior host system (PC / PLC as server). The BCL 308/i requires from the user the IP address of the server (host system) and the port number on which the server (host system) accepts a connection. In this case, the BCL 308/i determines when and with whom a connection is established!

☞ With a BCL 308/i as TCP client, also set the following values:

- IP address of the TCP server (normally the PLC/host computer)
- Port number of the TCP server
- Timeout for the wait time for an answer from the server
- Repetition time for renewed communication attempt following a timeout

In **TCP server mode**, the superior host system (PC / PLC) actively establishes the connection and the connected BCL 308/i waits for the connection to be setup. The TCP/IP stack requires information from the user regarding the local port of the BCL 308/i (port number) on which the connection requests of a client application (host system) are to be accepted. If there is a connection request and a connection is established by the superior host system (PC / PLC as client), the BCL 308/i (server mode) accepts the connection. Data can then be sent and received.

☞ With a BCL 308/i as TCP server, also set the following values:

- Port number for the communication of the BCL 308/i with the TCP client

The corresponding adjustment options can be found:

- Via webConfig:
Configuration -> Communication -> Host communication

3.4.5 UDP

The BCL 308/i requires from the user the IP address and the port number on which the communication partner receives data. In the same way, the host system (PC / PLC) now also requires the set IP address of the BCL 308/i and the selected port number. This assignment notifies both communication partners of which port the data is received on.

☞ Activate the UDP protocol

☞ Also set the following values:

- IP address of the communication partner
- Port number of the communication partner

The corresponding adjustment options can be found:

- Via webConfig:
Configuration -> Communication -> Host communication

3.5 Further settings

After the basic configuration of the operating mode and the communication parameters, you need to carry out further settings:

- Decoding and processing the read data

- ↳ Define at least one code type with the desired settings.
 - Via webConfig:
Configuration -> Decoder
- Control of the decoding
 - ↳ Configure the connected switching inputs according to your requirements. To do this, first set the *I/O mode* to *Input* and then configure the switching behavior:
 - Via webConfig:
Configuration > Device > Switching inputs/outputs
- Control of the switching outputs
 - ↳ Configure the connected switching outputs according to your requirements. To do this, first set the *I/O mode* to *Output* and then configure the switching behavior:
 - Via webConfig:
Configuration > Device > Switching inputs/outputs

3.6 Starting the device

↪ Connect the +18 ... 30VDC supply voltage (typ. +24VDC).

The BCL 308*i* starts up, the **PWR** and **NET** LEDs display the operating state. If there is a display, the bar code reading window appears in it.

PWR LED

	Green, continuous light	Power On, device OK
	Green, briefly off - on	Good read, successful reading
	Green, briefly off - briefly red - on	No read, reading not successful
	Orange, continuous light	Service mode
	Red, flashing	Warning set
	Red, continuous light	Error, device error

NET LED

	Flashes green	Initialization
	Green, continuous light	Network operation OK
	Flashes red	Communication error
	Red, continuous light	Network error

LED ACT0 / LINK0 (on the MS 308/MK308)

	Green, continuous light	Ethernet connected (LINK)
	Yellow, flickering light	Data communication (ACT)

LED ACT1 / LINK1 (on the MS 308/MK308)

	Green, continuous light	Ethernet connected (LINK)
	Yellow, flickering light	Data communication (ACT)

If a display is available, the following information appears successively during startup:

- Startup
- Device designation e.g. BCL 308i SM 102 D
- Reading Result

If Reading Result is displayed, the device is ready.

Operation of BCL 308*i*

After voltage (18 ... 30VDC) has been connected to the switching input, a read process is activated. In the standard setting, all common code types for decoding are released; only the **2/5 Interleaved** code type is limited to 10 digits of code content.

If a code is moved through the reading field, the code content is decoded and forwarded to the superior system (PLC/PC) via Ethernet.

3.7 Bar code reading

To test, you can use the following bar code in the 2/5 Interleaved format. The bar code module here is 0.5:



Provided your BCL 308*i* model has a display, the read information appears on this display. The **PWR** LED goes off briefly and then turns green again. Simultaneously, the read information is forwarded to the superior system (PLC/PC) via the Ethernet.

Please check the incoming data of the bar code information there.

Alternatively, you can use a switching input for read activation (switching signal of a photoelectric sensor or 24VDC switching signal).

4 Device description

4.1 About the bar code readers of the BCL 300*i* series

Bar code readers of the BCL 300*i* series are high-speed scanners with integrated decoder for all commonly used bar codes, e.g. 2/5 Interleaved, Code 39, Code 128, EAN 8/13 etc., as well as codes from the GS1 DataBar family.

Bar code readers of the BCL 300*i* series are available in various optics models as well as line scanners, line scanners with deflecting mirrors and also optionally as heated models.




Figure 4.1: Line scanner, line scanner with deflecting mirror and oscillating-mirror scanner

The many possible configurations of the device allow it to be adapted to a multitude of reading tasks. Due to the large reading distance combined with the great depth of field, a large opening angle and a very compact construction, the device is ideally suited for the conveyor and storage technology market.

The interfaces (**RS 232**, **RS 485** and **RS 422**) integrated in the various device models and the fieldbus systems (**PROFIBUS DP**, **PROFINET-IO**, **Ethernet TCP/IP UDP**, **Ethernet/IP** and **EtherCAT**) offer optimum connection to the superior host system.

4.2 Characteristics of the bar code readers of the BCL 300*i* series

Performance characteristics:

- Integrated fieldbus connectivity = *i*-> Plug-and-Play fieldbus coupling and easy networking
- Numerous interface variants facilitate connection to the superior systems
 - RS 232, RS 422
 - RS 485 and multiNet plus slave

Alternatively, various fieldbus systems, such as

- PROFIBUS DP
- PROFINET-IO
- Ethernet TCP/IP UDP
- EtherNet/IP
- EtherCAT

- Integrated code reconstruction technology (**CRT**) enables the identification of soiled or damaged bar codes
- Maximum depth of field and reading distances from 30 mm to 700 mm
- Large optical opening angle and, thus, large reading field width
- High scanning rate with 1000 scans/s for fast reading tasks
- On request with display to easily detect and activate functions and status messages.
- Integrated USB service interface, Mini-B type
- Adjustment of all device parameters with a web browser
- Easy alignment and diagnostics functions
- Up to four possible connection technologies
- Two freely programmable switching inputs/outputs for the activation or signaling of states
- Automatic monitoring of the read quality with **autoControl**
- Automatic recognition and setting of the bar code type using **autoConfig**
- Reference code comparison
- Optional heating models to -35°C
- Heavy-duty housing of degree of protection IP 65

NOTE



For information on technical data and characteristics, refer to Chapter 5.

General information

The integrated fieldbus connectivity = / contained in the bar code readers of the BCL 300/series facilitates the use of identification systems which function without connection unit or gateways. The integrated fieldbus interface considerably simplifies handling. The Plug-and-Play concept enables easy networking and very simple commissioning: Directly connect the respective fieldbus and all configuration is performed with no additional software.

For decoding bar codes, the bar code readers of the BCL 300/series make available the proven **CRT decoder** with code reconstruction technology:

The proven code reconstruction technology (**CRT**) enables bar code readers of the BCL 300/series to read bar codes with a small bar height, as well as bar codes with a damaged or soiled print image.

With the aid of the **CRT decoder**, bar codes can also be read without problem in other demanding situations, such as with a large tilt angle (azimuth angle or even twist angle).




Figure 4.2: Possible bar code orientation

The BCL 308/ can be operated and configured using the integrated webConfig tool via the USB service interface; alternatively, the bar code readers can be adjusted using configuration commands via the host/ service interface.

The BCL 308/ needs a suitable activation to start a read process as soon as an object is in the reading field. This opens a time window ("reading gate") in the BCL 308/ for the read process during which the bar code reader has time to detect and decode a bar code.

In the basic setting, triggering takes place through an external reading cycle signal. Alternative activation options include online commands via the host interface and the **autoRefIAct** function.

Through the read operation, the BCL 308*i* collects additional useful pieces of data for diagnostics which can also be transmitted to the host. The quality of the read operation can be inspected using the **alignment mode** which is integrated in the webConfig tool.

An optional, multi-language display with buttons is used to operate the BCL 308*i* as well as for visualization purposes. Two LEDs provide additional optical information on the current operating state of the device.

The two freely configurable switching inputs/outputs **SWIO1** and **SWIO2** can be assigned various functions and control e.g. activation of the BCL 308*i* or external devices, such as a PLC.

System, warning and error messages provide assistance in setup/troubleshooting during commissioning and read operation.

4.3 Device construction

BCL 308*i*/Bar code reader




Figure 4.3: BCL 308*i*/device construction - line scanner



Figure 4.4: Device construction BCL 308*i* - Line scanner with deflecting mirror




Figure 4.5: BCL 308*i* device construction - oscillating-mirror scanner

MS 308 connector hood




Figure 4.6: Device construction - MS 308 connector hood

MK 308 terminal hood




Figure 4.7: Device construction MK 308 hood with integrated connectors

ME 308 103 / ME 308 104 / ME 308 214 connection hood




Figure 4.8: Device construction - MS 308 103 / MS 308 104 connector hood

4.4 Reading techniques

4.4.1 Line scanner (single line)

A line (scan line) scans the label. Due to the opt. opening angle, the reading field width is dependent on the read distance. Through the movement of the object, the entire bar code is automatically transported through the scan line.

The integrated code reconstruction technology permits twisting of the bar code (tilt angle) within certain limits. These are dependent on the transport speed, the scanning rate of the scanner and the bar code properties.

Areas of application of the line scanner

The line scanner is used:

- when the bars of the bar code are printed in the conveying direction ('ladder arrangement').
- with bar codes having very short bar lengths.
- when the ladder code is turned out of the vertical position (tilt angle).
- when the reading distance is large.



Figure 4.9: Deflection principle for the line scanner

4.4.2 Line scanner with oscillating mirror

The oscillating mirror deflects the scan line additionally to both sides across the scan direction at a randomly adjustable oscillation frequency. In this way, the BCL 308*i* can also scan larger areas or spaces for bar codes. The reading field height (and the scan line length useful for evaluation) depends on the reading distance due to the optical opening angle of the oscillating mirror.

Areas of application of the line scanner with oscillating mirror

For line scanners with oscillating mirror, oscillation frequency, start/stop position etc. are adjustable. It is used:

- when the position of the label is not fixed, e.g. on pallets – various labels can, thus, be detected at various positions.
- when the bars of the bar code are printed perpendicular to the conveying direction ("picket fence arrangement").
- when reading stationary objects.
- when a large reading field (reading window) has to be covered.




Figure 4.10: Deflection principle for the line scanner with oscillating mirror add-on

4.4.3 Raster scanner (raster line)

Multiple scan lines scan the label. Due to the optical opening angle, the reading field width is dependent on the read distance. Provided the code is located in the reading field, it can be read during standstill. If the code moves through the reading field, it is scanned by multiple scan lines.

The integrated code reconstruction technology permits twisting of the bar code (tilt angle) within certain limits. These are dependent on the transport speed, the scanning rate of the scanner and the bar code properties. In most cases, everywhere a line scanner is used, a raster scanner can be used.

Areas of application of the raster scanner:

The raster scanner is used:

- When the bars of the bar code are perpendicular to the conveying direction (picket fence arrangement)
- With bar codes with low height displacement
- With very glossy bar codes



Figure 4.11: Deflection principle for the raster scanner

NOTE



With the raster scanner, there may not be two or more bar codes in the raster area of the BCL at the same time.

4.5 Fieldbus systems

Various product variants of the BCL 300*/*series are available for connecting to different fieldbus systems such as PROFIBUS DP, PROFINET, Ethernet, EtherNet/IP and EtherCAT.

4.5.1 Ethernet

The BCL 308*/*is designed as an Ethernet device (acc. to IEEE 802.3) with a standard baud rate of 10/100 Mbit. A fixed MAC ID is assigned to each BCL 308*/*by the manufacturer; this address cannot be changed.

The BCL 308*/*automatically supports the transmission rates of 10 Mbit/s (10Base T) and 100 Mbit/s (100Base TX), as well as auto-negotiation and auto-crossover.

The BCL 308*/*features multiple M 12 connectors / sockets for the electrical connection of the supply voltage, the interface and the switching inputs and outputs. Additional information on the electrical connection can be found in Chapter 7.

The BCL 308*/*supports the following protocols and services:

- TCP/IP (client / server)
- UDP
- DHCP
- Telnet
- HTTP
- ARP
- PING

For communication with the superior host system, the corresponding TCP/IP protocol (client/server mode) or UDP must be selected.

Further information on commissioning can be found in Chapter 10.

4.6 Heating

For low-temperature applications to min. -35°C (e.g. in cold storage), the bar code readers of the BCL 308*/* series can optionally be permanently fitted with a built-in heating and these bar code readers purchased as separate device models.

4.7 External parameter memory in the MS 308 / MK 308 and ME 308

The parameter memory available in the MS 308/MK 308 or ME 308 simplifies the time saving on-site exchange of a BCL 308/ by providing a copy of the current parameter set of the BCL 308/ and by storing the device name as well. This eliminates the need to configure the exchanged device manually and, in particular, a new naming of the device – the control can immediately access the exchanged BCL 308/.

4.8 autoReflAct

autoReflAct stands for **automatic Reflector Activation** and permits an activation without additional sensors. This is achieved by directing the scanner with reduced scanning beam towards a reflector mounted behind the conveyor path.

NOTE	
	Compatible reflectors are available on request.

As long as the scanner is targeted at the reflector, the reading gate remains closed. If, however, the reflector is blocked by an object such as a container with a bar code label, the scanner activates the read procedure, and the label on the container is read. When the path from the scanner to the reflector has cleared, the read procedure has completed and the scanning beam is reduced and again directed onto the reflector. The reading gate is closed.




Figure 4.12: Reflector arrangement for autoReflAct

The **autoReflAct** function uses the scanning beam to simulate a photoelectric sensor and thus permits an activation without additional sensors.

4.9 Reference codes

The BCL 308/ offers the possibility of storing one or two reference codes.

It is possible to store the reference codes via the webConfig tool or via online commands.

The BCL 308/ can compare read bar codes with one and/or both reference codes and execute user-configurable functions depending on the comparison result.

4.10 autoConfig

With the autoConfig function, the BCL 308/ offers an extremely simple and convenient configuration option to users who only want to read one code type (symbology) with one number of digits at a time.

After starting the autoConfig function via the switching input or from a superior control, it is sufficient to position a bar code label with the desired code type and number of digits in the reading field of the BCL 308/.

Afterward, bar codes with the same code type and number of digits are recognized and decoded.

5 Technical data

5.1 General specifications of the bar code readers

5.1.1 Line scanner / raster scanner

Type	BCL 308/ Ethernet
Design	Line scanner without heating
Optical data	
Light source	Laser diode $\lambda = 655\text{nm}$ (red light)
Max. output power (peak)	$\leq 1.8\text{mW}$
Impulse duration	$\leq 150\mu\text{s}$
Beam exit	At the front
Scanning rate	1000 scans/s
Beam deflection	Via rotating polygon wheel
Useful opening angle	Max. 60°
Optics models / resolution	High Density (N): 0.127 ... 0.20 mm Medium Density (M): 0.20 ... 0.5 mm Low Density (F): 0.30 ... 0.5 mm Ultra Low Density (L): 0.35 ... 0.8 mm Ink Jet (J): 0.50 ... 0.8 mm
Reading distance	See reading field curves
Laser class	1 acc. to IEC/EN 60825-1:2014 and 21 CFR 1040.10 with Laser Notice No. 56
Bar code data	
Code types	2/5 Interleaved, Code 39, Code 128, EAN 128, EAN / UPC, Codabar, Code 93, GS1 DataBar, EAN Addendum
Bar code contrast (PCS)	$\geq 60\%$
Ambient light tolerance	2000 lx (on the bar code)
Number of bar codes per scan	3
Electrical data	
Interface type	2x Ethernet on 2x M12 (D-coded)
Protocols	Ethernet TCP/IP (client/server) / UDP
Baud rate	10/100MBaud
Data formats	
Service interface	USB 2.0 Mini-B type socket
Switching input / switching output	2 switching inputs/outputs, freely programmable functions - Switching input: 18 ... 30 V DC depending on supply voltage, I max. = 8 mA - Switching output: 18 ... 30VDC depending on supply voltage, I max. = 60 mA (short-circuit proof) Switching inputs/outputs protected against polarity reversal!
Operating voltage	18 ... 30VDC (Class 2, protection class III)
Power consumption	Max. 3.7W
Operating and display elements	
Display	Monochromatic graphical display, 128 x 32 pixel, with background lighting
Keyboard	2 keys
LEDs	2 LEDs for power (PWR) and bus state (NET), two-colored (red/green)
Mechanical data	
Degree of protection	IP 65 ¹⁾
Weight	270 g (without connection hood)
Dimensions (H x W x D)	44 x 95 x 68 mm (without connection hood)
Housing	Diecast aluminum

Table 5.1: Technical data of the BCL 308/line/raster scanners without heating

Type	BCL 308/ Ethernet
Design	Line scanner without heating
Environmental data	
Operating temperature range	0 °C ... -40 °C
Storage temperature range	-20 °C ... +70 °C
Air humidity	Max. 90% rel. humidity, non-condensing
Vibration	IEC 60068-2-6, test Fc
Shock	IEC 60068-2-27, test Ea
Continuous shock	IEC 60068-2-29, test Eb
Electromagnetic compatibility	EN 55022; IEC 61000-6-2 (contains IEC 61000-4-2, -3, -4, -5 and -6) ²⁾

Table 5.1: Technical data of the BCL 308/*i*/line/raster scanners without heating

- 1) Only with the MS 308, MK 308 or MK 308 connection hood and screwed-on M12 connectors or cable bushings and mounted caps. Minimum tightening torque of the housing connecting screw of the connection hood is 1.4Nm!
- 2) This is a Class A product. In a domestic environment this product may cause radio interference, in which case the operator may be required to take adequate measures.

⚠ ATTENTION!	
	For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).



The BCL 308/*i*/bar code readers are designed in accordance with protection class III for supply by PELV (protective extra-low voltage with reliable disconnection).

5.1.2 Oscillating-mirror scanner

Technical data same as for line scanner without heating, however with the following differences:

Type	BCL 308/ Ethernet
Design	Oscillating-mirror scanner without heating
Optical data	
Beam exit	Lateral zero position at an angle of 90°
Beam deflection	Via rotating polygon wheel (horizontal) and stepping motor with mirror (vertical)
Oscillation frequency	0 ... 10 Hz (adjustable, max. frequency is dependent on set swivel angle)
Max. swivel angle	±20° (adjustable)
Reading field height	See reading field curves
Electrical data	
Power consumption	Max. 4.9W
Mechanical data	
Weight	580 g (without connection hood)
Dimensions (H x W x D)	58 x 125 x 110 mm (without connection hood)

Table 5.2: Technical data of the BCL 308/*i*/oscillating-mirror scanners with heating

5.1.3 Line / raster scanner with deflecting mirror

Technical data same as for line scanner without heating, however with the following differences:

Type	BCL 308/ Ethernet
Design	Line scanner with deflecting mirror without heating
Optical data	
Beam exit	Lateral zero position at an angle of 105°
Beam deflection	Via rotating polygon wheel (horizontal) and deflecting mirror (vertical)
Electrical data	
Power consumption	Max. 3.7W
Mechanical data	
Weight	350 g (without connection hood)
Dimensions (H x W x D)	44 x 103 x 96 mm (without connection hood)

Table 5.3: Technical data of the BCL 308/*i* deflecting mirror scanners without heating

5.2 Heating models of the bar code readers

The BCL 308/*i* bar code readers are optionally available as models with integrated heating. In this case, heating is permanently installed ex works. Self-installation on-site by the user is not possible!

Features

- Integrated heating (permanently installed)
- Extends the application range of the BCL 308/*i* to -35 °C
- Supply voltage 24VDC ±20%
- Enabling the BCL 308/*i* through an internal temperature switch (switch-on delay about 30 min for 24 V DC and minimum ambient temperature of -35 °C)
- Necessary conductor cross-section for the voltage supply: at least 0.75 mm²; the use of ready-made cables is, thus, not possible

Structure

The heating consists of two parts:

- The front cover heater
- The housing heater

Function

When the 24 V DC supply voltage is applied to the BCL 308/*i*, a temperature switch initially only connects the heating to electrical power (front cover heater and housing heater). During the heating phase (around 30 min), when the inside temperature rises above 15 °C, the temperature switch connects the BCL 308/*i* to the supply voltage. This is followed by the self test and the changeover to read operation. The **PWR** LED lights up, showing overall readiness for operation.

When the inside temperature reaches approx. 18 °C, another temperature switch turns the housing heater off and, if necessary, back on again (if the inside temperature drops below 15 °C). This does not interrupt the read operation. The front cover heater remains activated until an inside temperature of 25 °C is reached. At temperatures above this, the front cover heater switches off and, with a switching hysteresis of 3 °C, back on again at an inside temperature below 22 °C.

Mounting location

NOTE	
	The mounting location is to be selected such that it does not expose the BCL 308/ <i>i</i> with heating directly to a cold air stream. To achieve an optimal heating effect, the BCL 308/ <i>i</i> should be mounted so that it is thermally isolated.

Electrical connection

The required wire cross section of the connection cable for the voltage supply must be at least 0.75 mm².

⚠ ATTENTION!	
	The voltage supply must not be looped through from one device to the next.

Power consumption

The energy requirement depends on the model:

- the line/raster scanner with heating consumes a maximum of 27W power.
- the line scanner with oscillating mirror and heating consumes a maximum of 45W.
- the line/raster scanner with deflecting mirror and heating consumes a maximum of 27W power.

These values are based on operation with unconnected switching outputs.

5.2.1 Line scanner / raster scanner with heating

Technical data same as for line scanner without heating, however with the following differences:

Type	BCL 308/ Ethernet
Design	Line scanner with heater
Electrical data	
Operating voltage	24 VDC ± 20 %
Power consumption	Max. 17.7W
Structure of the heating	Housing heating and separate heating of the optics glass
Warmup time	Min. 30 min at +24 V DC and an ambient temperature of -35 °C
Min. conductor cross section	Conductor cross section of at least 0.75 mm ² for the supply-voltage line. Wiring through of the voltage supply to multiple heating devices is not permissible. Standard, M12 ready-made cable not usable (insufficient cable cross-section)
Environmental data	
Operating temperature range	-35°C ... +40°C
Storage temperature range	-20°C ... +70°C

Table 5.4: Technical data of the BCL 308/i line / raster scanners with heating

5.2.2 Oscillating-mirror scanner with heating

Technical data same as for line scanner without heating, however with the following differences:

Type	BCL 308/ Ethernet
Design	Oscillating-mirror scanner with heating
Optical data	
Useful opening angle	Max. 60°
Max. swivel angle	±20° (adjustable)
Electrical data	
Operating voltage	24VDC ± 20%
Power consumption	Max. 26.7W
Structure of the heating	Housing heating and separate heating of the optics glass
Warmup time	Min. 30 min at +24 V DC and an ambient temperature of -35 °C
Min. conductor cross section	Conductor cross section of at least 0.75 mm ² for the supply-voltage line. Wiring through of the voltage supply to multiple heating devices is not permissible. Standard, M12 ready-made cable not usable (insufficient cable cross-section)
Environmental data	
Operating temperature range	-35°C ... +40°C
Storage temperature range	-20°C ... +70°C

Table 5.6: Specifications of the BCL 308/i oscillating-mirror scanners with heating

5.2.3 Line scanner / raster scanner with deflecting mirror and heating

Technical data same as for line scanner without heating, however with the following differences:

Type	BCL 308/ Ethernet
Design	Deflecting mirror scanner with heating
Optical data	
Useful opening angle	Max. 60°
Max. adjustment range	±10°(adjustable via display or software)
Electrical data	
Operating voltage	24VDC ± 20%
Power consumption	Max. 19.7W
Structure of the heating	Housing heating and separate heating of the optics glass
Warmup time	Min. 30 min at +24 V DC and an ambient temperature of -35 °C
Min. conductor cross section	Conductor cross section of at least 0.75 mm ² for the supply-voltage line. Wiring through of the voltage supply to multiple heating devices is not permissible. Standard, M12 ready-made cable not usable (insufficient cable cross-section)
Environmental data	
Operating temperature range	-35°C ... +40°C
Storage temperature range	-20°C ... +70°C

Table 5.7: Technical data of the BCL 308/deflecting mirror scanners with heating

5.3 Dimensioned drawings

5.3.1 Dimensioned drawing of complete overview of the BCL 308/i with MS 3xx / MK 3xx / ME 3xx




Figure 5.1: Dimensioned drawing of complete overview of the BCL 308/i with MS 3xx / MK 3xx / ME 3xx

5.3.2 Dimensioned drawing of line scanner with / without heating




Figure 5.2: Dimensioned drawing of BCL 308/S...102 line scanner

5.3.3 Dimensioned drawing of deflecting mirror scanner with / without heating




Figure 5.3: Dimensioned drawing of BCL 308/i/S...100 with deflecting mirror

5.3.4 Dimensioned drawing of oscillating-mirror scanner with / without heating




Figure 5.4: Dimensioned drawing of BCL 308/O...100 oscillating-mirror scanner

5.3.5 Dimensioned drawings of MS 3xx / ME 3xx / MK 3xx connection hoods




Figure 5.5: Dimensioned drawing of MS 3xx connector hood / ME 3xx connection hood




Figure 5.6: Dimensioned drawing of MK 3xx terminal hood

5.4 Reading field curves / optical data

5.4.1 Bar code characteristics


NOTE	
	Please note that the size of the bar code module influences the maximum reading distance and the width of the reading field. Therefore, when selecting a mounting location and/or the bar code label, take into account the different reading characteristics of the scanner with various bar code modules.
	<p>M = Module: The narrowest line or space of a bar code in mm</p> <p>Z_B = Wide character: Wide bars and gaps are a multiple (ratio) of the module. Module x Ratio = Z_B (Normal Ratio 1 : 2.5)</p> <p>B_z = Quiet zone: The quiet zone should be at least 10 times the module, but not less than 2.5mm.</p> <p>L = Code length: The length of the bar code in mm including the start and stop characters. The quiet zone is included depending on the code definition.</p> <p>S_L = Bar length: height of the elements in mm</p>

Figure 5.7: The most important characteristics of a bar code

The range in which the bar code can be read by the BCL 308*i* (the so-called reading field) depends on the quality of the printed bar code and its dimensions.

Therefore, above all, the module of a bar code is decisive for the size of the reading field.

NOTE	
	A rule of thumb: The smaller the module of the bar code is, the smaller the maximum reading distance and reading field width will be.

5.4.2 Raster scanner

A raster variant is also available in the BCL 300*i* series. The BCL 300*i* as a raster scanner projects 8 scan lines which vary depending on the reading distance from the raster aperture.

		Distance [mm] starting at the zero position						
		50	100	200	300	400	450	700
Raster line cover [mm] all raster lines	Front scanner	8	14	24	35	45	50	77
	Deflecting mirror scanner	12	17	27	38	48	54	80

Table 5.8: Raster line cover dependent on the distance

NOTE	
	With the raster scanner, there may not be two or more bar codes in the raster area at the same time.

5.5 Reading field curves

NOTE	
i	Please notice that the real reading fields are also influenced by factors such as labeling material, printing quality, reading angle, printing contrast etc., and may thus deviate from the reading fields specified here. The reading field curves also apply for the device models with heating.

The zero position of the reading distance always refers to the front edge of the housing of the beam exit and is shown for the three housing types of the BCL 308*i* in Figure 5.8.




Figure 5.8: Zero position of the reading distance

Reading conditions for the reading field curves

Bar code type	2/5 Interleaved
Ratio	1:2.5
ANSI specification	Class A
Reading rate	> 75%

Table 5.9: Reading conditions

5.5.1 High Density (N) - optics: BCL 308/S/R1 N 102 (H)




Figure 5.9: "High Density" reading field curve for line scanner without deflecting mirror

5.5.2 High Density (N) - optics: BCL 308/S/R1 N 100 (H)




Figure 5.10: "High Density" reading field curve for line scanner with deflecting mirror

The reading field curve applies for the reading conditions stated in Table 5.9.

5.5.3 Medium Density (M) - optics: BCL 308*i*/S/R1 M 102 (H)




Figure 5.11: "Medium Density" reading field curve for line scanner without deflecting mirror

5.5.4 Medium Density (M) - optics: BCL 308*i*/S/R1 M 100 (H)




Figure 5.12: "Medium Density" reading field curve for line scanner with deflecting mirror

The reading field curves apply for the reading conditions stated in Table 5.9.

5.5.5 Medium Density (M) - optics: BCL 308*i*/O M 100 (H)




Figure 5.13: "Medium Density" reading field curve for oscillating-mirror scanners




Figure 5.14: Lateral "Medium Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 5.9.

5.5.6 Low Density (F) - optics: BCL 308*i*/S/R1 F 102 (H)




Figure 5.15: "Low Density" reading field curve for line scanner without deflecting mirror

5.5.7 Low Density (F) - optics: BCL 308*i*/S/R1 F 100 (H)




Figure 5.16: "Low Density" reading field curve for line scanner with deflecting mirror
The reading field curves apply for the reading conditions stated in Table 5.9.

5.5.8 Low Density (F) - optics: BCL 308*i*/O F 100 (H)




Figure 5.17: "Low Density" reading field curve for oscillating-mirror scanners




Figure 5.18: Lateral "Low Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 5.9.

5.5.9 Ultra Low Density (L) - optics: BCL 308/i S L 102 (H)




Figure 5.19: "Ultra Low Density" reading field curve for line scanner without deflecting mirror

5.5.10 Ultra Low Density (L) - optics: BCL 308/i S L 100 (H)




Figure 5.20: "Ultra Low Density" reading field curve for line scanner with deflecting mirror

The reading field curves apply for the reading conditions stated in Table 5.9.

5.5.11 Ultra Low Density (L) - optics: BCL 308/i O L 100 (H)




Figure 5.21: "Ultra Low Density" reading field curve for oscillating-mirror scanners




Figure 5.22: Lateral "Ultra Low Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 5.9.

5.5.12 Ink Jet (J) - optics: BCL 308/R1 J 100




Figure 5.23: "Ink Jet" reading field curve for line scanner with deflecting mirror

NOTE



Please note that the real reading distances are also influenced by factors such as labeling material, printing quality, scanning angle, printing contrast, etc., and may thus deviate from the reading distances specified here.

Due to the shape of the optical laser spot, the CRT function may exhibit limitations (max. permissible tilt angle of $\pm 15^\circ$).

Low-contrast bar codes that are printed with inkjet should be sent to Leuze for examination.

6 Installation and mounting

6.1 Storage, transportation

⚠ ATTENTION!	
	Package the device for transport and storage in such a way that is protected against shock and humidity. Optimum protection is achieved when using the original packaging. Ensure compliance with the approved environmental conditions listed in the specifications.

Unpacking

- ↪ Check the packaging content for any damage. If damage is found, notify the post office or shipping agent as well as the supplier.
- ↪ Check the delivery contents using your order and the delivery papers:
 - Delivered quantity
 - Device type and model as indicated on the nameplate
 - Brief manual

The name plate provides information as to what BCL type your device is. For specific information, please refer to Chapter 5.

Name plates of the bar code readers of the BCL 308/series




Figure 6.1: Device name plate BCL 308/

- ↪ Save the original packaging for later storage or shipping.

NOTE	
	All BCL 308/are delivered with a protective cover on the connection side which must be removed before attaching a connection hood.

If you have any questions concerning your shipment, please contact your supplier or your local Leuze sales office.

- ↪ Observe the applicable local regulations when disposing of the packaging materials.

6.2 Mounting the BCL 308/

The BCL 308/bar code readers can be mounted in different ways:

- Via four or six M4x5 screws on the device bottom.
- Via a BT 56/BT 59 mounting device in the two fastening grooves on the device bottom.

⚠ ATTENTION!	
	The BCL 308/does not fulfill degree of protection IP 65 until the connection hood has been screwed on. Minimum tightening torque of the housing connecting screw of the connection hood is 1.4Nm!

6.2.1 Mounting via M4 x 5 screws




Figure 6.2: Fastening options using M4x5 threaded holes

6.2.2 Mounting devices BT 56 and BT 56-1

The BT 56 or BT 56-1 mounting device is available for mounting the BCL 308/i using the fastening grooves. It is designed for rod mounting ($\varnothing 16$ mm to 20 mm), the BT 56-1 for rods from $\varnothing 12$ mm to 16 mm. For order guide, please refer to chapter "Type overview and accessories" on page 104.

Mounting devices BT 56 and BT 56-1




Figure 6.3: Mounting devices BT 56 and BT 56-1



Figure 6.4: Mounting example of BCL 308*i* with BT 56

6.2.3 BT 59 mounting device

The BT 59 mounting device offers you an additional fastening option. For order guide, please refer to chapter "Type overview and accessories" on page 104.

BT 59 mounting device




Figure 6.5: BT 59 mounting device

NOTE	
	When mounting, ensure that the scanning beam is not reflected directly back to the scanner by the label which is being read. For further information, see the notices in Chapter 6.3! Please refer to Chapter 5.4 for the permissible minimum and maximum distances between the BCL 308 <i>i</i> and the labels to be read.

6.2.4 BT 300 - 1, BT 300 W mounting devices

Mounting brackets BT 300 W and BT 300 - 1 offer you an additional mounting option. For ordering instructions, please refer to chapter "Type overview and accessories" on page 104.

BT 300 - 1, BT 300 W mounting devices




Figure 6.6: BT 300 - 1, BT 300 W mounting devices

NOTE	
	When mounting, ensure that the scanning beam is not reflected directly back to the scanner by the label which is being read. For further information, see the notices in Chapter 6.3! Please refer to Chapter 5.4 for the permissible minimum and maximum distances between the BCL 308 <i>i</i> and the labels to be read.

6.3 Device arrangement

6.3.1 Selecting a mounting location

In order to select the right mounting location, several factors must be considered:

- Size, orientation, and position tolerance of the bar codes on the objects to be scanned.
- The reading field of the BCL 308*i* in relation to the bar code module width.
- The resulting minimum and maximum reading distance from the respective reading field (see chapter 5.4 "Reading field curves / optical data").
- The permissible cable lengths between the BCL 308*i* and the host system depending on which interface is used.
- The correct time for data output. The BCL 308*i* should be positioned in such a way that, taking into consideration the time required for data processing and the conveyor belt speed, there is sufficient time to e.g. initiate sorting operations on the basis of the read data.
- The display elements such as LEDs or the display should be highly visible.
- For configuring and commissioning with the webConfig tool, the USB interface should be easily accessible.

For specific information, please refer to Chapter 6 and Chapter 7.

NOTE	
i	<p>The beam of the BCL 308<i>i</i> exits:</p> <ul style="list-style-type: none"> • Parallel to the housing base in the case of the line scanner • At 105 degrees from the housing base in the case of the deflecting mirror • Perpendicular to the housing base in the case of the oscillating mirror <p>In each case, the housing base is the black area in Figure 6.2. The best read results are obtained when:</p> <ul style="list-style-type: none"> • The BCL 308<i>i</i> is mounted in such a way that the scanning beam is incident on the bar code at an angle of inclination greater than $\pm 10^\circ \dots 15^\circ$ to vertical. • The reading distance lies in the middle area of the reading field. • The bar code labels are of good print quality and have good contrast ratios. • You do not use high-gloss labels. • There is no direct sunlight.

6.3.2 Avoiding total reflection – Line scanner

The bar code label must be positioned at an angle of inclination greater than $\pm 10^\circ \dots 15^\circ$ from vertical in order to avoid total reflection of the laser beam (see Figure 6.7)!

Total reflection occurs whenever the laser light of the bar code reader is directly incident on the surface of the bar code at an angle of 90° . The light directly reflected by the bar code may overload the bar code reader and thereby cause non-readings!




Figure 6.7: Total reflection – line scanner

6.3.3 Avoiding total reflection – deflecting mirror scanner

For the BCL 308*i* with **deflecting mirror**, the laser beam exits at an angle of 105° to the rear housing wall. An angle of incidence of 15° of the laser to the label has already been integrated in the deflecting mirror so that the BCL 308*i* can be installed parallel to the bar code (rear housing wall).




Figure 6.8: Total reflection – line scanner

6.3.4 Avoiding total reflection – oscillating-mirror scanner

For the BCL 308*i* with **oscillating mirror**, the laser beam exits at an angle of 90° to vertical. For the BCL 308*i* with **oscillating mirror**, the **swivel range of ±20° (±12° for devices with heating) is to be taken into account**.

This means that in order to be on the safe side and to avoid total reflection, the BCL 308*i* with oscillating mirror must be inclined upward or downward 20° ... 30°!

NOTE	
	Mount the BCL 308 <i>i</i> with oscillating mirror in such a way that the exit window of the bar code reader is parallel to the object. This will result in an angle of inclination of approx. 25°.




Figure 6.9: Total reflection – BCL 308*i* with oscillating-mirror scanner

6.3.5 Mounting location

- ☞ When choosing the mounting location, observe the following:
- Maintaining the required environmental conditions (temperature, humidity).
 - Possible soiling of the reading window due to liquids, abrasion by boxes, or packaging material residues.
 - Lowest possible chance of damage to the BCL 308*i* by mechanical collision or jammed parts.
 - Possible extraneous light (no direct sunlight or sunlight reflected by the bar code).

6.3.6 Devices with integrated heating

↪ When mounting devices with integrated heating, also observe the following points:

- Mount the BCL 308*i* in a way which provides maximum thermal isolation, e.g. using rubber-bonded metal.
- Mount in such a way that the device is protected from draft and wind; mount additional shields if necessary.

NOTE	
	When installing the BCL 308 <i>i</i> in a protective housing, it must be ensured that the scanning beam can exit the protective housing without obstruction.

6.3.7 Possible read angles between BCL 308*i* and bar code

The optimum alignment of the BCL 308*i* is accomplished when the scan line scans the bar code bars almost at a right angle (90°). All reading angles that are possible between the scan line and bar code must be taken account (Figure 6.10).




Figure 6.10: Reading angle for the line scanner

- α Azimuth angle (tilt)
 - β Inclination angle (pitch)
 - γ Angle of rotation (skew)
- In order to avoid total reflection, the angle of rotation γ should be greater than 10°

6.4 Cleaning

↪ Clean the glass window of the BCL 308*i* with a soft cloth after mounting. Remove all packaging remains, e.g. carton fibers or styrofoam balls. In doing so, avoid leaving fingerprints on the front screen of the BCL 308*i*.

⚠ ATTENTION!	
	Do not use aggressive cleaning agents such as thinner or acetone for cleaning the device.

7 Electrical connection

The bar code readers of the BCL 300*i* series feature a modular connection concept with interchangeable connection hoods.

The additional Mini-B type USB interface is used for configuring the device.

NOTE	
	On delivery, the products are provided with a plastic protective cap on the side of the system plug or the system socket. Additional connection accessories can be found in Chapter 13.

⚠ ATTENTION!	
	The BCL 308 <i>i</i> does not fulfill degree of protection IP 65 until the connection hood has been screwed on. Minimum tightening torque of the housing connecting screw of the connection hood is 1.4Nm!

Location of the electrical connections




Figure 7.1: Location of the electrical connections

7.1 Safety notices for the electrical connection

⚠ ATTENTION!	
	Do not open the device yourself under any circumstances! There is otherwise a risk of uncontrolled emission of laser radiation from the device. The housing of the BCL 308 <i>i</i> contains no parts that need to be adjusted or maintained by the user. Before connecting the device, be sure that the supply voltage agrees with the value printed on the name plate. Connection of the device and cleaning must only be carried out by a qualified electrician. Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly. If faults cannot be cleared, the device should be switched off and protected against accidental use.

⚠ ATTENTION!

For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).



*The bar code readers of the BCL 300*i* series are designed in accordance with protection class III for supply by PELV (protective extra-low voltage with reliable disconnection).*

NOTE

Degree of protection IP 65 is not fulfilled until connectors or cable bushings are screwed on and caps are installed!

⚠ ATTENTION!

To ensure degree of protection IP 65 is fulfilled, the screws of the connection hood are tightened with a tightening torque of 1.4 Nm for connecting to the BCL.

7.2 BCL 308/i electrical connection

For the electrical connection of the BCL 308/i, 2 connection variants are available.

The **voltage supply** (18 ... 30VDC) is connected acc. to the connection type selected.

2 freely programmable switching inputs/outputs for individual adaptation to the respective application are also available here. Detailed information on this topic can be found in Chapter 7.3.1.

7.2.1 MS 308 connector hood with 3 integrated M12 connectors

The MS 308 hood with integrated connectors features three M12 connector plugs and a Mini-B type USB socket as a service interface. Parameter memory is integrated into the MS 308 which temporarily stores the settings of the BCL 308/i in the case of replacement and transmits them to a new device.




Figure 7.2: BCL 308/i- MS 308 connection hood with M12 connectors

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the MS 308. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet linear topology, the network is interrupted when the BCL 308/i is removed from the MS 308.
NOTE	
	Dimensioned drawing on see chapter 5.3.5 "Dimensioned drawings of MS 3xx / ME 3xx / MK 3xx connection hoods" on Page 40.

7.2.2 ME 308 103 connection hood with M12 connection cables

The ME 308 103 connection hood features three connection cables with M12 connectors and a Mini-B type USB socket as service interface. Parameter memory is integrated into the ME 308 103 which temporarily stores the settings of the BCL 308/i in the case of replacement and transmits them to a new device.




Figure 7.3: BCL 308/i- ME 308 103 connection hood with M12 connection cables

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the ME 308 103. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet line topology, the network is interrupted when the BCL 308/i is removed from the ME 308 103.
NOTE	
	Dimensioned drawing on see chapter 5.3.5 "Dimensioned drawings of MS 3xx / ME 3xx / MK 3xx connection hoods" on Page 40.

7.2.3 ME 308 104 connection hood with M8/M12 connection cables

The ME 308 104 connector hood features three connection cables with M12 connectors, a connection cable with M8 connectors and a Mini-B type USB socket as service interface. Parameter memory is integrated into the ME 308 104 which temporarily stores the settings of the BCL 308/i in the case of replacement and transmits them to a new device.




Figure 7.4: BCL 308*i*- ME 308 104 connection hood with M8/M12 connection cables

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308 <i>i</i> is located in the ME 308 104. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet line topology, the network is interrupted when the BCL 308 <i>i</i> is removed from the ME 308 104.
NOTE	
	Dimensioned drawing on see chapter 5.3.5 "Dimensioned drawings of MS 3xx / ME 3xx / MK 3xx connection hoods" on Page 40.

7.2.4 ME 308 214 connection hood with M8/M12/RJ45 connection cables

The ME 308 214 connector hood features a connection cable with M12 connectors, two connection cables with RJ45 sockets, a connection cable with M8 connectors and a Mini-B type USB socket as service interface. Parameter memory is integrated into the ME 308 214 which temporarily stores the settings of the BCL 308*i* in the case of replacement and transmits them to a new device.




Figure 7.5: BCL 308/i - ME 338 214 connection hood with M8/M12/RJ45 connection cables

NOTE	
	The shielding connection is done via the M12 connector housing.
NOTE	
	The integrated parameter memory for the simple replacement of the BCL 308/i is located in the ME 308 214. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.
NOTE	
	In the case of Ethernet line topology, the network is interrupted when the BCL 308/i is removed from the ME 308 214.
NOTE	
	Dimensioned drawing on see chapter 5.3.5 "Dimensioned drawings of MS 3xx / ME 3xx / MK 3xx connection hoods" on Page 40.

7.2.5 MK 308 terminal hood with spring-cage terminals

The MK 308 terminal hood makes it possible to connect the BCL 308/i directly and without additional connectors. The MK 308 features three cable lead-throughs in which the shielding connection for the interface cable is also located. The BCL 308/i is also to be configured when the MK 308 is in a closed state via a Mini-B type USB socket functioning as the service interface. Parameter memory is integrated into the MK 308 which temporarily stores the settings of the BCL 308/i in the case of replacement and transmits them to a new device.




Figure 7.6: BCL 308/i - MK 308 terminal hood with spring-cage terminals

NOTE

i The integrated parameter memory for the simple replacement of the BCL 308/i is located in the MK 308. In the integrated parameter memory, both the settings and the network address are saved and transmitted to a new device.

NOTE

i In the case of Ethernet linear topology, the network is interrupted when the BCL 308/i is removed from the MK 308.

Cable fabrication and shielding connection

Remove approx. 78 mm of the connection cable sheathing. 15 mm of sheath of the shielded line must be freely accessible.




Figure 7.7: Cable fabrication for MK 308 terminal hood

The shield is automatically contacted when the cable is lead into the metal screw fitting and fastened when the cord grip is closed. Then lead the individual wires into the terminals according to the diagram. Wire end sleeves are not necessary.

NOTE

i Dimensioned drawing on see chapter 5.4 "Reading field curves / optical data" on Page 41.

7.3 Detailed description of the connections

Described in detail in the following are the individual connections and pin assignments.

7.3.1 PWR / SW IN/OUT - Voltage supply and switching input/output 1 and 2

PWR / SW IN/OUT			
	Pin (M12)	Name (terminal)	Comment
<p>MS 308 PWR / SW IN/OUT SWIO_1 2 GNDIN 3 VIN 1 FE 4 SWIO_2 M12 connector (A-coded) MK 308 FE GNDIN VIN SWIO_1 SWIO_2 Spring-cage terminals</p>	1	VIN	Positive supply voltage +18 ... +30VDC
	2	SWIO_1	Configurable switching input/output 1
	3	GNDIN	Negative supply voltage 0VDC
	4	SWIO_2	Configurable switching input/output 2
	5	FE	Functional earth
	Thread	FE	Functional earth (housing)

Table 7.1: PWR / SW IN/OUT pin assignment

Supply voltage

⚠ ATTENTION!	
	For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).



The bar code readers of the BCL 300*i* ... series are designed in accordance with protection class III for supply by PELV (protective extra-low voltage with reliable disconnection).

Connecting the functional earth FE

- ↪ Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly. All electrical disturbances (EMC couplings) are discharged via the functional earth connection.

Switching input/output

The bar code readers of the BCL 300*i* series are equipped with two freely programmable, opto-decoupled switching inputs and outputs, **SWIO_1** and **SWIO_2**.

The switching inputs can be used to activate various internal functions of the BCL 308*i* (decoding, auto-Config, ...). The switching outputs can be used to signal the state of the BCL 308*i* and to implement external functions independent of the superior control.

NOTE	
	The respective function as input or output can be set with the aid of the webConfig configuration tool!

Described in the following is the external wiring for use as a switching input or output; the respective function assignments to the switching inputs/outputs can be found in Chapter 10.

Function as switching input




Figure 7.8: Switching input connection diagram SWIO_1 and SWIO_2

↳ If you use a sensor with a standard M12 connector, please note the following:

- Pins 2 and 4 must not be operated as switching outputs if sensors which function as inputs are also connected to these pins.

If, for example, the inverted sensor output is connected to pin 2, and pin 2 of the bar code reader is, at the same time, configured as an output (and not as an input), the switching output malfunctions.

 ATTENTION!	
	The maximum input current must not exceed 8 mA!

Function as switching output




Figure 7.9: Switching output connection diagram SWIO_1 / SWIO_2

 ATTENTION!	
	Each configured switching output is short-circuit proof! Do not load the respective switching output of the BCL 308 <i>i</i> with more than 60 mA at +18 ... +30 VDC in normal operation!

NOTE	
	Both switching inputs/outputs SWIO_1 and SWIO_2 are configured by default in such a way that: <ul style="list-style-type: none"> • Switching input SWIO_1 activates the reading gate. • Switching output SWIO_2 switches by default on "No Read".

7.3.2 SENSOR - direct connection of an external sensor (ME 308 xx4 only)

Connection hoods ME 308 104 and ME 308 214 are equipped with an M8 connection cable for the direct connection of an external sensor (e.g., a trigger sensor)

PWR / SW IN/OUT			
	Pin (M8)	Name (terminal)	Comment
<p>ME 308 104 ME 308 214</p> <p>SENSOR</p> <p>SWIO_1 n. c. GNDOUT VOUT M8 socket</p>	1	VOUT	Positive supply voltage for ext. sensor +18 ... +30VDC
	2	n.c.	Not assigned
	3	GNDOUT	Negative supply voltage for ext. sensor 0VDC
	4	SWIO_1	Configurable switching input/output 1
	Thread	FE	Functional earth (housing)

Table 7.2: SENSOR pin assignment

7.3.3 SERVICE – USB interface (Mini-B type)

SERVICE – USB interface (Mini-B type)			
	Pin (USB Mini-B)	Name	Comment
<p>SERVICE</p> <p>VB D- D+ ID GND</p> <p>1 2 3 4 5</p>	1	VB	Sense input
	2	D-	Data -
	3	D+	Data +
	4	ID	Not connected
	5	GND	Ground

Table 7.3: SERVICE pin assignment – Mini-B type USB interface

⚡ Ensure adequate shielding.

The entire interconnection cable must absolutely be shielded acc. to the USB specifications. Cable length must not exceed 3 m.

⚡ Use the Leuze specific **USB service cable** (see chapter 13 "Type overview and accessories") for the connection and use a service PC to configure.

NOTE	
	IP 65 is achieved only if the connectors and caps are screwed into place.

7.3.4 HOST / BUS IN for BCL 308/i

The BCL 308/i makes either the Ethernet interface available as host interface.




HOST / BUS IN Ethernet_0 (4-pin socket, D-coded)			
MS 308 HOST / BUS IN	Pin (M12)	Name (terminal)	Comment
	1	TD0+	Transmit Data +
	2	RD0+	Receive Data +
	3	TD0-	Transmit Data -
	4	RD0-	Receive Data -
	FE via thread	FE via screw fitting	Functional earth (housing)

Table 7.4: Pin assignment HOST / BUS IN for BCL 308/i

Ethernet cable assignment



RJ45 - assignment and core colors

Pin	Signal	Name	Core color acc. to PROFINET	Core color acc. to EIA T568B
1	TD+	Transmission Data +	Yellow	White/orange
2	TD-	Transmission Data -	Orange	Orange
3	RD+	Receive Data +	White	White/Green
6	RD-	Receive Data -	Blue	Green

Figure 7.10: HOST / BUS IN cable assignments on RJ-45

NOTE	
	Ensure adequate shielding. The entire interconnection cable must be shielded and earthed. The RD+/RD- and TD+/TD- wires must be stranded in pairs. Use CAT 5 cable for the connection.

7.3.5 BUS OUT for the BCL 308*i*

To set up an Ethernet network with other participants with linear topology, the BCL 308*i* makes available another Ethernet interface. The use of this interface drastically reduces the cabling requirements, as only the first BCL 308*i* requires a direct connection to the switch, via which it can communicate with the host. All other BCL 308*i* are connected in series to the first BCL 308*i*, see Figure 7.12.

BUS OUT Ethernet_1 (4-pin socket, D-coded)			
	Pin (M12)	Name (terminal)	Comment
	1	TD1+	Transmit Data +
	2	RD1+	Receive Data +
	3	TD1-	Transmit Data -
	4	RD1-	Receive Data -
	FE via thread	FE via screw fitting	Functional earth (housing)

Table 7.5: Pin assignment BUS OUT for BCL 308*i*

If you use ready-made cables, note the following:

NOTE	
	Ensure adequate shielding. The entire interconnection cable must be shielded and earthed. The signal lines must be stranded in pairs. Use CAT 5 cables for the connection.
NOTE	
	For the BCL 308 <i>i</i> as stand-alone device or as the last participant in a linear topology, termination on the BUS OUT socket is not mandatory!

7.4 Ethernet topologies

The BCL 308*i* can be operated as a single device (stand-alone) in an Ethernet star topology with individual IP address.

The IP address can either be set permanently via display or webConfig tool or assigned dynamically via a DHCP server.




Figure 7.11: Ethernet in a star topology

The innovative further development of the BCL 308*i* with integrated switch functionality offers the option of networking multiple bar code readers of type BCL 308*i* with one another. In addition to the classic "star topology", a "linear topology" is thus also possible.

This makes wiring the network easy and inexpensive as slaves are looped through to one another in parallel.

The maximum length of a segment (connection from the hub to the last participant) is limited to 100m.




Figure 7.12: Ethernet in a linear topology

Up to 254 bar code readers can be networked. For this purpose, each participating BCL 308*i* is assigned the respective network address via the webConfig Tool. This address must be specified by the network administrator. Alternatively, the BCL 308*i* can also be configured as a DHCP client and then automatically receive its address from a DHCP server.

Information on the necessary configuration steps can be found in Chapter 10.

7.4.1 Ethernet wiring

A cat. 5 Ethernet cable should be used for wiring.

For the connection on the BCL 308*i*, a "KDS ET M12 / RJ 45 W - 4P" adapter is available into which the standard network cable can be plugged.

For unavailable cable lengths, you can configure your cables yourself. When doing so, make certain that you connect **TDx+** on the M12 connector with **RD+** on the RJ-45 connector and **TDx-** on the M12 connector with **RD-** on the RJ-45 connector, respectively, etc.

NOTE	
	Use the recommended plugs / sockets or the ready-made cables (see chapter 13 "Type overview and accessories").

7.5 Cable lengths and shielding

↪ Observe the following maximum cable lengths and shielding types:

Connection	Interface	Max. cable length	Shielding
BCL – service	USB	3m	Shielding absolutely necessary acc. to USB specifications
BCL – host	Ethernet	100m	Shielding absolutely required
Network from the first BCL to the last BCL	Ethernet	The maximum segment length must not exceed 100 m for 10Base-T Twisted Pair (min. Cat. 3) and 100Base-TX Twisted Pair (min. Cat. 5)	Shielding absolutely required
BCL – power supply unit		30m	Not necessary
Switching input		10 m	Not necessary
Switching output		10 m	Not necessary

Table 7.6: Cable lengths and shielding

8 Display elements and display

The BCL 308/i is available optionally with display, 2 control buttons and LEDs or with only 2 LEDs as display elements.

8.1 BCL 308/i LED indicators



Figure 8.1: BCL 308/i - LED indicators

2 multicolor LEDs are used as the primary display instrument.

LED functions:

PWR LED

<p>PWR ● Off</p>	<p>Device OFF</p> <ul style="list-style-type: none"> - No supply voltage
<p>PWR ● Green, flashing</p>	<p>Device ok, initialization phase</p> <ul style="list-style-type: none"> - No bar code reading possible - Voltage connected - Self test runs for 0.25s after power up - Initialization running
<p>PWR ● Green, continuous light</p>	<p>Device ok</p> <ul style="list-style-type: none"> - Bar code reading possible - Self test successfully finished - Device monitoring active
<p>PWR ● Green, briefly off - on</p>	<p>Good read, successful reading</p> <ul style="list-style-type: none"> - Bar code(s) successfully read
<p>PWR ● Green, briefly off - briefly red - on</p>	<p>No read, reading not successful</p> <ul style="list-style-type: none"> - Bar code(s) not read
<p>PWR ● Orange, continuous light</p>	<p>Service mode</p> <ul style="list-style-type: none"> - Bar code reading possible - Configuration via the USB service interface - No data on the host interface
<p>PWR ● Red, flashing</p>	<p>Warning set</p> <ul style="list-style-type: none"> - Bar code reading possible - Self test runs for 0.25s after power up - Temporary operating fault

PWR



Red, continuous light

Device error

- No bar code reading possible

NET LED

NET



Off

No supply voltage,

- No communication possible
- Ethernet protocols not released

NET



Flashes green

Initialization

- of the BCL 308*i*, establishing communication

NET



Green, continuous light

Operation ok

- Network operation ok
- Connection and communication to host established

NET



Flashes red

Communication error

- Temporary connection error
- If DHCP is active, no address could be obtained

NET



Red continuous light

Network error

8.2 MS 308/ME 308.../MK 308 LED indicators




Figure 8.2: MS 308/ME 308.../MK 308 - LED indicators

As a status display for the two Ethernet connections, **Ethernet_0** and **Ethernet_1**, there are 2 split two-colored LEDs each in the MS 308, ME 308... and MK 308:

LED ACT0 / LINK0 (on the MS 308/ME 308/MK 308)

	<p>Green, continuous light Yellow, flickering light</p>	<p>Ethernet connected (LINK) Data communication (ACT)</p>
---	---	---

LED ACT1 / LINK1 (on the MS 308/ME 308/MK 308)

	<p>Green, continuous light Yellow, flickering light</p>	<p>Ethernet connected (LINK) Data communication (ACT)</p>
---	---	---

8.3 BCL 308/*i* display



Figure 8.3: BCL 308/*i*- Display

NOTE	
	The function of the LEDs is identical for the devices with and without display.

The optional display of the BCL 308/*i* has the following features:

- Monochromatic with background lighting (blue/white)
- Double line, 128 x 32 pixels
- Display language: English

The display is only used as a **display element**. Two buttons can control which values are displayed. In doing so, the upper line displays the selected function and the lower line displays the result.

The background lighting is activated by the push of any button and automatically deactivated after a defined point in time:

Display functions

The following functions can be displayed and activated:

- Reading result = result of reading process
- Decodequality = quality of decoding process
- BCL Info = device status/error code
- I/O Status = status of the inputs/outputs
- BCL Address = IP address of the BCL 308/*i*
- Adjustmode = alignment mode
- Version = software and hardware version

After the voltage is switched off/on, the reading result is always displayed.

The display is controlled via the two control buttons:

- | | | |
|---|--------------|---|
|  | ENTER | Activation/deactivation of the display change function |
|  | Down | Scroll through functions (downwards) |

Example:

Representation of the BUS status on the display:

1. Press button  : Display flashes
2. Press button  : Display changes from read result to decoding quality
3. Press button  : Display changes from decoding quality to device status
4. Press button  : Display changes from device status to BUS status
5. Press button  : Bus status displayed, display stops flashing.

Description of the display functions

Reading result
88776655

- 1st line: **read result** display function
- 2nd line: code content of the bar code, e.g. **88776655**

Decoding quality
84

- 1st line: **decoding quality** display function
- 2nd line: decoding quality in percent, e.g. **84%**

BCL info
Error code 3201

- 1st line: **device status** display function
- 2nd line: error code, e.g. **Error code 3201**

I/O status
In = 0 Out = 1

- 1st line: input/output **status** display function
- 2nd line: state: 0 = inactive, 1 = active, e.g. **In=0, Out=1**

BCL address
192.168.060.0

- 1st line: **IP address** display function
- 2nd line: set address, e.g. **192.168.060.0**

Adjust mode
73

- 1st line: **alignment mode** display function
- 2nd line: decoding quality in percent, e.g. **73%**

Version
SW: xxxxx HW: xxx

- 1st line: **version** display function
- 2nd line: software and hardware version of the device

9 Leuze webConfig tool

With the **Leuze webConfig tool**, an operating-system independent, web-technology based, graphical user interface is available for configuring bar code readers of the BCL 300*i* series.

Through the use of HTTP as communication protocol and by using only standard technologies on the client side (HTML, JavaScript and AJAX), which are supported by all commonly used, modern browsers (e.g. **Mozilla Firefox** beginning with Version 4.0 or **Internet Explorer** beginning with Version 8.0 or Microsoft **Edge**), it is possible to operate the **Leuze webConfig tool** on any internet-ready PC.

NOTE



The webConfig tool is offered in 6 languages:

- German
- English
- French
- Italian
- Spanish
- Chinese

9.1 Connecting the SERVICE USB interface

The connection to the SERVICE USB interface of the BCL 308*i* is established via the PC-side USB interface using a standard USB cable with 1 type A connector and a Mini-B type connector.



Figure 9.1: Connecting the SERVICE USB interface

9.2 Installing the required software

9.2.1 System requirements

Operating system:	Windows 2000 Windows XP (Home Edition, Professional) Windows Vista Windows 7 Windows 8/8.1 Windows 10
Computer:	PC with USB interface version 1.1 or higher
Graphics card:	Min. 1024 x 768 pixels or higher resolution
Required hard drive capacity:	Approx. 10MB

NOTE



It is recommended to update the operating system and the browser regularly and to install the current Windows service packs.

9.2.2 Installing the USB driver

NOTE



If you have already installed a USB driver for a BCL 5xx*i* on your computer, you don't have to install the USB driver for the BCL 308*i*. In this case, you can also start the webConfig tool of the BCL 308*i* by double-clicking on the BCL 5xx*i* icon.

In order for the BCL 308*i* to be automatically detected by the connected PC, the **USB driver** must be installed **once** on your PC. To do this, you must have **administrator privileges**.

Please proceed according to the following steps:

- ↳ Start your PC with administrator privileges and log on.
- ↳ Load the CD included in the delivery contents of your BCL 308*i* in the CD drive and start the setup.exe program.
- ↳ Alternatively, you can also download the setup program from the internet at www.leuze.com.
- ↳ Follow the instructions provided by the setup program.

Upon successful installation of the USB driver, an icon  with the name **Leuze Web Config** automatically appears on the desktop.

NOTE



If the installation failed, contact your network administrator: The settings of the firewall used may need to be adjusted.

9.3 Starting the webConfig tool

To start the **webConfig tool**, click the icon  with the name **Leuze Web Config** located on the desktop. Make certain that the BCL 308*i* is connected to the PC via the USB interface and that voltage is connected. Alternatively, the **webConfig tool** can also be directly started via the Ethernet connection.

NOTE



If you have already installed a USB driver for a BCL 5xx*i* on your computer, you can also start the webConfig tool of the BCL 308*i* by double-clicking on the BCL 5xx*i* icon.

Alternatively, you can start the webConfig tool by starting the browser installed on your PC and entering the following IP address: **192.168.61.100**

This is the default Leuze service address for communication with bar code readers of the BCL 300/ and BCL 500/ series.

In both cases, the following start page appears on your PC.




Figure 9.2: The start page of the webConfig tool

NOTE	
	The webConfig tool is completely contained in the firmware of the BCL 308/. Depending on firmware version, the start page may vary from that shown above.

The individual parameters are – where useful – graphically displayed in order to better illustrate the meaning of the what are often perceived as abstract parameters.

The result is an easy-to-use and practically-oriented user interface!

9.4 Short description of the webConfig tool

The webConfig tool has 5 main menus:

- Process
with read information of the host interface of the connected BCL 308/.
- Alignment
for manually starting read processes and for aligning the bar code reader. The results of the read processes are displayed immediately. As a result, this menu item can be used to determine the optimum installation location.
- Configuration
for adjusting decoding, for data formatting and output, switching inputs/outputs, communication parameters and interfaces, etc. ...
- Diagnostics
for event logging of warnings and errors
- Maintenance
for updating the firmware.

The user interface of the webConfig tool is largely self-explanatory.

9.4.1 Module overview in the Configuration menu

The adjustable parameters of the BCL 308*i* are clustered in modules in the Configuration menu.




Figure 9.3: Module overview in the webConfig tool

NOTE



The webConfig tool is completely contained in the firmware of the BCL 308*i*. Depending on firmware version, the module overview may vary from that shown above.

The individual modules and their relationships to one another are graphically displayed in the module overview. The display is context sensitive, i.e. click a module to directly access the corresponding submenu.

Overview of the configurable modules

- Device:
Configuration of the **switching inputs and outputs**
- Decoder:
Configuration of the decoder table, such as **code type, number of digits**, etc.
- Control:
Configuration of **activation and deactivation**, e.g. **auto-activation, AutoReflAct**, etc.
- Data:
Configuration of **code content**, such as **filtering, segmentation of bar code data**, etc.
- Output:
Configuration of **data output, header, trailer, reference code**, etc.
- Communication:
Configuration of the **host interface** and the **service interface**, e.g. **IP address, TCP/IP or UDP**, etc.
- Oscillating mirror:
Configuration of the **oscillating mirror settings**

NOTE



On the right side of the user interface of the webConfig tool, you will find a description of the individual modules and functions as a help text in the **Information** area.

10 Commissioning and configuration

⚠ ATTENTION LASER!	
	Observe the safety notices in Chapter 2!

This chapter describes basic configuration steps which you can carry out via the webConfig tool.

Via the webConfig tool

The most convenient way to configure the BCL 308*i* is via the webConfig tool. To use the webConfig tool, you need to establish a USB connection between the BCL 308*i* and a PC/laptop.

NOTE	
	Notes on the use of the webConfig tool can be found in Chapter 9 "Leuze webConfig tool" on page 78.

10.1 Measures to be performed prior to the initial commissioning

- ↪ Before commissioning, familiarize yourself with the operation and configuration of the BCL 308*i*.
- ↪ Before connecting the supply voltage, recheck all connections and ensure that they have been properly made.

The description of the electrical connections can be found in Chapter 7.

10.2 Starting the device

- ↪ Connect the +18 ... 30VDC supply voltage (typ. +24VDC); the BCL 308*i* starts up and the bar code reading window appears on the display.

NOTE	
	<p>The BCL 308<i>i</i> can decode the following code types in the standard setting:</p> <ul style="list-style-type: none"> • Code 128 Number of digits 4 ... 63 • 2/5 Interleaved Number of digits 10 • Code 39 Number of digits 4 ... 30 • EAN 8 / 13 Number of digits 8 and 13 • UPC Number of digits 8 • Codabar Number of digits 4 ... 63 • Code 93 Number of digits 4 ... 63 • Code GS1 Data Bar OMNIDIRECTIONAL • Code GS1 Data Bar LIMITED • Code GS1 Data Bar EXPANDED

Deviations from these settings must be set via the webConfig tool. See "Leuze webConfig tool" on page 78.

As a first step, you need to set the communication parameters of the BCL 308*i*.

10.3 Setting the communication parameters

With the communication parameters, you determine how data is exchanged between BCL 308*i* and host system, monitor PCs etc.

The communication parameters are **independent** of the topology in which the BCL 308*i* is operated (see "Ethernet topologies" on page 70).

10.3.1 Manual configuration of the IP address

If your system does not include a DHCP server or if the IP addresses of the devices are to be set permanently, proceed as follows:

- ↪ Have the network administrator specify the data for IP address, net mask and gateway address of the BCL 308*i*.
- ↪ Set these values on the BCL 308*i*.

In the webConfig tool

- ↪ In the main menu, select *Configuration*, submenu *Communication* -> *Ethernet interface*.

NOTE	
	<p>If the setting is performed via the webConfig tool, the BCL 308<i>i</i> must be restarted. The set IP address is only accepted and active after this restart.</p>

10.3.2 Automatically setting the IP address

If your system includes a DHCP server which is to be used to assign the IP addresses, proceed as follows:

- ↪ Activate the DHCP client mode in the BCL 308*i*.

Via webConfig:

Configuration > Communication > Ethernet interface

Activate the DHCP = ON setting there.

NOTE	
	<p>The BCL 308<i>i</i> responds to ping commands. A simple test to determine whether the address assignment was successful is to enter the previously configured IP address in a ping command (e.g. ping 192.168.60.101 in a command line window under Windows).</p>

10.3.3 Ethernet host communication

The Ethernet host communication enables the configuration of connections to an external host system. Both UDP as well as TCP/IP (in either client or server mode) can be used. The connection-free UDP protocol is used primarily to transfer process data to the host (monitor operation). The connection-oriented TCP/IP protocol can also be used to transfer commands from the host to the device. With this connection, the data is backed up by the TCP/IP protocol itself.

If you would like to use the TCP/IP protocol, you must also define whether the BCL 308/i is to operate as a TCP client or as a TCP server.

Both protocols can be activated simultaneously and used in parallel.

↪ Contact your network administrator to determine which communication protocol is used.

10.3.4 TCP/IP

↪ Activate the TCP/IP protocol

↪ Set the TCP/IP mode of the BCL 308/i

In **TCP client mode**, the BCL 308/i actively establishes the connection to the superior host system (PC / PLC as server). The BCL 308/i requires from the user the IP address of the server (host system) and the port number on which the server (host system) accepts a connection. In this case, the BCL 308/i determines when and with whom a connection is established!

↪ With a BCL 308/i as TCP client, also set the following values:

- IP address of the TCP server (normally the PLC/host computer)
- Port number of the TCP server
- Timeout for the wait time for an answer from the server
- Repetition time for renewed communication attempt following a timeout

In **TCP server mode**, the superior host system (PC / PLC) actively establishes the connection and the connected BCL 308/i waits for the connection to be setup. The TCP/IP stack requires information from the user regarding the local port of the BCL 308/i (port number) on which the connection requests of a client application (host system) are to be accepted. If there is a connection request and a connection is established by the superior host system (PC / PLC as client), the BCL 308/i (server mode) accepts the connection. Data can then be sent and received.

↪ With a BCL 308/i as TCP server, also set the following values:

- Port number for the communication of the BCL 308/i with the TCP client

The corresponding adjustment options can be found:

- Via webConfig:
Configuration -> Communication -> Host communication

10.3.5 UDP

The BCL 308/i requires from the user the IP address and the port number on which the communication partner receives data. In the same way, the host system (PC / PLC) now also requires the set IP address of the BCL 308/i and the selected port number. This assignment notifies both communication partners of which port the data is received on.

↪ Activate the UDP protocol

↪ Also set the following values:

- IP address of the communication partner
- Port number of the communication partner

The corresponding adjustment options can be found:

- Via webConfig:
Configuration -> Communication -> Host communication

10.4 Additional settings for the BCL 308*i*

After the basic configuration of the operating mode and the communication parameters, you need to carry out further settings via the webConfig tool:

- Decoding and processing the read data
- Control of the decoding
- Control of the switching outputs

10.4.1 Decoding and processing the read data

The BCL 308*i* offers the following options:

- Setting the number of labels to be decoded for each reading gate (0 ... 64). This is done via the Max. no. of labels parameter.
- Definition of up to 8 different code types. Labels that match one of the defined code types are decoded. Further parameters can be set for each code type:
 - The code type (symbology)
 - The Number of digits: either up to 5 different numbers of digits (e.g., 10, 12, 16, 20, 24), or a range (Interval mode) and up to three additional numbers of digits (e.g., 2 ... 10, 12, 16, 26)
 - The Reading reliability: the set value specifies how many times a label must be read and decoded with the same result before the result is accepted as valid.
 - Additional code type specific settings (in the webConfig tool only)
 - Check digit method used for decoding as well as the type of check digit transmission for the output of the read result. The two possibilities for the latter are Standard (corresponds to the standard for the selected code type/symbology) and not Standard.

↪ Define at least one code type with the desired settings.

- Via webConfig:
Configuration -> Decoder

Data processing via the webConfig tool

In the Data and Output submenus of the Configuration main menu, the webConfig tool provides extensive data processing options to adapt the functionality of the BCL 308*i* to the specific reading task:

- Data filtering and segmentation in the Data submenu:
 - Data filtering according to characteristics for handling identical bar code information
 - Data segmentation for differentiating between identifier and content of the read data
 - Data filtering according to content and/or identifier in order to suppress the output of bar codes with specific content/identifiers
 - Completeness inspection of the read data
- Sorting and formatting the output data in the Output submenu:
 - Configuration of up to 3 different sorting criteria. Sorting by physical data and content of the read bar codes.
 - Formatting of the data output for the HOST.
 - Formatting of the data output for the display.

10.4.2 Control of the decoding

In general, decoding is controlled via one or more of the configurable switching inputs/outputs. For this purpose, the respective connection to the SW IN/OUT and POWER interfaces must be configured as a switching input.

Via a switching input, you can:

- Start decoding
- Stop decoding
- Start decoding and then stop decoding after a configurable time period
- Read a reference code
- Start the automatic code type configuration (AutoConfig)

↪ Connect the required control devices (photoelectric sensor, proximity switch, etc.) as described in Chapter 7 to the BCL 308*i*.

↪ Configure the connected switching inputs according to your requirements. To do this, first set the *I/O mode* to *Input* and then configure the switching behavior:

- Via webConfig:
Configuration > Device > Switching inputs/outputs

NOTE



Alternatively, one can also activate decoding via the online command '+' and deactivate it via the online command '-'. Further information on the online commands can be found in Chapter 11.

Advanced decoder control via the webConfig tool

The webConfig tool provides advanced functions, in particular for deactivating decoding. These may be accessed via the *Control* submenu of the *Configuration* main menu. You can:

- Activate decoding automatically (delayed)
- Stop decoding after a maximum reading gate time
- Stop decoding via the completeness mode, if:
 - The maximum number of bar codes to be decoded has been decoded
 - A positive reference code comparison has taken place.

10.4.3 Control of the switching outputs

By using the switching inputs/outputs of the BCL 308*i*, external event-controlled functions can be implemented without assistance from the superior process control. For this purpose, the respective connection at the SW IN/OUT and POWER interfaces must be configured as a switching output.

A switching output can be activated:

- At the start/end of the reading gate
- Depending on the read result:
 - Reference code comparison positive/negative
 - Read result valid/invalid
- Depending on the state of the device:
 - Ready/not ready
 - Data transmission active/not active
 - Active/standby
 - Error/no error
- etc.

↳ As described in Chapter 7 of the manual, connect the required switching outputs.

↳ Configure the connected switching outputs according to your requirements. To do this, first set the *I/O mode* to *Output* and then configure the switching behavior:

- Via webConfig:
Configuration > Device > Switching inputs/outputs

10.5 Transmitting configuration data

Instead of going through the tedious task of configuring every parameter of the BCL 308*i* individually, you can also conveniently transfer configuration data.

Configuration data can be transferred between two bar code readers BCL 308*i* as follows

- Storage in a file and transfer using the webConfig tool

10.5.1 Via the webConfig tool

With the webConfig tool, you can store entire configurations of the BCL 308*i* on data carriers and transfer them from these to the BCL 308*i*.

This storage of configuration data is especially useful if you want to store basic configurations which will require only minor changes.

In the webConfig tool, you store the configuration data via the buttons in the upper part of the middle window of all submenus of the Configuration main menu.




Figure 10.1: Storing configuration data in the webConfig tool

10.5.2 Replacing a defective BCL 308*i*

The MS 308 connector hood, the ME 308... connection hood and the MK 308 terminal hood feature an integrated parameter memory in which the configuration data is saved as a backup. If a defective BCL 308*i* has to be replaced, proceed as follows:

1. Disconnect the defective BCL 308*i* from the voltage supply.
2. Dismount the defective BCL 308*i* and disconnect it from the hoods with integrated connectors/terminal hoods.
3. Connect the new BCL 308*i* to the connection hood and remount the unit.
4. Recommission the new BCL 308*i* (reconnect the voltage supply).

The configuration is now imported from the external parameter memory of the connection hood and the BCL 308*i* is immediately operational without any further configuration.

11 Online commands

11.1 Overview of commands and parameters

Online commands can be used to send commands directly to the device for control and configuration. For this purpose, the BCL 308*i* must be connected to a host or service computer via the interface. The commands described can be sent either via the host or the service interface.

Online commands

With the commands, you can:

- control/decode.
- read/write/copy parameters.
- carry out an automatic configuration.
- teach-in/set reference codes.
- call up error messages.
- call up statistical device information.
- carry out a software reset in order to reinitialize the device.

Syntax

Online commands consist of one or two ASCII characters followed by command parameters.

No separation characters may be entered between the command and the command parameter(s). Both small and capitalized letters can be used.

Example:

Command '**CA**': autoConfig function

Parameter '+': Activation

Transmitted is: '**CA+**'

Notation

Commands, command parameters and returned data are enclosed between single quotation marks ' ' in the text of this manual.

Most online commands are acknowledged by the BCL 308*i* and any requested data returned. For commands that are not acknowledged, command execution can be observed or monitored directly on the device.

11.1.1 General online commands

Software version number

Command	'v'
Description	Requests device version information
Parameter	No
Acknowledgment	'BCL 308i SM 100 V 1.3.8 2008-02-15' The first line contains the device type of the BCL 308 <i>i</i> , followed by the device version number and version date. (The data which is actually displayed may vary from the values given here.)

NOTE	
	This command returns the major release number of the software packet. This major release number also appears on the display during start-up. This command can be used to check whether the connected host or service computer is properly connected and configured. If you do not receive an acknowledgment, please check interface connections, protocol and service switches.

Software reset

Command	'H'
Description	Carries out a software reset. The device is restarted and reinitialized, leaving it in the same state as when the supply voltage is switched on.
Parameter	No
Acknowledgment	'S' (start signal)

Code recognition

Command	'CC'
Description	Detects an unknown bar code and outputs number of digits, code type, and code information to the interface, without storing the bar code in the parameter memory.
Parameter	No
Acknowledgment	<p>'xx yy zzzzzz'</p> <p>xx: Code type of the read code</p> <p>'01' 2/5 Interleaved</p> <p>'02' Code 39</p> <p>'03' Code 32</p> <p>'06' UPC (A, E)</p> <p>'07' EAN</p> <p>'08' Code 128, EAN 128</p> <p>'10' EAN Addendum</p> <p>'11' Codabar</p> <p>'12' Code 93</p> <p>'13' GS1 DataBar OMNIDIRECTIONAL</p> <p>'14' GS1 DataBar LIMITED</p> <p>'15' GS1 DataBar EXPANDED</p> <p>yy: Number of digits of the read code</p> <p>zzzzz: Contents of the decoded label. A – appears if the label was not correctly read.</p>

autoConfig

Command	'CA'
Description	Activates or deactivates the 'autoConfig' function. Certain label reading parameters are programmed automatically in the setup by the labels which the BCL 308 <i>i</i> reads while the 'autoConfig' function is active.
Parameter	'+' Activates 'autoConfig' '/' Rejects the last code read '-' Deactivates 'autoConfig' and stores the decoded data in the current parameter set
Acknowledgment	'CSx' x Status '0' Valid 'CA' command '1' Invalid command '2' autoConfig could not be activated '3' autoConfig could not be deactivated '4' Result could not be deleted
Description	'xx yy zzzzzz' xx Number of digits of the read code yy Code type of the read code '01' 2/5 Interleaved '02' Code 39 '03' Code 32 '06' UPC (A, E) '07' EAN '08' Code 128, EAN 128 '10' EAN Addendum '11' Codabar '12' Code 93 '13' GS1 DataBar OMNIDIRECTIONAL '14' GS1 DataBar LIMITED '15' GS1 DataBar EXPANDED zzzzzz: Contents of the decoded label. A – appears if the label was not correctly read.

Alignment mode

Command	'JP'
Description	<p>This command simplifies mounting and alignment of the BCL 308<i>i</i>. After activating the function with 'JP+', the BCL 308<i>i</i> continuously supplies status information to the serial interfaces.</p> <p>With this online command, the scanner is set to terminate the decoding after 100 successfully decoded labels and output the status information. Subsequently, the read process is reactivated automatically.</p> <p>In addition to the output of the status information, the laser beam is used to display the reading quality. Depending on how many read results could be extracted, the duration of the laser's "OFF" time increases.</p> <p>If the reading quality is high, the laser beam flashes in brief, regular intervals. The worse the decoder decodes, the longer the pauses become during which the laser is switched off. The flashing intervals become more and more irregular because the laser may, in total, be active for longer to extract more labels. The duration of the pauses has been stepped in such a way that they can be distinguished by the eye.</p>
Parameter	<p>'+' : Starts the alignment mode. '-' : Ends the alignment mode.</p>
Acknowledgment	<p>'yyy_zzzzzz'</p> <p>yyy: Reading quality in %. A high process availability is ensured at read qualities > 75 %.</p> <p>zzzzzz: Bar code information.</p>

Manual definition of the reference code

Command	'RS'
Description	This command can be used to define a new reference code in the BCL 308/ by means of direct input via the serial interface. The data is saved in the parameter set according to your input under reference code 1 through 2 and stored in the working buffer for direct further processing.
Parameter	<p>'RSyvxzzzzzzz' y, v, x and z are placeholders (variables) for the actual input.</p> <p>y Defined reference code no. '1' (Code 1) '2' (Code 2)</p> <p>v Storage location for reference code: '0' RAM+EEPROM, '3' RAM only</p> <p>xx Defined code type (see command 'CA')</p> <p>z Defined code information (1 ... 63 characters)</p>
Acknowledgment	<p>'RSx' x Status</p> <p>'0' Valid 'Rx' command '1' Invalid command '2' Insufficient memory for reference code '3' Reference code has not been saved '4' Reference code invalid</p>
Example	Entry = 'RS130678654331' (Code 1 (1), RAM only (3), UPC (06), code information)

Reference code teach-in

Command	'RT'
Description	This command enables a reference code to be defined quickly by reading an example label.
Parameter	<p>'RTy' y Function</p> <p>'1' Defines reference code 1 '2' Defines reference code 2 '+' Activates the definition of reference code 1 up to the value of Parameter no_of_labels '-' Ends the teach event</p>
Acknowledgment	<p>The BCL 308/ first responds with the command 'RS' and corresponding status (see command 'RS'). After a bar code has been read, it sends the result in the following format:</p> <p>'RCyvxzzzzz' y, v, x and z are placeholders (variables) for the actual input.</p> <p>y Defined reference code no. '1' (Code 1) '2' (Code 2)</p> <p>v Storage location for reference code '0' RAM+EEPROM, '3' RAM only</p> <p>xx Defined code type (see command 'CA')</p> <p>z Defined code information (1 ... 63 characters)</p>

NOTE	
	<p>With this function, only code types are recognized that are identified using the 'autoConfig' function or which were set in the set-up.</p> <p>↳ After each reading via an 'RTy' command, explicitly switch off the function again since failure to do so will interfere with other commands as well as prevent execution of a new 'RTx' command.</p>

Reading a reference code

Command	'RR'
Description	The command reads out the reference code defined in the BCL 308 <i>i</i> . If no parameters are specified, all defined codes are output.
Parameter	<Reference code number> '1' ... '2' value range of reference codes 1 to 2
Acknowledgment	<p>If no reference codes are defined, the BCL 308<i>i</i> responds with the 'RS' command and corresponding status (see command RS). For valid codes, the output corresponds to the following format:</p> <p>RCyvxzzzzz</p> <p>y, v, x and z are placeholders (variables) for the actual input.</p> <p>y Defined reference code no.</p> <p> '1' (Code 1)</p> <p> '2' (Code 2)</p> <p>v Storage location for reference code</p> <p> '0' RAM+EEPROM,</p> <p> '3' RAM only</p> <p>xx Defined code type (see command 'CA')</p> <p>z Defined code information (1 ... 63 characters)</p>

11.1.2 Online commands for system control

Activating sensor input

Command	'+'
Description	The command activates decoding. This command is used to activate the reading gate. It remains active until it is deactivated by one of the following criteria: <ul style="list-style-type: none"> • Deactivation by a manual command • Deactivation by a switching input • Deactivation upon reaching the specified read quality (equal scans) • Deactivation by timeout • Deactivation upon reaching a preset number of scans without information.
Parameter	No
Acknowledgment	None

Deactivating sensor input

Command	'_'
Description	The command activates decoding. This command can be used to deactivate the reading gate. Following deactivation, the read result is output. Because the reading gate was manually deactivated and, thus, no GoodRead criterion was met, a NoRead is output.
Parameter	No
Acknowledgment	None

11.1.3 Online commands for configuring the switching inputs/outputs

Activate switching output

Command	'OA'
Description	The switching outputs 1 and 2 can be activated with this command. The respective port must have been configured as a switching output. The logic state is output, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output).
Parameter	'OA<a> <a> Selected switching output [1, 2], unit (dimensionless)
Acknowledgment	None

Query the state of the switching outputs

Command	'OA'
Description	This command may be used to query the states of the switching inputs and outputs that are configured as a switching output and that have been set via commands. The logic state is output, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output).
Parameter	'OA?'
Acknowledgment	'OA S1=<a>;S2=<a>' <a> State of the switching outputs '0' Low '1' High 'I' Configuration as switching input 'P' Passive configuration

Set the state of the switching outputs

Command	'OA'
Description	This command is used to set the states of the switching inputs/outputs that are configured as a switching output. The logic state is specified, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output). The values of the switching inputs/outputs that are not configured as switching outputs are ignored. You may also use only a selection of the existing switching inputs/outputs as long as these are listed in ascending order.
Parameter	'OA [S1=<a>];S2=<a>' <a> State of the switching output '0' Low '1' High
Acknowledgment	'OA=<aa>' <aa> Status acknowledgment, unit (dimensionless) '00' Ok '01' Syntax error '02' Parameter error '03' Other error

Deactivate switching output

Command	'OD'
Description	The switching outputs 1 and 2 can be deactivated with this command. The respective port must have been configured as a switching output. The logic state is output, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output).
Parameter	'OD<a>' <a> Selected switching output [1, 2], unit (dimensionless)
Acknowledgment	None

Query the configuration of the switching inputs/outputs

Command	'OF'
Description	This command may be used to query the configuration of the switching inputs/outputs 1 and 2.
Parameter	'OF?'
Acknowledgment	'OF S1=<a>;S2=<a>' <a> Function of the switching input/ output, unit [dimensionless] 'I' Switching input 'O' Switching output 'P' Passive

Configure the switching inputs/ outputs

Command	'OF'
Description	This command may be used to configure the function of the switching inputs/outputs 1 and 2. You may also use only a selection of the existing switching inputs/outputs as long as these are listed in ascending order.
Parameter	'OF [S1=<a>];[;S2=<a>]' <a> Function of the switching input/ output, unit [dimensionless] 'I' Switching input 'O' Switching output 'P' Passive
Acknowledgment	'OF=<bb>' <bb> Status acknowledgment '00' Ok '01' Syntax error '02' Parameter error '03' Other error

11.1.4 Online commands for the parameter set operations

NOTE	
	You can obtain detailed information on the parameter set of the bar code reader from Leuze on request.

Copying parameter set

Command	'PC'
Description	This command can only be used to copy parameter sets in their entirety. This can be used to replicate the three parameter sets default , permanent and operating parameters on the basis of one another. In addition, this command can also be used to restore the factory settings.
Parameter	<p>'PC<Source type><Target type>'</p> <p><Source type> Parameter data set that is to be copied, unit [dimensionless]</p> <p>'0' Parameter data set in permanent memory</p> <p>'2' Default or factory parameter set</p> <p>'3' Operating parameter data set in volatile memory</p> <p><Target type> Parameter set into which the data is to be copied, unit [dimensionless]</p> <p>'0' Parameter data set in permanent memory</p> <p>'3' Operating parameter data set in volatile memory</p> <p>Permissible combinations here include:</p> <p>'03' Copying the data set from the permanent memory to the operating parameter data set</p> <p>'30' Copying the operating parameter data set to the permanent parameter set memory</p> <p>'20' Copying the default parameters to the permanent memory and to the main memory</p>
Acknowledgment	<p>'PS=<aa>'</p> <p><aa> Status acknowledgment, unit [dimensionless]</p> <p>'00' Ok</p> <p>'01' Syntax error</p> <p>'02' Impermissible command length</p> <p>'03' Reserved</p> <p>'04' Reserved</p> <p>'05' Reserved</p> <p>'06' Impermissible combination, source type - target type</p>

Requesting parameter data set from BCL 308/

Command	'PR'
Description	The parameters of the BCL 308/ are grouped together in a parameter set and permanently stored in memory. There is one parameter set in permanent memory and one operating parameter set in volatile memory; in addition, there is a default parameter set (factory parameter set) for initialization. This command can be used to edit the first two parameter sets (in permanent and volatile memory). A check sum can be used for reliable parameter transfer.
Parameter	'PR<BCC type><PS type><Address><Data length>[<BCC>]' <BCC type> Check-digit function during transmission, unit [dimensionless] '0' Not used '3' BCC mode 3 <PS type> Memory from which the values are to be read, unit [dimensionless] '0' Parameter values stored in the flash memory '1' Reserved '2' Default values '3' Operating values in RAM <Address> Relative address of the data within the data set 'aaaa' Four-digit, unit [dimensionless] <Data length> Length of the parameter data to be transferred 'bbbb' Four-digit, unit [length in bytes] <BCC> Check sum calculated as specified under BCC type
Acknowledgment positive	PT<BCC type><PS type><Status><Start> <Address parameter value><Address+1 parameter value>... [<Address><Address parameter value>][<BCC>] <BCC type> Check-digit function during transmission, unit [dimensionless] '0' Not used '3' BCC mode 3 <PS type> Memory from which the values are to be read, unit [dimensionless] '0' Parameter values stored in the flash memory '2' Default values '3' Operating values in RAM <Status> Mode of parameter processing, unit [dimensionless] '0' No further parameters '1' Additional parameters follow <Start> Relative address of the data within the data set, 'aaaa' Four-digit, unit [dimensionless] <P.value A.> Parameter value of the parameter stored at this address; the parameter set data 'bb' is converted from HEX format to a 2-byte ASCII-format for transfer. <BCC> Check sum calculated as specified under BCC type,
Acknowledgment negative	'PS=<aa>' Parameter reply: <aa> Status acknowledgment, unit [dimensionless] '01' Syntax error '02' Impermissible command length '03' Impermissible value for checksum type '04' Invalid check sum received '05' Impermissible number of data requested '06' Requested data does not (any longer) fit in the transmission buffer '07' Impermissible address value '08' Read access after end of data set '09' Impermissible QPF data set type

Determining parameter set difference to default parameters

Command	'PD'
Description	<p>This command outputs the difference between the default parameter set and the operating parameter set or the difference between the default parameter set and the permanent parameter set.</p> <p>Comment: The reply supplied by this command can e.g. be directly used for programming a device with factory settings, whereby this device receives the same configuration as the device on which the PD-sequence was executed.</p>
Parameter	<p>'PD<P.set1><P.set2>'</p> <p><P.set1> Parameter data set which is to be copied, unit [dimensionless] '0' Parameter data set in permanent memory '2' Default or factory parameter set</p> <p><P.set2> Parameter set to which the data is to be copied, unit [dimensionless] '0' Parameter data set in permanent memory '3' Operating parameter data set in volatile memory</p> <p>Permissible combinations here include: '20' Output of the parameter differences between the default and the permanently saved parameter set '23' Output of the parameter differences between the default parameter set and the operating parameter set saved in volatile memory '03' Output of the parameter differences between the permanent parameter set and the operating parameter set saved in volatile memory</p>
Acknowledgment positive	<p>PT<BCC><PS type><Status><Adr.><P.value adr.><P.valueAdr.+1>... [;<Adr.><P.value adr.>] <BCC> '0' No check digit '3' BCC mode 3 <PS type> '0' Values stored in flash memory '3' Operating values stored in RAM <Status> '0' No further parameters '1' Additional parameters follow <Adr.> Relative address of the data within the data set 'aaaa' Four-digit, unit [dimensionless] <P.value>Parameter value of the -bb- parameter stored at this address. The parameter set data is converted from HEX format to a 2-byte-ASCII format for transfer.</p>
Acknowledgment negative	<p>'PS=<aa>' <aa> Status acknowledgment, unit [dimensionless] '0' No difference '1' Syntax error '2' Impermissible command length '6' Impermissible combination, parameter set 1 and parameter set 2 '8' Invalid parameter set</p>

Writing parameter set

Command	'PT'
Description	The parameters of the BCL 308/ are grouped together in a parameter set and permanently stored in memory. There is one parameter set in permanent memory and one operating parameter set in volatile memory; in addition, there is a default parameter set (factory parameter set) for initialization. This command can be used to edit the first two parameter sets (in permanent and volatile memory). A check sum can be used for reliable parameter transfer.
Parameter	<p>PT<BCC type><PS type><Status><Adr.><P.value adr.> <P.value adr+1>...[;<Adr.><P.value adr.>][<BCC>]</p> <p><BCC type> Check-digit function during transfer, unit [dimensionless] '0' No check digit '3' BCC mode 3</p> <p><PS type> Memory from which the values are to be read, unit [dimensionless] '0' Parameter values stored in the flash memory '3' Operating values stored in RAM</p> <p><Status> Mode of parameter processing, without function here, unit [dimensionless] '0' No reset after parameter change, no further parameters '1' No reset after parameter change, additional parameters follow '2' With reset after parameter change, no further parameters '6' Set parameters to factory settings, no further parameters '7' Set parameters to factory settings, lock all code types; the code-type setting must follow in the command!</p> <p><Adr.> Relative address of the data within the data set, 'aaaa' Four-digit, unit [dimensionless]</p> <p><P.value> Parameter value of the -bb- parameter stored at this address. The parameter set data is converted from HEX format to a 2-byte-ASCII format for transfer.</p> <p><BCC> Check sum calculated as specified under BCC type</p>
Acknowledgment	<p>'PS=<aa>' Parameter reply:</p> <p><aa> Status acknowledgment, unit [dimensionless] '01' Syntax error '02' Impermissible command length '03' Impermissible value for checksum type '04' Invalid check sum received '05' Impermissible data length '06' Invalid data (parameter limits violated) '07' Invalid start address '08' Invalid parameter set '09' Invalid parameter set type</p>

12 Diagnostics and troubleshooting

12.1 General causes of errors

Error	Possible error cause	Measures
Status LED PWR		
Off	<ul style="list-style-type: none"> No supply voltage connected to the device Hardware error 	<input type="checkbox"/> Check supply voltage <input type="checkbox"/> Send device to customer service
Red, flashing	<ul style="list-style-type: none"> Warning 	<input type="checkbox"/> Query diagnostic data and carry out the resulting measures
Red, continuous light	<ul style="list-style-type: none"> Error: no function possible 	<input type="checkbox"/> Internal device error, send in device
Orange, continuous light	<ul style="list-style-type: none"> Device in service mode 	<input type="checkbox"/> Reset service mode with webConfig tool
Status LED NET		
Off	<ul style="list-style-type: none"> No supply voltage connected to the device Etherhost communication not yet activated. Hardware error 	<input type="checkbox"/> Check supply voltage <input type="checkbox"/> Activate Etherhost communication. <input type="checkbox"/> Send device to customer service
Red, flashing	<ul style="list-style-type: none"> Communication error 	<input type="checkbox"/> Check interface
Red, continuous light	<ul style="list-style-type: none"> No communication 	<input type="checkbox"/> Check interface
Orange, flashing	<ul style="list-style-type: none"> Timeout -> Error on interface 	<input type="checkbox"/> Check interface wiring

Table 12.1: General causes of errors

12.2 Interface errors

Error	Possible error cause	Measures
No communication via USB service interface	<ul style="list-style-type: none"> Incorrect interconnection cable Connected BCL 308/i is not recognized 	<input type="checkbox"/> Check interconnection cable <input type="checkbox"/> Install USB driver
Sporadic errors at the Ethernet/IP interface	<ul style="list-style-type: none"> Incorrect wiring Effects due to EMC Overall network expansion exceeded 	<input type="checkbox"/> Check wiring <ul style="list-style-type: none"> In particular, check wire shielding Check the cable used <input type="checkbox"/> Check shielding (shield covering in place up to the clamping point) <input type="checkbox"/> Check grounding concept and connection to functional earth (FE) <input type="checkbox"/> Avoid EMC coupling caused by power cables laid parallel to device lines. <input type="checkbox"/> Check max. network expansion as a function of the max. cable lengths

Table 12.2: Interface error

12.3 Service and support

Service hotline

You can find the contact information for the hotline in your country on our website www.leuze.com under **Contact & Support**.

Repair service and returns

Defective devices are repaired in our service centers competently and quickly. We offer you an extensive service packet to keep any system downtimes to a minimum. Our service center requires the following information:

- Your customer number
- Product description or part description
- Serial number and batch number
- Reason for requesting support together with a description

Please register the merchandise concerned. Simply register return of the merchandise on our website www.leuze.com under **Contact & Support > Repair Service & Returns**.

To ensure quick and easy processing of your request, we will send you a returns order with the returns address in digital form.

What to do should servicing be required?

NOTE	
	<p>Please use this chapter as a master copy should servicing be required.</p> <p>↳ Enter the contact information and fax this form together with your service order to the fax number given below.</p>

Customer data (please complete)

Device type:	
Serial number:	
Firmware:	
Display messages	
Status of LEDs:	
Error description	
Company:	
Contact person/department:	
Phone (direct dial):	
Fax:	
Street / no.:	
ZIP code / City:	
Country:	

Leuze Service fax number:

+49 7021 573 - 199

13.2 BCL 308/type overview

Network participants with 2x Ethernet interface:

Type designation	Description	Part no.
Single line scanner with frontal beam exit		
BCL 308/S N 102	With N optics	50116414
BCL 308/S M 102	With M optics	50116408
BCL 308/S F 102	With F optics	50116396
BCL 308/S L 102	With L optics	50116402
BCL 308/S N 102 D	With N optics and display	50116413
BCL 308/S M 102 D	With M optics and display	50116407
BCL 308/S F 102 D	With F optics and display	50114822
BCL 308/S L 102 D	With L optics and display	50116401
BCL 308/S N 102 D H	With N optics, display and heating	50116412
BCL 308/S M 102 D H	With M optics, display and heating	50116406
BCL 308/S F 102 D H	With F optics, display and heating	50116395
BCL 308/S L 102 D H	With L optics, display and heating	50116400
Raster scanner with frontal beam exit		
BCL 308/R1 N 102	With N optics	50116391
BCL 308/R1 M 102	With M optics	50116387
BCL 308/R1 F 102	With F optics	50116383
BCL 308/R1 N 102 D	With N optics and display	50116390
BCL 308/R1 M 102 D	With M optics and display	50116386
BCL 308/R1 F 102 D	With F optics and display	50116382
Single line scanner with deflecting mirror		
BCL 308/S N 100	With N optics	50116411
BCL 308/S M 100	With M optics	50116405
BCL 308/S F 100	With F optics	50116394
BCL 308/S L 100	With L optics	50116399
BCL 308/S N 100 D	With N optics and display	50116410
BCL 308/S M 100 D	With M optics and display	50116404
BCL 308/S F 100 D	With F optics and display	50116393
BCL 308/S L 100 D	With L optics and display	50116398
BCL 308/S N 100 D H	With N optics, display and heating	50116409
BCL 308/S M 100 D H	With M optics, display and heating	50116403
BCL 308/S F 100 D H	With F optics, display and heating	50116392
BCL 308/S L 100 D H	With L optics, display and heating	50116397
Raster scanner with deflecting mirror		
BCL 308/R1 N 100	With N optics	50116389
BCL 308/R1 M 100	With M optics	50116385
BCL 308/R1 F 100	With F optics	50116381
BCL 308/R1 J 100	With J optics	50123505
BCL 308/R1 N 100 D	With N optics and display	50116388
BCL 308/R1 M 100 D	With M optics and display	50116384
BCL 308/R1 F 100 D	With F optics and display	50116380

Table 13.2: BCL 308/type overview

Type designation	Description	Part no.
Oscillating-mirror scanner		
BCL 308/O N 100	With N optics	50116377
BCL 308/O M 100	With M optics	50116374
BCL 308/O F 100	With F optics	50116368
BCL 308/O L 100	With L optics	50116371
BCL 308/O N 100 D	With N optics and display	50116378
BCL 308/O M 100 D	With M optics and display	50116375
BCL 308/O F 100 D	With F optics and display	50116369
BCL 308/O L 100 D	With L optics and display	50116372
BCL 308/O N 100 D H	With N optics, display and heating	50116379
BCL 308/O M 100 D H	With M optics, display and heating	50116376
BCL 308/O F 100 D H	With F optics, display and heating	50116370
BCL 308/O L 100 D H	With L optics, display and heating	50116373

Table 13.2: BCL 308/i type overview

13.3 Accessories – Connection hoods

Type designation	Description	Part no.
MS 308	Connector hood for BCL 308/i	50114823
MK 308	Terminal hood for BCL 308/i	50116466
ME 308 103	Connection hood for BCL 308/i, 3 x M12	50131255
ME 308 104	Connection hood for BCL 308/i, 3 x M12, 1 x M8	50131255

Table 13.3: Connection hoods for the BCL 308/i

13.4 Accessories – Connectors

Type designation	Description	Part no.
KD 095-5A	M12 axial socket for voltage supply, shielded	50020501
D-ET1	RJ45 connector for user-configuration	50108991
S-M12A-ET	M12 connector, axial, D-coded, for user-configuration	50112155
KDS ET M12 / RJ 45 W - 4P	Converter from M12, D-coded, to RJ 45 socket	50109832

Table 13.4: Connectors for the BCL 308/i

13.5 Accessories – USB cable

Type designation	Description	Part no.
KB USBA-USBminiB	USB service cable, 2 Type A and Mini-B type connector, length 1 m	50117011

Table 13.5: Service cable for the BCL 308/i

13.6 Accessories – Mounting device

Type designation	Description	Part no.
BT 56	Mounting device for rod Ø 16 ... 20 mm	50027375
BT 56-1	Mounting device for rod Ø 12 ... 16 mm	50121435
BT 59	Mounting device for ITEM	50111224
BT 300 W	Mounting bracket	50121433
BT 300 - 1	Mounting bracket for rod	50121434

Table 13.6: Mounting devices for the BCL 308/i

13.7 Accessory - Reflector for AutoReflAct

Type designation	Description	Part no.
Reflective tape no. 4 / 100 x 100 mm	Reflective tape as reflector for AutoReflAct operation	50106119

Table 13.7: Reflector for autoReflAct operation

14 Maintenance

14.1 General maintenance information

Usually, the BCL 308*i* bar code reader does not require any maintenance by the operator.

Cleaning

Clean glass surface with a damp sponge soaked in commercial cleaning detergent. Then rub it with a soft, clean, dry cloth.

NOTE



Do not use aggressive cleaning agents such as thinner or acetone for cleaning the device. Use of improper cleaning agents can damage the optical window.

14.2 Repairs, servicing

Repairs to the device must only be carried out by the manufacturer.

- ↳ Contact your Leuze distributor or service organization should repairs be required. The addresses can be found on the inside of the cover and on the back.

NOTE



When sending devices to Leuze for repair, please provide an accurate description of the error.

14.3 Disassembling, packing, disposing

Repacking

For later reuse, the device is to be packed so that it is protected.

NOTE



Electrical scrap is a special waste product! Observe the locally applicable regulations regarding disposal of the product.

15 Appendix

15.1 ASCII character set

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
NUL	0	00	0	ZERO	Zero
SOH	1	01	1	START OF HEADING	Start of heading
STX	2	02	2	START OF TEXT	Start of text characters
ETX	3	03	3	END OF TEXT	Last character of text
EOT	4	04	4	END OF TRANSMISS.	End of transmission
ENQ	5	05	5	ENQUIRY	Request for data trans.
ACK	6	06	6	ACKNOWLEDGE	Positive acknowledgment
BEL	7	07	7	BELL	Bell signal
BS	8	08	10	BACKSPACE	Backspace
HT	9	09	11	HORIZ. TABULATOR	Horizontal tabulator
LF	10	0A	12	LINE FEED	Line feed
VT	11	0B	13	VERT. TABULATOR	Vertical tabulator
FF	12	0C	14	FORM FEED	Form feed
CR	13	0D	15	CARRIAGE RETURN	Carriage return
SO	14	0E	16	SHIFT OUT	Shift out
SI	15	0F	17	SHIFT IN	Shift in
DLE	16	10	20	DATA LINK ESCAPE	Data link escape
DC1	17	11	21	DEVICE CONTROL 1	Device control character 1
DC2	18	12	22	DEVICE CONTROL 2	Device control character 2
DC3	19	13	23	DEVICE CONTROL 3	Device control character 3
DC4	20	14	24	DEVICE CONTROL 4	Device control character 4
NAK	21	15	25	NEG. ACKNOWLEDGE	Negative acknowledge
SYN	22	16	26	SYNCHRONOUS IDLE	Synchronization
ETB	23	17	27	EOF TRANSM. BLOCK	End of data transmission block
CAN	24	18	30	CANCEL	Invalid
EM	25	19	31	END OF MEDIUM	End of medium
SUB	26	1A	32	SUBSTITUTE	Substitution
ESC	27	1B	33	ESCAPE	Escape
FS	28	1C	34	FILE SEPARATOR	File separator
GS	29	1D	35	GROUP SEPARATOR	Group separator
RS	30	1E	36	RECORD SEPARATOR	Record separator

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
US	31	1F	37	UNIT SEPARATOR	Unit separator
SP	32	20	40	SPACE	Space
!	33	21	41	EXCLAMATION POINT	Exclamation point
"	34	22	42	QUOTATION MARK	Quotation mark
#	35	23	43	NUMBER SIGN	Number sign
\$	36	24	44	DOLLAR SIGN	Dollar sign
%	37	25	45	PERCENT SIGN	Percent sign
&	38	26	46	AMPERSAND	Ampersand
'	39	27	47	APOSTROPHE	Apostrophe
(40	28	50	OPEN. PARENTHESIS	Open parenthesis
)	41	29	51	CLOS. PARENTHESIS	Closed parenthesis
*	42	2A	52	ASTERISK	Asterisk
+	43	2B	53	PLUS	Plus sign
,	44	2C	54	COMMA	Comma
-	45	2D	55	HYPHEN (MINUS)	Hyphen
.	46	2E	56	PERIOD (DECIMAL)	Period (decimal)
/	47	2F	57	SLANT	Slant
0	48	30	60	0	Number
1	49	31	61	1	Number
2	50	32	62	2	Number
3	51	33	63	3	Number
4	52	34	64	4	Number
5	53	35	65	5	Number
6	54	36	66	6	Number
7	55	37	67	7	Number
8	56	38	70	8	Number
9	57	39	71	9	Number
:	58	3A	72	COLON	Colon
;	59	3B	73	SEMICOLON	Semicolon
<	60	3C	74	LESS THAN	Less than
=	61	3D	75	EQUALS	Equals
>	62	3E	76	GREATER THAN	Greater than
?	63	3F	77	QUESTION MARK	Question mark
@	64	40	100	COMMERCIAL AT	Commercial AT

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
A	65	41	101	A	Capital letter
B	66	42	102	B	Capital letter
C	67	43	103	C	Capital letter
D	68	44	104	D	Capital letter
E	69	45	105	E	Capital letter
F	70	46	106	F	Capital letter
G	71	47	107	G	Capital letter
H	72	48	110	H	Capital letter
I	73	49	111	I	Capital letter
J	74	4A	112	J	Capital letter
K	75	4B	113	K	Capital letter
L	76	4C	114	L	Capital letter
M	77	4D	115	M	Capital letter
N	78	4E	116	N	Capital letter
O	79	4F	117	O	Capital letter
P	80	50	120	P	Capital letter
Q	81	51	121	Q	Capital letter
R	82	52	122	R	Capital letter
S	83	53	123	S	Capital letter
T	84	54	124	T	Capital letter
U	85	55	125	U	Capital letter
V	86	56	126	V	Capital letter
W	87	57	127	W	Capital letter
X	88	58	130	X	Capital letter
Y	89	59	131	Y	Capital letter
Z	90	5A	132	Z	Capital letter
[91	5B	133	OPENING BRACKET	Opening bracket
\	92	5C	134	REVERSE SLANT	Reverse slant
]	93	5D	135	CLOSING BRACKET	Closing bracket
^	94	5E	136	CIRCUMFLEX	Circumflex
_	95	5F	137	UNDERScore	Underscore
`	96	60	140	GRAVE ACCENT	Grave accent
a	97	61	141	a	Lower case letter
b	98	62	142	b	Lower case letter
c	99	63	143	c	Lower case letter
d	100	64	144	d	Lower case letter
e	101	65	145	e	Lower case letter
f	102	66	146	f	Lower case letter
g	103	67	147	g	Lower case letter
h	104	68	150	h	Lower case letter
i	105	69	151	i	Lower case letter
j	106	6A	152	j	Lower case letter
k	107	6B	153	k	Lower case letter
l	108	6C	154	l	Lower case letter
m	109	6D	155	m	Lower case letter
n	110	6E	156	n	Lower case letter
o	111	6F	157	o	Lower case letter

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
p	112	70	160	p	Lower case letter
q	113	71	161	q	Lower case letter
r	114	72	162	r	Lower case letter
s	115	73	163	s	Lower case letter
t	116	74	164	t	Lower case letter
u	117	75	165	u	Lower case letter
v	118	76	166	v	Lower case letter
w	119	77	167	w	Lower case letter
x	120	78	170	x	Lower case letter
y	121	79	171	y	Lower case letter
z	122	7A	172	z	Lower case letter
{	123	7B	173	OPENING BRACE	Opening brace
	124	7C	174	VERTICAL LINE	Vertical line
}	125	7D	175	CLOSING BRACE	Closing brace
~	126	7E	176	TILDE	Tilde
DEL	127	7F	177	DELETE (RUBOUT)	Delete

15.2 Bar code samples

15.2.1 Module 0.3




Figure 15.1: Bar code sample labels (module 0.3)

15.2.2 Module 0.5

Code type 01: Interleaved 2 of 5



Code type 02: Code 39



Code type 11: Codabar



Code 128



Code type 08: EAN 128



Code type 06: UPC-A



Code type 07: EAN 8



Code type 10: EAN 13 Add-on



Figure 15.2: Bar code sample labels (module 0.5)