

Translation of original operating instructions

BCL 500*i* and BCL 501*i*

Bar code readers



© 2024

Leuze electronic GmbH + Co. KG

In der Braike 1

D-73277 Owen / Germany

Phone: +49 7021 573-0

Fax: +49 7021 573-199

<http://www.leuze.com>

info@leuze.de

The main menus

BCL500i SF 102
Leuze electronic
GmbH & Co. KG
SW: V 1.8.0 HW:3
SN: 1009A009815 001



IO1 IO2 IO3
IO4 ATT ERR
12345678



Parameter
Parameter handling
Decoder table
Digital SWIO
Com



Language selection
o Deutsch
● English
o Español
o Français
o Italiano



Service
Diagnosis
Status messages



Actions
o Start decoding
o Start alignment
o Start auto setup
o Start teach-in

Device buttons:

- Navigate upward/sideways
- Navigate downward/sideways
- ESCAPE**
leave
- ENTER**
confirm

Input of values

12|
<-|0123456789 save
Default ----- Unit
126 | |

- + Delete character
- + Enter digit
- save + Save input

Device information - main menu

Information about

- Device type
- Software version
- Hardware version
- Serial number

Main menu Bar code reading window

Visualization of the read bar code information.

See "Indicators in the display" on page 17.

Parameter - main menu

Parameterization of the bar code reader.

See "Parameter menu" on page 47.

Language selection - main menu

Selection of the display language.

See "Language selection menu" on page 53.

Service - main menu

Scanner diagnostics and status messages.

See "Service menu" on page 53.

Main menu Actions

Various functions for scanner configuration and manual operation.

See "Actions menu" on page 53.

PWR PWR LED

Off	Device OFF
Flashes green	Device ok, initialization phase
Green, continuous light	Device ok
Orange, continuous light	Service mode
Flashes red	Device ok, warning set
Red, continuous light	Device error

NET NET LED

Off	No supply voltage
Flashes green	Initialization
Green, continuous light	Operation ok
Flashes orange	Timeout
Flashes red	Communication error
Red, continuous light	Network error

1	General information	10
1.1	Explanation of symbols	10
1.2	Declaration of Conformity	10
2	Safety	11
2.1	Intended use	11
2.2	Foreseeable misuse	11
2.3	Competent persons	11
2.4	Exemption of liability	12
2.5	Laser safety notices	12
3	Device description	14
3.1	Device overview	14
3.2	Performance characteristics	14
3.3	Device construction	16
3.4	Connection technology	17
3.5	Display elements	17
3.5.1	Structure of the control panel	17
3.5.2	Status indicators and operation	18
3.5.3	LED status indicators	18
3.6	Control buttons	20
3.7	External parameter memory	20
4	Functions	21
4.1	autoReflAct	21
4.2	Reference codes	22
4.3	autoConfig	22
4.4	Stand-alone connection	23
4.5	Networking - Leuze multiNet plus	23
4.6	Leuze multiScan	24
4.7	Heating	24
5	Reading techniques	25
5.1	Line scanner (single line)	25
5.2	Line scanner with oscillating mirror	26
5.3	Omnidirectional reading	27
6	Mounting	28
6.1	Device arrangement	28
6.1.1	Selecting a mounting location	28
6.1.2	Avoiding total reflection – Line scanner	28
6.1.3	Avoiding total reflection – oscillating-mirror scanner	29
6.1.4	Mounting location	30
6.1.5	Devices with integrated heating	30
6.1.6	Possible read angles between device and bar code	30
6.2	Installing the external parameter memory	31
7	Electrical connection	32
7.1	Safety notices for the electrical connection	32
7.2	Electrical connection of the device	33
7.2.1	PWR – Voltage supply and switching inputs/outputs 3 and 4	34
7.2.2	SERVICE – USB interface (type A)	36

7.2.3	SW IN/OUT – Switching input/switching output	37
7.2.4	HOST / BUS IN	39
7.2.5	BUS OUT	41
7.3	Cable lengths and shielding	42
7.4	Leuze multiNet plus	42
7.4.1	Wiring the multiNet plus	43
7.4.2	The BCL 500/as network master	43
7.4.3	The BCL 500/as network slave	44
7.4.4	The BCL 501/as network slave	44
8	Menu description	46
8.1	The main menus	46
8.2	Parameter menu	47
8.3	Language selection menu	53
8.4	Service menu	53
8.5	Actions menu	53
8.6	Operation	55
9	Starting up the device – Leuze webConfig tool	56
9.1	Connecting the SERVICE USB interface	56
9.2	Installing the required software	56
9.2.1	System requirements	56
9.2.2	Installing the USB driver	56
9.3	Starting the webConfig tool	57
9.4	Short description of the webConfig tool	58
9.4.1	Module overview in the Configuration menu	58
10	Starting up the device - Configuration	60
10.1	Measures to be performed prior to the initial commissioning	60
10.2	Starting the device	60
10.3	Operation of the device	60
10.3.1	Operation as stand-alone device	60
10.3.2	Selecting the operating mode	60
10.3.3	Operation as multiNet plus master	61
10.4	Operation of BCL 501/.	62
10.5	Further settings	63
10.5.1	Decoding and processing the read data	63
10.5.2	Control of the decoding	64
10.5.3	Control of the switching outputs	64
10.6	Transmitting configuration data	65
10.6.1	Via the webConfig tool	65
10.6.2	With the external parameter memory	65
11	Online commands	66
11.1	Overview of commands and parameters	66
11.1.1	General online commands	66
11.1.2	Online commands for system control	69
11.1.3	Online commands for configuring the switching inputs/outputs	70
11.1.4	Online commands for the parameter set operations	71
12	Care, maintenance and disposal	76
12.1	Cleaning	76
12.2	Repairs, servicing	76
12.3	Disposing	76

13	Diagnostics and troubleshooting	77
13.1	General causes of errors	77
13.2	Interface errors	77
14	Support	78
15	Technical data	79
15.1	General specifications of the bar code readers	79
15.1.1	Line scanner	79
15.1.2	Oscillating-mirror scanner	81
15.2	Heating models of the bar code readers	81
15.2.1	Line scanner with heater	82
15.2.2	Oscillating-mirror scanner with heating	83
15.3	Dimensioned drawings	84
15.3.1	Line scanner with / without heating	84
15.3.2	Oscillating-mirror scanner with/without heating	85
15.4	Dimensioned drawings: Accessories	86
15.5	Reading field curves / optical data	87
15.6	Reading field curves	88
15.6.1	High Density (N) - optics: BCL 500/\ BCL 501/SN 102	89
15.6.2	High Density (N) - optics: BCL 500/\ BCL 501/ON 100	90
15.6.3	Medium Density (M) - optics: BCL 500/\ BCL 501/SM 102	91
15.6.4	Medium Density (M) - optics: BCL 500/\ BCL 501/OM 100	92
15.6.5	Low Density (F) - optics: BCL 500/\ BCL 501/SF 102	93
15.6.6	Low Density (F) - optics: BCL 500/\ BCL 501/OF 100	94
15.6.7	Ultra Low Density (L) - optics: BCL 500/\ BCL 501/SL 102	95
15.6.8	Ultra Low Density (L) - optics: BCL 500/\ BCL 501/OL 100	96
15.7	Reading field curves for heating devices	97
15.7.1	High Density (N) - optics: BCL 500/\ BCL 501/SN 102 H	97
15.7.2	High Density (N) - optics: BCL 500/\ BCL 501/ON 100 H	98
15.7.3	Medium Density (M) - optics: BCL 500/\ BCL 501/SM 102 H	99
15.7.4	Medium Density (M) - optics: BCL 500/\ BCL 501/OM 100 H	100
15.7.5	Low Density (F) - optics: BCL 500/\ BCL 501/SF 102 H	101
15.7.6	Low Density (F) - optics: BCL 500/\ BCL 501/OF 100 H	102
15.7.7	Ultra Low Density (L) - optics: BCL 500/\ BCL 501/SL 102 H	103
15.7.8	Ultra Low Density (L) - optics: BCL 500/\ BCL 501/OL 100 H	104
16	Order guide and accessories	105
16.1	Part number code	105
16.2	Overview of BCL 500/types	105
16.2.1	BCL 500/	105
16.2.2	BCL 501/	106
16.3	Accessories	106
17	Appendix	108
17.1	ASCII character set	108
17.2	Bar code samples	110
17.2.1	Module 0.3	110
17.2.2	Module 0.5	112

Table 1.1:	Warning symbols and signal words	10
Table 1.2:	Other symbols	10
Figure 2.1:	Attaching stick-on labels with warning notices (top: with oscillating mirror, bottom: line scanners)	13
Figure 3.1:	Line scanner and oscillating-mirror scanner	14
Figure 3.2:	Device construction	16
Table 3.1:	BCL 500/BCL 501/interfaces	17
Figure 3.3:	Location of the electrical connections	17
Figure 3.4:	Structure of the control panel	17
Table 3.2:	Status displays of the switching inputs/outputs	18
Table 3.3:	Status display of the USB interface	18
Figure 4.1:	Possible bar code orientation	21
Figure 4.2:	Reflector arrangement for autoReflAct	22
Figure 4.3:	Stand-alone connection	23
Figure 4.4:	Networking possibilities using the multiNet plus	23
Figure 4.5:	Scanner arrangement with the multiScan function	24
Figure 5.1:	Deflection principle for the line scanner	25
Figure 5.2:	Deflection principle for the line scanner with oscillating mirror add-on	26
Figure 5.3:	Principle arrangement for omnidirectional reading	27
Figure 6.1:	Total reflection – line scanner	29
Figure 6.2:	Total reflection – oscillating-mirror scanner	29
Figure 6.3:	Reading angle for the line scanner	30
Figure 7.1:	Location of the electrical connections	32
Figure 7.2:	Connections of the device	33
Figure 7.3:	PWR, M12 connector (A-coded)	34
Table 7.1:	Pin assignments - PWR	34
Figure 7.4:	Switching input connection diagram SWIO_3 and SWIO_4	35
Figure 7.5:	Switching output connection diagram SWIO_3 / SWIO_4	35
Figure 7.6:	Service, USB, type A	36
Table 7.2:	Pin assignments of SERVICE – USB interface	36
Figure 7.7:	SW IN/OUT, M12 socket (A-coded)	37
Table 7.3:	Pin assignment SW IN/OUT	37
Figure 7.8:	Switching input connection diagram SWIO_1 and SWIO_2	37
Figure 7.9:	Switching output connection diagram SWIO_1 / SWIO_2	38
Figure 7.10:	HOST/BUS IN, M12 connector (B-coded)	39
Table 7.4:	Pin assignment HOST / BUS IN for BCL 500/	39
Figure 7.11:	Pin assignments - HOST / BUS IN as RS 232	39
Figure 7.12:	Pin assignments - HOST / BUS IN as RS 422	40
Figure 7.13:	HOST/BUS IN, M12 connector (B-coded)	40
Table 7.5:	Pin assignment HOST / BUS IN for BCL 501/	40
Figure 7.14:	M12 socket (B-coded)	41
Table 7.6:	Pin assignment BUS OUT	41
Table 7.7:	Cable lengths and shielding	42
Figure 7.15:	Leuze multiNet plus system topology	42
Figure 7.16:	Leuze multiNet plus system topology with BCL 500/as slave	44
Table 8.1:	Parameter handling submenu	47
Table 8.2:	Decoder table submenu	47
Table 8.3:	Digital SWIO submenu	49
Table 8.4:	Com submenu	52

Table 9.1:	webConfig system requirements	56
Figure 9.1:	The start page of the webConfig tool	57
Figure 9.2:	Module overview in the webConfig tool	58
Table 13.1:	General causes of errors	77
Table 13.2:	Interface error	77
Table 15.1:	Technical data of the BCL 500/and BCL 501/line scanners without heating	79
Table 15.2:	Technical data of the BCL 500/and BCL 501/oscillating-mirror scanners with heating	81
Table 15.3:	Technical data of the BCL 500/and BCL 501/line scanners with heating	82
Table 15.4:	Technical data of the BCL 501/and BCL 500/oscillating-mirror scanners with heating	83
Figure 15.1:	Dimensioned drawing - line scanner	84
Figure 15.2:	Dimensioned drawing of oscillating-mirror scanner	85
Figure 15.3:	BT 56 mounting device	86
Figure 15.4:	BT 59 mounting device	86
Figure 15.5:	External parameter memory	87
Figure 15.6:	The most important characteristics of a bar code	87
Figure 15.7:	Zero position of the reading distance	88
Table 15.5:	Reading conditions	88
Figure 15.8:	"High Density" reading field curve for line scanner	89
Figure 15.9:	"High Density" reading field curve for oscillating-mirror scanners	90
Figure 15.10:	Lateral "High Density" reading field curve for oscillating-mirror scanners	90
Figure 15.11:	"Medium Density" reading field curve for line scanner	91
Figure 15.12:	"Medium Density" reading field curve for oscillating-mirror scanners	92
Figure 15.13:	Lateral "Medium Density" reading field curve for oscillating-mirror scanners	92
Figure 15.14:	"Low Density" reading field curve for line scanner	93
Figure 15.15:	"Low Density" reading field curve for oscillating-mirror scanners	94
Figure 15.16:	Lateral "Low Density" reading field curve for oscillating-mirror scanners	94
Figure 15.17:	"Ultra Low Density" reading field curve for line scanner	95
Figure 15.18:	"Ultra Low Density" reading field curve for oscillating-mirror scanners	96
Figure 15.19:	Lateral "Ultra Low Density" reading field curve for oscillating-mirror scanners	96
Figure 15.20:	"High Density" reading field curve for line scanner with heating	97
Figure 15.21:	"High Density" reading field curve for oscillating-mirror scanners with heating	98
Figure 15.22:	Lateral "High Density" reading field curve for oscillating-mirror scanners with heating	98
Figure 15.23:	"Medium Density" reading field curve for line scanner with heating	99
Figure 15.24:	"Medium Density" reading field curve for oscillating-mirror scanners with heating	100
Figure 15.25:	Lateral "Medium Density" reading field curve for oscillating-mirror scanners with heating	100
Figure 15.26:	"Low Density" reading field curve for line scanner with heating	101
Figure 15.27:	"Low Density" reading field curve for oscillating-mirror scanners with heating	102
Figure 15.28:	Lateral "Low Density" reading field curve for oscillating-mirror scanners with heating	102
Figure 15.29:	"Ultra Low Density" reading field curve for line scanner with heating	103
Figure 15.30:	"Ultra Low Density" reading field curve for oscillating-mirror scanners with heating ..	104
Figure 15.31:	Lateral "Ultra Low Density" reading field curve for oscillating-mirror scanners with heating	104
Table 16.1:	Part number code	105
Table 16.2:	Overview of BCL 500/types	105

Table 16.3:	Overview of BCL 501/types	106
Table 16.4:	Accessories – Connectors	106
Table 16.5:	Accessories – Terminating resistor for BCL 500// BCL 501/.....	106
Table 16.6:	Accessories – Cables	106
Table 16.7:	Accessories – External parameter memory	107
Table 16.8:	Mounting device accessories	107
Figure 17.1:	Code type 01: Interleaved 2 of 5	110
Figure 17.2:	Code type 02: Code 39	110
Figure 17.3:	Code type 06: UPC-A	110
Figure 17.4:	Code type 07: EAN 8.....	111
Figure 17.5:	Code type 08: EAN 128.....	111
Figure 17.6:	Code type 10: EAN 13 Add-on	111
Figure 17.7:	Code type 11: Codabar	111
Figure 17.8:	Code 128.....	111
Figure 17.9:	Code type 01: Interleaved 2 of 5	112
Figure 17.10:	Code type 02: Code 39	112
Figure 17.11:	Code type 06: UPC-A	112
Figure 17.12:	Code type 07: EAN 8.....	112
Figure 17.13:	Code type 08: EAN 128.....	112
Figure 17.14:	Code type 10: EAN 13 Add-on	112
Figure 17.15:	Code type 11: Codabar	113
Figure 17.16:	Code 128.....	113

1 General information

1.1 Explanation of symbols

Table 1.1: Warning symbols and signal words







 CAUTION!	
	This symbol precedes text messages which must strictly be observed. Failure to observe the provided instructions could lead to personal injury or damage to equipment.
 ATTENTION, LASER RADIATION – CLASS 1 LASER PRODUCT	
	This symbol warns of possible danger caused by hazardous laser radiation.
NOTE	
	This symbol indicates text passages containing important information.

Table 1.2: Other symbols


	Symbol for action steps Text passages with this symbol instruct you to perform actions.
---	---

1.2 Declaration of Conformity

The bar code readers of the BCL 500/series have been developed and manufactured in accordance with the applicable European standards and directives.

The BCL 500/series is "UL LISTED" according to American and Canadian safety standards and fulfills the requirements of Underwriter Laboratories Inc. (UL).



NOTE	
	The Declaration of Conformity for these devices can be requested from the manufacturer.

The manufacturer of the product, Leuze electronic GmbH & Co KG in D-73277 Owen, possesses a certified quality assurance system in accordance with ISO 9001.

2 Safety

The bar code readers of the BCL 500/ series were developed, manufactured and tested in accordance with the applicable safety standards. They correspond to the state of the art.


2.1 Intended use

The device is designed as a stationary high-speed scanner with integrated decoder for all common bar codes for automatic object detection.

Areas of application

The device is specially designed for the following areas of application:

- Object identification on fast-moving conveyor lines
- Omnidirectional reading


⚠ CAUTION!	
	<p>Comply with conditions and regulations!</p> <p>Observe the locally applicable legal regulations and the rules of the employer's liability insurance association.</p>

2.2 Foreseeable misuse

Any use other than that defined under "Intended use" or which goes beyond that use is considered improper use.

In particular, use of the device is not permitted in the following cases:

- in rooms with explosive atmospheres
- in circuits which are relevant to safety
- for medical purposes

⚠ CAUTION!	
	<p>Do not modify or otherwise interfere with the device!</p> <p>Do not carry out modifications or otherwise interfere with the device.</p> <p>The device must not be tampered with and must not be changed in any way.</p> <p>The device must not be opened. There are no user-serviceable parts inside.</p> <p>Repairs must only be performed by Leuze electronic GmbH + Co. KG.</p>

2.3 Competent persons

Connection, mounting, commissioning and adjustment of the device must only be carried out by competent persons.

Prerequisites for competent persons:

- They have a suitable technical education.
- They are familiar with the rules and regulations for occupational safety and safety at work.
- They are familiar with the technical description of the device.
- They have been instructed by the responsible person on the mounting and operation of the device.

Certified electricians

Electrical work must be carried out by a certified electrician.

Due to their technical training, knowledge and experience as well as their familiarity with relevant standards and regulations, certified electricians are able to perform work on electrical systems and independently detect possible dangers.


In Germany, certified electricians must fulfill the requirements of accident-prevention regulations DGUV V3 (e.g. electrician foreman). In other countries, there are respective regulations that must be observed.


2.4 Exemption of liability

Leuze electronic GmbH + Co. KG is not liable in the following cases:

- The device is not being used properly.
- Reasonably foreseeable misuse is not taken into account.
- Mounting and electrical connection are not properly performed.
- Changes (e.g., constructional) are made to the device.

2.5 Laser safety notices

⚠ ATTENTION, LASER RADIATION – CLASS 1 LASER PRODUCT	
	<p>The device satisfies the requirements of IEC 60825-1:2014 / EN 60825-1:2014+A11:2021 safety regulations for a product of laser class 1 and complies with 21 CFR 1040.10 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.</p> <p>↳ Observe the applicable statutory and local laser protection regulations.</p> <p>↳ The device must not be tampered with and must not be changed in any way.</p> <p>There are no user-serviceable parts inside the device.</p> <p>CAUTION! Opening the device may result in hazardous radiation exposure!</p> <p>Repairs must only be performed by Leuze electronic GmbH + Co. KG.</p>



- A Laser aperture
- B Laser warning sign

Figure 2.1: Attaching stick-on labels with warning notices
(top: with oscillating mirror, bottom: line scanners)

3 Device description

3.1 Device overview

Bar code readers of the BCL 500*/*series are high-speed scanners with integrated decoder for all commonly used bar codes, e.g. 2/5 Interleaved, Code 39, Code 128, EAN 8/13 etc., as well as codes from the GS1 DataBar family.

Bar code readers of the BCL 500*/*series are available in various optics models as well as line scanners, line scanners with oscillating mirrors and also optionally as heated models.



Figure 3.1: Line scanner and oscillating-mirror scanner

The extensive options for device configuration via display or software enable adaptation to a multitude of reading tasks. Due to the large reading distance combined with the great depth of field and a very compact construction, the device is ideally suited for package and pallet transportation systems. In general, the bar code readers of the BCL 500*/*series are designed for the conveyor and storage technology market.


The interfaces (**RS 232**, **RS 485** and **RS 422**) integrated in the various device models and the fieldbus systems (**PROFIBUS DP**, **PROFINET-IO**, **Ethernet** and **Ethernet IP**) of the BCL 500*/*series bar code readers offer optimum connection to the superior host system.

3.2 Performance characteristics

- Integrated fieldbus connectivity = *i*-> Plug-and-Play fieldbus coupling and easy networking
- Numerous interface variants facilitate connection to the superior systems
 - RS 232, RS 422 as well as with integrated multiNet plus master
 - RS 485 and multiNet plus slave
- Alternatively, various fieldbus systems, such as
 - PROFIBUS DP
 - PROFINET-IO
 - Ethernet TCP/IP, UDP
 - Ethernet/IP
- Integrated code reconstruction technology (**CRT**) enables the identification of soiled or damaged bar codes
- Maximum depth of field and reading distances from 200 mm to 2400 mm
- Large optical opening angle and, thus, large reading field width
- High scanning rate of 800 / 1200 scans/s for fast reading tasks
- Intuitive, backlit, multi-language display with user-friendly menu navigation
- Integrated **USB 1.1** service interface
- Adjustment of all device parameters with a web browser
- Connection options for an external parameter memory
- Easy alignment and diagnostics functions

- M 12 connections with Ultra-Lock [™] technology
- Four freely programmable switching inputs/outputs for the activation or signaling of states
- Automatic monitoring of the read quality with **autoControl**
- Automatic recognition and setting of the bar code type using **autoConfig**
- Reference code comparison
- Optional heating models to -35 °C
- Heavy-duty housing of degree of protection IP 65

3.3 Device construction



- 1 Reading window
- 2 Control panel with display, LEDs and buttons
- 3 M12 connection technology
- 4 USB interface
- 5 Dovetail mounting
- 6 M4 mounting thread

Figure 3.2: Device construction

3.4 Connection technology

The bar code readers are connected using variously coded M12 connectors. This ensures unique connection assignments.

The additional USB interface is used for configuring the device.

The two product series BCL 500/ and BCL 501/ differ in their interfaces and in their function as multiNet plus master or slave.

Table 3.1: BCL 500/ BCL 501/ interfaces

	HOST / BUS IN	BUS OUT
BCL 500/ (Stand alone or multiNet plus Master)	RS 232 / RS 422	RS 485
BCL 501/ (multiNet plus slave)	RS 485	RS 485

For the locations of the individual device connections, please refer to the device detail shown below.




Figure 3.3: Location of the electrical connections

3.5 Display elements

3.5.1 Structure of the control panel




Figure 3.4: Structure of the control panel

3.5.2 Status indicators and operation

Indicators in the display

Table 3.2: Status displays of the switching inputs/outputs

IO1	Switching input or switching output 1 active (function dependent on set parameterization). Default: Switching input with the "Reading gate activation" function
IO2	Switching input or switching output 2 active (function dependent on set parameterization). Default: Input with the "Teach-in" function
IO3	Switching input or switching output 3 active (function dependent on set parameterization). Default: Switching input with the "Reading gate activation" function
IO4	Switching input or switching output 4 active (function dependent on set parameterization). Default: Switching output with the "No read" function
ATT	Warning (Attention)
ERR	Internal device error (Error) -> The device must be sent in for inspection

Bar graph

The read quality is shown on a scale of 0 - 100 %. The quality is evaluated based on the "Equal Scans" of the read result configured in the bar code reader.

Table 3.3: Status display of the USB interface

USB	The device is connected to a PC via the USB interface.
MS	An external parameter memory is properly connected to the USB interface of the device.

Read result




The read bar code information is displayed.










Device address

Displays the set multiNet plus network address (default = 1).





3.5.3 LED status indicators

PWR LED

PWR 	Off	Device OFF <ul style="list-style-type: none"> • No supply voltage
PWR 	Flashes green	Device ok, initialization phase <ul style="list-style-type: none"> • No bar code reading possible • Voltage connected • Self test running • Initialization running
PWR 	Green, continuous light	Device ok <ul style="list-style-type: none"> • Bar code reading possible • Self test successfully finished • Device monitoring active

PWR 	Orange, continuous light	Service mode <ul style="list-style-type: none"> • Bar code reading possible • Configuration via the USB service interface • Configuration via the display • No data on the host interface
PWR 	Flashes red	Device ok, warning set <ul style="list-style-type: none"> • Bar code reading possible • Temporary operating fault
PWR 	Red, continuous light	Device error / parameter enable <ul style="list-style-type: none"> • No bar code reading possible
NET LED		
NET 	Off	No supply voltage <ul style="list-style-type: none"> • No communication possible
NET 	Flashes green	Initialization <ul style="list-style-type: none"> • of interfaces (BCL 500/i stand-alone) • of the network (BCL 500/i master) • of the network, slaves waiting for initialization by the master (BCL 500/i and BCL 501/i slave)
NET 	Green, continuous light	Operation ok <ul style="list-style-type: none"> • Network mode ok • Interfaces (BCL 500/i stand-alone) • Network (BCL 500/i master) • Network, slaves were initialized by the master (BCL 500/i and BCL 501/i slave)
NET 	Flashes orange	Timeout
NET 	Flashes red	Communication error <ul style="list-style-type: none"> • Parameterization or configuration failed ("parameter failure") • IO error • No data exchange • An already initialized slave has been lost in the network (BCL 500/i master) • Network error after initialization by the master (BCL 500/i and BCL 501/i slave)
NET 	Red, continuous light	Network error <ul style="list-style-type: none"> • No communication (protocol) to IO controller established (no data exchange) • Slave cannot send any more data to the master (BCL 500/i and BCL 501/i slave).


3.6 Control buttons

	Up	Navigate upward/sideways.
	Down	Navigate downward/sideways.
	ESC	Exit menu item.
	ENTER	Confirm/enter value, change menu levels.

Navigating within the menus

The menus within a level are selected with the up/down buttons  .


The selected menu item is activated with the enter button .





Press the ESC button  to move up one menu level.

When one of the buttons is actuated, the display illumination is activated for 10 min.

Setting values

If input of a value is possible, the display looks like this:






Use the   and  buttons to set the desired value. An accidental, incorrect entry can be corrected by selecting <-| and then pressing .


Then use the   buttons to select **save** and save the set value by pressing .

Selecting options

If options can be selected, the display looks like this:



Select the desired option with the   buttons.

Activate the option by pressing .

3.7 External parameter memory

The optionally available external parameter memory – based on a USB memory stick (compatible with version 1.1) – is housed in an external hood with integrated connectors which cover the USB service interface when installed (IP 65).

The external parameter memory makes it easy and reduces the time needed to replace a device on site by providing a copy of the current parameter set of the device. This eliminates the need to configure the exchanged device manually.

The delivery contents of the external parameter memory include the hood with integrated connectors with unscrewable cover and the USB memory stick.

For transferring the configuration with the aid of the external parameter memory see chapter 6.2.

NOTE



To mount, the cover of the service interface must be unscrewed. Then take the USB memory stick and plug it into the USB connection on the device. Then, take the connector hood of the USB memory stick and screw this over the plugged-in USB memory stick onto the service interface to close the system and ensure degree of protection IP 65.

4 Functions

General information

The integrated fieldbus connectivity = / contained in the bar code readers of the BCL 500 / series facilitates the use of identification systems which function without connection unit or gateways. The integrated fieldbus interface considerably simplifies handling. The Plug-and-Play concept enables easy networking and very simple commissioning: Directly connect the respective fieldbus and all parameterization is performed with no additional software.

For decoding bar codes, the bar code readers of the BCL 500 / series make available the proven **CRT decoder** with code reconstruction technology:

The proven code reconstruction technology (**CRT**) enables bar code readers of the BCL 500 / series to read bar codes with a small bar height, as well as bar codes with a damaged or soiled print image.

With the aid of the **CRT decoder**, bar codes can also be read without problem in other demanding situations, such as with a large tilt angle (azimuth angle or even twist angle).




Figure 4.1: Possible bar code orientation

The device can be operated and configured using the integrated webConfig tool via the USB service interface; alternatively, the bar code readers can be adjusted using configuration commands via the host/ service interface.

The device needs a suitable activation to start a read process as soon as an object is in the reading field. This opens a time window (reading gate) in the device for the read process during which the bar code reader has time to detect and decode a bar code.

In the basic setting, triggering takes place through an external reading cycle signal. Alternative activation options include online commands via the host interface and the **autoRefIAct** function.

Through the read operation, the device collects additional useful pieces of data for diagnostics which can also be transmitted to the host. The quality of the read operation can be inspected using the **alignment mode** which is integrated in the webConfig tool.

A multi-language display with buttons is used to operate the device as well as for visualization purposes. Two LEDs provide additional optical information on the current operating state of the device.

The four freely configurable switching inputs/outputs SWIO 1 ... SWIO 4 can be assigned various functions and control e.g. activation of the device or external devices, such as a PLC.

System, warning and error messages provide assistance in setup/troubleshooting during commissioning and read operation.

4.1 autoRefIAct

autoRefIAct stands for **automatic Reflector Activation** and permits an activation without additional sensors. This is achieved by directing the scanner with reduced scanning beam towards a reflector mounted behind the conveyor path. As long as the scanner is targeted at the reflector, the reading gate remains closed. If, however, the reflector is blocked by an object such as a container with a bar code label, the scanner acti-

vates the read procedure, and the label on the container is read. When the path from the scanner to the reflector has cleared, the read procedure has completed and the scanning beam is reduced and again directed onto the reflector. The reading gate is closed.

NOTE



You will find a matching reflector in Accessories, and more are available on request.



Figure 4.2: Reflector arrangement for autoRefIAct

The **autoRefIAct** function uses the scanning beam to simulate a photoelectric sensor and thus permits an activation without additional sensors.

4.2 Reference codes

The device offers the possibility of storing one or two reference codes.

It is possible to store the reference codes by means of teach-in (display command), via the webConfig tool or via online commands.

The device can compare read bar codes with one and/or both reference codes and execute user-configurable functions depending on the comparison result.

4.3 autoConfig

With the autoConfig function, the device offers an extremely simple and convenient configuration option to users who only want to read one code type (symbology) with one number of digits at a time.


After starting the autoConfig function via the display, switching input or from a superior control, it is sufficient to position a bar code label with the desired code type and number of digits in the reading field of the device.

Afterward, bar codes with the same code type and number of digits are recognized and decoded.

Detailed information on this topic can be found in Chapter 10 "Starting up the device - Configuration" on page 62.

4.4 Stand-alone connection

The bar code readers of the BCL 500/series can be operated as single "stand-alone" devices. The device features multiple M12 connectors / sockets for the electrical connection of the supply voltage, the interface and the switching inputs and outputs.



- 1 Switching inputs/outputs
- 2 Supply voltage
- 3 PC / PLC host interface

Figure 4.3: Stand-alone connection

4.5 Networking - Leuze multiNet plus

In the Leuze **multiNet plus** network, up to 32 bar code readers can be networked together. The respective network devices transmit the read data when requested to by the BCL 500/ (or MA 31) network master. For this purpose, each device is assigned its own station address, which is set using the display of the corresponding device.

The master then transmits the data of all network devices via its host interface to a superior PLC control system or a computer, i.e. it "collects" the scanner data in the network and transmits it to an interface on the host computer. This reduces interface costs (CPs) and time spent programming the software.




Figure 4.4: Networking possibilities using the multiNet plus

Two-wire RS 485

The **Leuze multiNet plus** is optimized for fast transmission of scanner data to a superior host computer. The multiNet plus consists physically of a two-wire RS 485 interface through which the **Leuze multiNet plus software protocol** is controlled. This makes wiring the network easy and inexpensive as slaves are looped through to one another in parallel.

In principle, networking occurs via a parallel connection of the individual RS 485 interfaces of the respective bar code scanners. Shielded, twisted pair conductors should be used for the **Leuze multiNet plus**. This allows a total network length of up to 1200m.

4.6 Leuze multiScan

The **multiScan** operating mode is based on **Leuze multiNet plus** and links individual bar code readings from multiple bar code scanners into a single decoding result. This is used, for example, on a packet conveyor system on which the label can be affixed on either the right or left side, thereby requiring two read stations. To prevent the host from having to always process two readings for a single packet, i.e. a decoding result and a No Read, a multiScan arrangement is used which transmits only one reading from the two read stations to the host; this single reading is transmitted by the multiScan master.

NOTE



Thus, from the perspective of the host, the scanner network appears to be just a single bar code reader!

For this purpose one multiScan master and one or more multiScan slaves are connected together via the RS 485 interface.




Figure 4.5: Scanner arrangement with the multiScan function

NOTE



The multiScan function on the RS 485 interface is possible for minimum of 2 and a maximum of 32 devices!

The protocol set on the RS 485 interface is the multiNet protocol. As a result, during multiScan operation on the RS 485 interface, the multiNet master also functions as the multiScan master and the multiNet slaves function as multiScan slaves (thus, all multiNet slave are included in multiScan operation).

4.7 Heating

For low-temperature applications to min. -35°C (e.g. in cold storage), the bar code readers of the BCL 500/ series can optionally be permanently fitted with a built-in heating and these bar code readers purchased as separate device models.

5 Reading techniques

5.1 Line scanner (single line)

A line (scan line) scans the label. Due to the opt. opening angle, the reading field width is dependent on the read distance. Through the movement of the object, the entire bar code is automatically transported through the scan line.

The integrated code reconstruction technology permits twisting of the bar code (tilt angle) within certain limits. These are dependent on the transport speed, the scanning rate of the scanner and the bar code properties.

Areas of application of the line scanner

The line scanner is used:

- When the bars of the bar code are printed in the conveying direction ('ladder arrangement').
- With bar codes having very short bar lengths.
- When the ladder code is turned out of the vertical position (tilt angle).
- When the reading distance is large.



Figure 5.1: Deflection principle for the line scanner

5.2 Line scanner with oscillating mirror

The oscillating mirror deflects the scan line additionally to both sides across the scan direction at a randomly adjustable oscillation frequency. In this way, the device can also scan larger areas or spaces for bar codes. The reading field height (and the scan line length useful for evaluation) depends on the reading distance due to the optical opening angle of the oscillating mirror.

Areas of application of the line scanner with oscillating mirror

For line scanners with oscillating mirror, oscillation frequency, start/stop position etc. are adjustable. It is used:

- When the position of the label is not fixed, e.g. on pallets – various labels can, thus, be detected at various positions.
- When the bars of the bar code are printed perpendicular to the conveying direction ("picket fence arrangement").
- When reading stationary objects.
- When the bar code is turned out of the horizontal position.
- When the reading distance is large.
- When a large reading field (reading window) has to be covered.




Figure 5.2: Deflection principle for the line scanner with oscillating mirror add-on

5.3 Omnidirectional reading

In order to read arbitrarily oriented bar codes on an object, at least 2 bar code readers are necessary. If the bar code is not printed over-square, i.e. bar length > code length, bar code readers with integrated code reconstruction technology are necessary.




Figure 5.3: Principle arrangement for omnidirectional reading

6 Mounting

The bar code readers can be mounted in different ways:

- Using two M4x6 screws on the rear of the device or using four M4x6 screws on the bottom of the device (see figure 3.2).
- Using a BT 56 mounting device on the two fastening grooves (see figure 14.3).
- Using a BT 59 mounting device on the two fastening grooves (see figure 14.4).


6.1 Device arrangement

6.1.1 Selecting a mounting location

In order to select the right mounting location, several factors must be considered:

- Size, orientation, and position tolerance of the bar codes on the objects to be scanned.
- The reading field of the device in relation to the bar code module width.
- The resulting minimum and maximum reading distance from the respective reading field (see chapter 14.5 "Reading field curves / optical data").
- The permissible cable lengths between the device and the host system depending on which interface is used.
- The correct time for data output. The device should be positioned in such a way that, taking into consideration the time required for data processing and the conveyor belt speed, there is sufficient time to e.g. initiate sorting operations on the basis of the read data.
- The display and control panel should be very visible and accessible.
- For configuring and commissioning with the webConfig tool, the USB interface should be easily accessible.

For specific information, please refer to Chapter 5.

NOTE	
	<p>The beam of the device exits:</p> <ul style="list-style-type: none"> • Parallel to the housing base in the case of the line scanner • Perpendicular to the housing base in the case of the oscillating mirror <p>In each case, the housing base is the black area.</p>
	<p>The best read results are obtained when:</p> <ul style="list-style-type: none"> • The device is mounted in such a way that the scanning beam is incident on the bar code at an angle of inclination greater than $\pm 10^\circ \dots 15^\circ$ to vertical. • The reading distance lies in the middle area of the reading field. • The bar code labels are of good print quality and have good contrast ratios. • You do not use high-gloss labels. • There is no direct sunlight.

6.1.2 Avoiding total reflection – Line scanner

The bar code label must be positioned at an angle of inclination greater than $\pm 10^\circ \dots 15^\circ$ from vertical in order to avoid total reflection of the laser beam (see Figure 6.1)!

Total reflection occurs whenever the laser light of the bar code reader is directly incident on the surface of the bar code at an angle of 90° . The light directly reflected by the bar code may overload the bar code reader and thereby cause non-readings!





Figure 6.1: Total reflection – line scanner

6.1.3 Avoiding total reflection – oscillating-mirror scanner

For the device with **oscillating mirror**, the laser beam exits at an **angle of 90° to vertical**.

Furthermore, the **swivel range of $\pm 20^\circ$ ($\pm 12^\circ$ for devices with heating)** is to be taken into account.

This means that in order to be on the safe side and to avoid total reflection, the device with oscillating mirror must be inclined upward or downward $20^\circ \dots 30^\circ$!

NOTE	
	Mount the device with oscillating mirror in such a way that the exit window of the bar code reader is parallel to the object. This will result in an angle of inclination of approx. 25° .




Figure 6.2: Total reflection – oscillating-mirror scanner

6.1.4 Mounting location

- ✎ When choosing the mounting location, observe the following:
- Maintaining the required environmental conditions (temperature, humidity).
 - Possible soiling of the reading window due to liquids, abrasion by boxes, or packaging material residues.
 - Lowest possible chance of damage to the device by mechanical collision or jammed parts.
 - Possible extraneous light (no direct sunlight or sunlight reflected by the bar code).

6.1.5 Devices with integrated heating

- ✎ When mounting devices with integrated heating, also observe the following points:
- Mount the device in a way which provides maximum thermal isolation, e.g. using rubber-bonded metal.
 - Mount in such a way that the device is protected from draft and wind; mount additional shields if necessary.

NOTE



When installing the device in a protective housing, it must be ensured that the scanning beam can exit the protective housing without obstruction.

6.1.6 Possible read angles between device and bar code

The optimum alignment of the device is accomplished when the scan line scans the bar code bars almost at a right angle (90°). All reading angles that are possible between the scan line and bar code must be taken account (Figure 6.3).



- α Azimuth angle (tilt)
 β Inclination angle (pitch)
 γ Angle of rotation (skew)

Figure 6.3: Reading angle for the line scanner

NOTE



In order to avoid total reflection, the angle of rotation γ should be greater than 10°.

6.2 Installing the external parameter memory

✚ Remove the cover of the USB connection on the device.

✚ Insert the USB memory stick into the USB connection and then cover it with the connector hood to ensure degree of protection IP 65.

The USB memory stick can be inserted regardless of whether or not the device is connected to supply voltage.

- After the USB memory stick has been inserted and supply voltage applied, the following message appears on the display.

Memory stick connected: Export internal configuration?

✚ Use the navigation buttons   to select OK and activate with the enter button .

The configuration is now transferred to the external parameter memory and is from now on updated immediately when the configuration is changed via display or online commands.

- The display of MS under the device address indicates that the USB memory stick is correctly connected and functional.

Replacing a defective device

✚ Uninstall the defective device.




✚ Remove the external parameter memory from the defective device by unscrewing the protection hood.


✚ Mount the external parameter memory on the new device.

✚ Install and start up the new device.

The following message appears on the display again:

- Memory stick connected: Export internal configuration?

✚ Use the navigation buttons   to select Cancel and activate with the enter button .

NOTE	
	Make sure you select Cancel. Otherwise, the configuration in the external parameter memory is lost!

The configuration is now imported from the external parameter memory and the device is immediately operational without any further configuration.

7 Electrical connection

The bar code readers of this series are connected using variously coded M12 connectors. This ensures unique connection assignments.

The additional USB interface is used for configuring the device.

For the locations of the individual device connections, please refer to the device detail shown below.




NOTE	
	The corresponding mating connectors and preassembled cables are available as accessories for all connections. For additional information, refer to Section 15.3 and Section 7.3.




Figure 7.1: Location of the electrical connections

7.1 Safety notices for the electrical connection

⚠ CAUTION!	
	<p>Do not open the device yourself under any circumstances! There is otherwise a risk of uncontrolled emission of laser radiation from the device. The housing of the device contains no parts that need to be adjusted or maintained by the user.</p> <p>Before connecting the device, be sure that the supply voltage agrees with the value printed on the name plate.</p> <p>Connection of the device and cleaning must only be carried out by a qualified electrician.</p> <p>Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly.</p> <p>If faults cannot be cleared, the device should be switched off and protected against accidental use.</p>

⚠ CAUTION!	
	For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code). The bar code readers are designed in accordance with protection class III for supply by PELV (protective extra-low voltage with reliable disconnection).

NOTE	
	Degree of protection IP65 is achieved only if the connectors and caps are screwed into place!

7.2 Electrical connection of the device

As a **"stand-alone"** device, or multiNet plus **"master"** participant or network slave participant, the device is equipped with four M12 plugs/sockets which are A- and B-coded.

The voltage supply (**PWR**) as well as the four freely configurable switching inputs/outputs (**SW IN/OUT** and **PWR**) are connected there.

An RS 232 or optionally RS 422 interface is available as **"HOST / BUS IN"** interface for connecting to the host system. An RS 485 is available as a second physical **"BUS OUT"** interface for setting up the Leuze multiNet plus scanner network. The device is suitable for use in the Leuze multiNet plus as network master/multiScan master.

An USB connection is used as a **"SERVICE"** interface.




Figure 7.2: Connections of the device

Described in detail in the following are the individual connections and pin assignments.

7.2.1 PWR – Voltage supply and switching inputs/outputs 3 and 4





Figure 7.3: PWR, M12 connector (A-coded)

Table 7.1: Pin assignments - PWR

Pin	Name	Comment
1	VIN	Positive supply voltage +10 ... +30 V DC
2	SWIO_3	Configurable switching input / output 3
3	GND	Negative supply voltage 0 V DC
4	SWIO_4	Configurable switching input / output 4
5	FE	Functional earth
Thread	FE	Functional earth (housing)

Supply voltage


NOTE	
	Connecting the functional earth FE Ensure that the functional earth (FE) is connected correctly. Unimpaired operation is only guaranteed when the functional earth is connected properly. All electrical disturbances (EMC couplings) are discharged via the functional earth connection.

Switching input/output

The device is equipped with four freely programmable, opto-decoupled switching inputs and outputs **SWIO_1 ... SWIO_4**.

The switching inputs can be used to activate various internal functions of the device (decoding, autoConfig, ...). The switching outputs can be used to signal the state of the device and to implement external functions independent of the superior control.

The two switching inputs/outputs **SWIO_1** and **SWIO_2** are located on the **SW IN/OUT** M12 socket and are described in Section 7.2.3. The other two (**SWIO_3** and **SWIO_4**) of the four freely configurable switching inputs/outputs are located on the **PWR** M12 connector.

NOTE	
	It is generally possible to set the respective function as input or output via the display or with the aid of the webConfig configuration tool.

Described in the following is the external wiring for use as a switching input or output; the respective function assignments to the switching inputs/outputs can be found in Chapter 9.

Function as switching input




Figure 7.4: Switching input connection diagram SWIO_3 and SWIO_4

NOTE



If you use a sensor with a standard M12 connector, please note the following:

- Pins 2 and 4 must not be operated as switching outputs if sensors which function as inputs are also connected to these pins.

If, for example, the inverted sensor output is connected to pin 2, and pin 2 of the bar code reader is, at the same time, configured as an output (and not as an input), the switching output malfunctions.

CAUTION!



The maximum input current must not exceed 8 mA!

Function as switching output




Figure 7.5: Switching output connection diagram SWIO_3 / SWIO_4

CAUTION!



Each configured switching output is short-circuit proof! Do not load the respective switching output of the device with more than 60 mA at +10 ... +30 V DC in normal operation!

NOTE



Both switching inputs/outputs SWIO_3 and SWIO_4 are configured by default in such a way that:

- Switching input SWIO_3 activates the reading gate
- Switching output SWIO_4 switches on "No Read."

7.2.2 SERVICE – USB interface (type A)




Figure 7.6: Service, USB, type A

Table 7.2: Pin assignments of SERVICE – USB interface

Pin	Name	Comment
1	VB	Positive supply voltage +5 V DC
2	D-	Data -
3	D+	Data +
4	GND	Ground

CAUTION!



Maximum load of the +5 V DC supply voltage of the USB interface is 200 mA!

☞ Ensure adequate shielding.

The entire interconnection cable must absolutely be shielded acc. to the USB specifications. Cable length must not exceed 3 m.

☞ Use the Leuze-specific **USB service cable** (see chapter 15 "Order guide and accessories") for the connection and use a service PC to configure.

NOTE



IP 65 is achieved only if the connectors and caps are screwed into place. Alternatively, a parameter memory in the form of a USB memory stick certified by Leuze electronic GmbH + Co. can be connected to the provided USB service interface. With this Leuze memory stick, degree of protection IP 65 is also ensured.

7.2.3 SW IN/OUT – Switching input/switching output




Figure 7.7: SW IN/OUT, M12 socket (A-coded)

Table 7.3: Pin assignment SW IN/OUT

Pin	Name	Comment
1	VOUT	Voltage supply for sensor system (VOUT identical to VIN at PWR IN)
2	SWIO_1	Configurable switching input / output 1
3	GND	GND for the sensor system
4	SWIO_2	Configurable switching input / output 2
5	FE	Functional earth
Thread	FE	Functional earth (housing)

The device is equipped with four freely programmable, opto-decoupled switching inputs and outputs **SWIO_1 ... SWIO_4**.

The two switching inputs/outputs **SWIO_1** and **SWIO_2** are located on the **SW IN/OUT** M12 socket. The other two (**SWIO_3** and **SWIO_4**) of the four freely configurable switching inputs/outputs are located on the **PWR** M12 connector and are described in Chapter 7.2.1.

Described in the following is the external wiring for use as a switching input or output; the respective function assignments to the switching inputs/outputs can be found in Chapter 9.

Function as switching input




Figure 7.8: Switching input connection diagram SWIO_1 and SWIO_2

NOTE




If you use a sensor with a standard M12 connector, please note the following:

- Pins 2 and 4 must not be operated as switching outputs if sensors which function as inputs are also connected to these pins.

If, for example, the inverted sensor output is connected to pin 2, and pin 2 of the bar code reader is, at the same time, configured as an output (and not as an input), the switching output malfunctions.

CAUTION!

The maximum input current must not exceed 8 mA!

Function as switching output

- 1 Switching output
- 2 Switching output from controller
- 3 Switching input to controller (deactivated)

Figure 7.9: Switching output connection diagram SWIO_1 / SWIO_2

CAUTION!

Each configured switching output is short-circuit proof! Do not load the respective switching output of the device with more than 60 mA at +10 ... +30 V DC in normal operation!

NOTE

By default, the two switching inputs/outputs SWIO_1 and SWIO_2 are configured so that they function as **switching inputs**.

- Switching input **SWIO_1** activates the **start reading gate** function
- Switching input **SWIO_2** activates the **reference code teach-in** function

The functions of the individual switching inputs/outputs are programmed via the display or via parameterization in the **webConfig** tool under the Switching input or Switching output heading. For further information, see also Chapter 9 "Starting up the device - Configuration" on page 49.

7.2.4 HOST / BUS IN

HOST / BUS IN for BCL 500/

The device makes either the RS 232 or RS 422 interface available as host interface. This is selected via the display or the "webConfig" configuration software. The pin assignments change depending on the selected interface type (see table 7.4, Figure 7.11 and Figure 7.12).




Figure 7.10: HOST/BUS IN, M12 connector (B-coded)

Table 7.4: Pin assignment HOST / BUS IN for BCL 500/

Pin	Name	Comment
1	CTS / RX+	CTS signal (RS 232) / RX+ (RS 422)
2	TxD / Tx-	TXD signal (RS 232) / TX- (RS 422)
3	GND_H	Reference potential 0V for RS 232 / RS 422
4	RTS/ Tx+	RTS signal (RS 232) / TX+ (RS 422)
5	RxD / Rx-	RxD signal (RS 232) / Rx- (RS 422)
Thread	FE	Functional earth (housing)

RS 232 interface






Figure 7.11: Pin assignments - HOST / BUS IN as RS 232

 **CAUTION!**

 Ensure adequate shielding.
The entire interconnection cable must be shielded and earthed. The cables for RTS and CTS must only be connected if RTS/CTS hardware handshake is used.

RS 422 interface




Figure 7.12: Pin assignments - HOST / BUS IN as RS 422

CAUTION!

⚡ Ensure adequate shielding.

The entire interconnection cable must be shielded and earthed. The signal lines must be stranded in pairs.

HOST / BUS IN for BCL 501/

The device makes available an RS 485 as HOST / BUS IN interface for the connection to the host system. This interface is physically looped through to the BUS OUT RS 485 socket. With its RS 485 interface, the device is suitable for use in the Leuze multiNet plus scanner network.




Figure 7.13: HOST/BUS IN, M12 connector (B-coded)

Table 7.5: Pin assignment HOST / BUS IN for BCL 501/

Pin	Name	Comment
1	N.C.	Reserved
2	RS 485 B	RS 485 B - signal line
3	GND 485	Reference ground RS 485 - potential equalization
4	RS 485 A	RS 485 A - signal line
5	FE	Functional earth / shield
Thread	FE	Functional earth (housing)

7.2.5 BUS OUT

To set up the Leuze multiNet plus network with additional participants, the device makes available another interface in the form of an RS 485.




Figure 7.14: M12 socket (B-coded)

Table 7.6: Pin assignment BUS OUT

Pin	Name	Comment
1	VCC485	+5VDC for bus termination
2	RS 485 B	RS 485 B - signal line
3	GND 485	Reference ground RS 485 - potential equalization
4	RS 485 A	RS 485 A - signal line
5	FE	Functional earth / shield
Thread	FE	Functional earth (housing)

If you use ready-made cables, note the following:

⚠ CAUTION!	
⚠	<p>⚡ Ensure adequate shielding.</p> <p>The entire interconnection cable must be shielded and earthed. The signal lines must be stranded in pairs.</p>

Termination of the RS 485 interface on the master (BCL 500)

The RS 485 interface must always be terminated externally on the master via a T-connector and a terminating resistor (see chapter 15 "Order guide and accessories").

Termination of the RS 485 interface on the slave (BCL 500)

On the last network participant, the Leuze multiNet plus network (RS 485 interface) should be terminated with a terminating resistor on the BUS OUT socket (see chapter 15 "Order guide and accessories").

NOTE	
i	The BCL 500 can only participate as a slave in the Leuze multiNet plus on the BUS OUT socket and via an external M 12 T-connector (see chapter 7.4.3 and Figure 7.16).

Termination of the RS 485 interface (BCL 501)

The device operates as slave in the Leuze multiNet plus network. On the last physical participant, the Leuze multiNet plus network (RS 485 interface) must be terminated with a terminating resistor (see chapter 15 "Order guide and accessories"). This prevents reflections on the Leuze multiNet plus and improves the immunity to interference.

7.3

Cable lengths and shielding

↳ Observe the following maximum cable lengths and shielding types:

Table 7.7: Cable lengths and shielding

Connection	Interface	Max. cable length	Shielding
BCL – service	USB	3m	Shielding absolutely necessary acc. to USB specifications
BCL – host	RS 232 RS 422 RS 485	10 m 1200 m 1200 m	Shielding absolutely required RS 422/485 conductors, stranded in pairs
Network from the first BCL to the last BCL	RS 485	1200 m	Shielding absolutely required RS 485 conductors, stranded in pairs
BCL – power supply unit		30m	Not necessary
Switching input		10 m	Not necessary
Switching output		10 m	Not necessary

7.4 Leuze multiNet plus

The Leuze multiNet plus is optimized for fast transmission of scanner data to a primary host computer. The multiNet plus consists physically of a two-wire RS 485 interface through which the multiNet plus software protocol is controlled.

This makes wiring the network easy and inexpensive as slaves are looped through to one another in parallel.




Figure 7.15: Leuze multiNet plus system topology

With the aid of a BCL 500/network master, up to 31 bar code readers can be networked. For this purpose, each participating device is assigned the respective station address via the display and the control panel. The devices are networked by connecting the individual RS 485 interfaces in parallel.

In the Leuze multiNet plus network, the individual network devices sequentially transfer their data to the BCL 500/network master when requested.

The BCL 500/master then transmits the data of all network devices via its host interface (either an RS 232 or RS 422) to a superior PLC control or to a computer, i.e. it "collects" the scanner data in the network and transmits it to an interface on the host computer. This reduces interface costs (CPs) and time spent programming the software.

7.4.1 Wiring the multiNet plus

Leuze multiNet plus connection hints

Shielded, twisted pair conductors should be used for the Leuze multiNet plus. This allows a total network length of up to 1200 m.

Recommended network cable (e.g. LiYCY 2x0.2 mm²):

- Twisted pairs, shielded
- Cross section: min. 0.2 mm²
- Copper resistance <100 W/km

When wiring the network, note the following points:

- ✎ The RS 485A, RS 485B and GND cables are looped through in the network and must not in any case be misconnected; the Leuze multiNet plus network is otherwise not functional. It is recommended to wire through the GND of the RS 485 interface of the participants.
- ✎ Connect the shielding to the slaves on one side with FE.
- ✎ The maximum cable length in the network is 1200m.
- ✎ The (physically) last slave in the network should be equipped with a terminating resistor of 220 W between RS 485A and RS 485B. This prevents reflections on the multiNet plus and improves the immunity to interference.

7.4.2 The BCL 500/ as network master

Master operation

The BCL 500/ bar code readers are specially designed for master operation in a network. They manage the data of the slaves in multiNet plus and establish the connection to the superior host computer. Only a few parameters need to be set for master operation. Network commissioning can thus be performed in very little time (see chapter 9 "Starting up the device - Configuration").

Last slave address

Unlike the slaves, the display of the BCL 500/ is not used to set the network address (the master always has the address 00), but the last slave address, i.e. the number of the most significant slave. This "informs" the BCL 500/ master of the number of slaves operating on the network, without requiring you to call up the webConfig tool. If the network is expanded at a later time, you only need to change the number of slaves (last slave address) accordingly via the display.

Start-up / timeout messages

During the initialization phase, i.e. after switching on the operating voltage, the master searches for the set number of slaves. If a slave is found, the master generates a start-up message "S" for the respective address found, e.g. "04S" -> Slave with the address 04 has responded correctly.

If a slave is not found or does not respond, the master generates a "timeout" (response timeout) at this address.

The slave address and a "T" are output on the host interface. For example, "08T" means that no slave responded at the network address 08. The network is still operational with one or several reported "time-outs", however, a slave, for which a timeout was generated, can no longer be addressed.

BCL 500/ master mounting location

Ensure that the BCL 500/ is mounted in an easily accessible and visible place in your system. Once the network has been put into operation, you can set (configure) every scanner in the network centrally via the USB service or host interface of the BCL 500/, without having to connect a PC/terminal to the individual read stations.

7.4.3 The BCL 500/ as network slave

Alternatively, the bar code readers of the BCL 500/ series can also operate as slave participants in the network mode. They now transmit data to the multiNet master (e.g. BCL 500/) only after the master prompts them to do so, and, using an external M12 T-connector, they establish the continuing connection via the BUS OUT socket to the slaves which follow (order information see chapter 15 "Order guide and accessories"). The last network participant must be terminated with a terminating resistor.




Figure 7.16: Leuze multiNet plus system topology with BCL 500/ as slave

Only a few parameters need to be set for slave operation. Network commissioning can thus be performed in very little time (see chapter 9 "Starting up the device - Configuration").

Slave address

The BCL 500/ display has an important function for setting the network address. The network address, i.e. the corresponding station number of the slave, is set via the display. The address which is set must be > 0 since the master always has address 0 (Adr.00).

Each network device with an address > 0 is thereby automatically informed that it is a slave in the Leuze multiNet plus with this address and that it is initialized and queried by the network master. No other settings are necessary for commissioning in the Leuze multiNet plus.

Other settings

The parameters necessary for the reading task, such as the code types to be read and the number of digits of the code, must be set. This can be done via the display, as well as with the help of the webConfig tool.

7.4.4 The BCL 501/ as network slave

The BCL 501/ bar code readers are specially designed for slave operation in a network. They transmit data to the multiNet master only after the master prompts it to do so and establish the continuing connection via the BUS OUT socket to the slaves which follow. Only a few parameters need to be set for slave operation. Network commissioning can thus be performed in very little time (see chapter 9 "Starting up the device - Configuration").

The connection is performed as described above (Figure 7.15).

Slave address

With the BCL 501/, the network address, i.e. the corresponding station number of the slave, is set via the display. The address which is set must be > 0 since the master always has address 0 (Adr.00).

Each network device with an address > 0 is thereby automatically informed that it is a slave in the Leuze multiNet plus with this address and that it is initialized and queried by the network master. No other settings are necessary for commissioning in the Leuze multiNet plus.






Other settings

The parameters necessary for the reading task, such as the code types to be read and the number of digits of the code, must be set. This can be done via the display, as well as with the help of the webConfig tool.

8 Menu description

After voltage is applied to the bar code reader, a startup screen is displayed for several seconds. The display then shows the bar code reading window with all status information.

8.1 The main menus



Device information - main menu

This menu item contains detailed information on

- Device type
- Software version
- Hardware version
- Serial number

Main menu Bar code reading window

- Visualization of the read bar code information
- Status overview of the switching inputs/outputs
- Set device address
- Bar graphs for read quality of the current bar code.

See "Indicators in the display" on page 17.

Parameter - main menu

- Parameterization of the bar code reader.

See "Parameter menu" on page 47.

Language selection - main menu

- Selection of the display language.

See "Language selection menu" on page 53.

Service - main menu

- Scanner diagnostics and status messages

See "Service menu" on page 53.

Main menu Actions

- Various functions for scanner configuration and manual operation

See "Actions menu" on page 53.

NOTE




The display offers only limited configuration options. The configurable parameters are described in this chapter. Only the webConfig tool provides complete configuration options and is largely self-explanatory. For the use of webConfig tool see chapter 8. Notes on commissioning via the webConfig tool see chapter 10.

8.2 Parameter menu

Parameter handling

The **Parameter handling** submenu is used to lock and release the parameter input via the display and for resetting to default values.

Table 8.1: Parameter handling submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
Parameter enable			OFF/ON <i>The standard setting (OFF) prevents unintended parameter changes. If parameter enabling is activated (ON), parameters can be changed manually.</i>	OFF
Parameters to default			<i>By pressing the enter button  after selecting Parameters to default, all parameters are reset to their standard settings without any further security prompts. In this case, English is selected as the display language.</i>	

Decoder table

In the **Decoder table** submenu, 4 different code type definitions can be stored. Bar codes that have been read can only be decoded if they correspond to one of the definitions stored here.

Table 8.2: Decoder table submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
Max. no. of labels			Value between 0 and 64 <i>The value set here specifies the maximum number of labels that should be detected for each reading gate.</i>	1
Decoder 1	Symbology (Code type)		No code Code 2/5 Interleaved Code 39 Code 32 Code UPC Code EAN Code 128 EAN Addendum Codabar Code 93 GS1 DataBar Omnidirectional GS1 DataBar Limited GS1 DataBar Expanded <i>If No code is configured, the current and all subsequent decoders are deactivated.</i>	Code 2/5i
		Number of digits	Interval mode OFF/ON <i>With the ON setting, the values in digits 1 and 2 define a range of character numbers that are to be read.</i>	OFF
		Number of digits 1	0 to 64 characters <i>First decodable number of characters or lower range limit.</i>	10
		Number of digits 2	0 to 64 characters <i>Second decodable number of characters or upper range limit.</i>	0
		Number of digits 3	0 to 64 characters <i>Third decodable number of characters.</i>	0
		Number of digits 4	0 to 64 characters <i>Fourth decodable number of characters.</i>	0
		Number of digits 5	0 to 64 characters <i>Fifth decodable number of characters.</i>	0
		Reading reliability	Value from 2 to 100 <i>Number or scans required to reliably detect a label.</i>	4

Table 8.2: Decoder table submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
	Check digit method		Standard No check <i>Depending on the symbology (code type) selected for the decoder, further calculation algorithms can be selected here.</i> <i>Check digit method used for the decoding of the bar code that has been read.</i> <i>If Standard is set, the check digit method intended for the respective code type is used.</i>	Standard
	Check digit transm.		Standard Not standard <i>Specifies whether the check digit is transmitted. Standard means that the transmission matches the standard intended for the respective code type.</i>	Standard
Decoder 2	Symbology		<i>Same as decoder 1</i>	Code 39
	Number of digits	Interval mode	OFF/ON	ON
		Number of digits 1	0 to 64 characters	4
		Number of digits 2	0 to 64 characters	30
		Number of digits 3	0 to 64 characters	0
		Number of digits 4	0 to 64 characters	0
		Number of digits 5	0 to 64 characters	0
	Reading reliability		Value from 2 to 100	4
	Check digit method		<i>Same as decoder 1</i>	Standard
	Check digit transm.		<i>Same as decoder 1</i>	Standard
Decoder 3	Symbology		<i>Same as decoder 1</i>	Code 128
	Number of digits	Interval mode	OFF/ON	ON
		Number of digits 1	0 to 64 characters	4
		Number of digits 2	0 to 64 characters	63
		Number of digits 3	0 to 64 characters	0
		Number of digits 4	0 to 64 characters	0
		Number of digits 5	0 to 64 characters	0
	Reading reliability		Value from 2 to 100	4
	Check digit method		<i>Same as decoder 1</i>	Standard
	Check digit transm.		<i>Same as decoder 1</i>	Standard
Decoder 4	Symbology		<i>Same as decoder 1</i>	Code UPC
	Number of digits	Interval mode	OFF/ON	OFF
		Number of digits 1	0 to 64 characters	8
		Number of digits 2	0 to 64 characters	0
		Number of digits 3	0 to 64 characters	0
		Number of digits 4	0 to 64 characters	0
		Number of digits 5	0 to 64 characters	0
	Reading reliability		Value from 2 to 100	4
	Check digit method		<i>Same as decoder 1</i>	Standard
	Check digit transm.		<i>Same as decoder 1</i>	Standard

Digital SWIO

The **Digital SWIO** submenu is used to configure the 4 switching inputs/outputs of the device.

Table 8.3: Digital SWIO submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
Sw. input/ output 1	I/O mode		Input / Output / Passive <i>Determines the function of switching input/output 1. In the case of passive, the connection is on 0 V if the Inverted parameter is set to OFF, and on +UB if the Inverted parameter is set to ON.</i>	Input
	Switching input	Inverted	OFF / ON OFF = activation of the switching input function upon high level at the switching input ON = activation of the switching input function upon low level at the switching input	OFF
		Debounce time	Value from 0 to 1000 <i>Time in milliseconds for which the input signal must be present and stable.</i>	5
		Switch-on delay	Value from 0 to 65535 <i>Time in milliseconds between the end of the debounce time and activation of the function configured below.</i>	0
		Pulse duration	Value from 0 to 65535 <i>Minimum activation time in milliseconds for the function configured below.</i>	0
		Switch-off delay	Value from 0 to 65535 <i>Time in milliseconds for which the function configured below remains activated after the switching input signal is deactivated and the pulse duration has expired.</i>	0
		Function	No BCL 500 function Reading gate start/stop Reading gate stop Rd. gate start Teach reference code Autoconfig start/stop <i>The function set here is carried out after the switching input is activated.</i>	Reading gate start/stop

Table 8.3: Digital SWIO submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
	Switching output	Inverted	OFF / ON <i>OFF = activated switching output upon high level ON = activated switching output upon low level</i>	OFF
		Signal delay	Value from 0 to 65535 <i>Time in milliseconds between activation function and switching of the switching output.</i>	0
		Pulse duration	Value from 0 to 65535 <i>Switch-on time of the switching output in milliseconds. If the Pulse duration is set to 0, the switching output is switched on via the Activation function and switched off via the Deactivation function. If the Pulse duration is greater than 0, the Deactivation function has no effect.</i>	400
		Activation function 1	No function Reading gate start Reading gate end Positive reference code comparison 1 Negative reference code comparison 1 Valid read result Invalid read result Device ready Device not ready Data transmission active Data transmission not active AutoCont. good quality AutoCont. bad quality Reflector detected Reflector not detected External event, pos. edge External event, neg. edge Device active Device standby No device error Device error Positive reference code comparison 2 Negative reference code comparison 2 <i>The function set here specifies which event activates the switching output.</i>	No function
		Deactivation function 1	See Activation function 1 for selection options <i>The function set here specifies the event that deactivates the switching output.</i>	No function
Sw. input/ output 2	I/O mode		Input / Output / Passive	Output
	Switching input	Inverted	OFF / ON	OFF
		Debounce time	Value from 0 to 1000	5
		Switch-on delay	Value from 0 to 65535	0
		Pulse duration	Value from 0 to 65535	0
		Switch-off delay	Value from 0 to 65535	0
		Function	<i>See switching input/output 1</i>	No function
	Switching output	Inverted	OFF / ON	OFF
		Signal delay	Value from 0 to 65535	0
		Pulse duration	Value from 0 to 65535	400
		Activation function 2	<i>See switching input/output 1</i>	Valid read result
		Deactivation function 2	<i>See switching input/output 1</i>	Reading gate start

Table 8.3: Digital SWIO submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
Sw. input/ output 3	I/O mode		Input / Output / Passive	Input
	Switching input	Inverted	OFF / ON	OFF
		Debounce time	Value from 0 to 1000	5
		Switch-on delay	Value from 0 to 65535	0
		Pulse duration	Value from 0 to 65535	0
		Switch-off delay	Value from 0 to 65535	0
		Function	<i>See switching input/output 1</i>	Reading gate start/stop
	Switching output	Inverted	OFF / ON	OFF
		Signal delay	Value from 0 to 65535	0
		Pulse duration	Value from 0 to 65535	400
		Activation function 3	<i>See switching input/output 1</i>	No function
		Deactivation function 3	<i>See switching input/output 1</i>	No function
Sw. input/ output 4	I/O mode		Input / Output / Passive	Output
	Switching input	Inverted	OFF / ON	OFF
		Debounce time	Value from 0 to 1000	5
		Switch-on delay	Value from 0 to 65535	0
		Pulse duration	Value from 0 to 65535	0
		Switch-off delay	Value from 0 to 65535	0
		Function	<i>See switching input/output 1</i>	No function
	Switching output	Inverted	OFF / ON	OFF
		Signal delay	Value from 0 to 65535	0
		Pulse duration	Value from 0 to 65535	400
		Activation function 4	<i>See switching input/output 1</i>	Invalid read result
		Deactivation function 4	<i>See switching input/output 1</i>	Reading gate start

Com

The **Com** submenu is used for configuring the communication interfaces of the BCL 500*i*.

Table 8.4: Com submenu

Level 3	Level 4	Level 5	Selection/configuration option <i>Description</i>	Standard
Operating mode			Stand-alone device Network Master Network Slave	Stand-alone device
HOST / BUS IN	Protocol type		No protocol Framing protocol Framing protocol with acknowledgment multiNet Slave multiNet master	Framing protocol
	Interface	Baud rate	110 ... 115200 baud	9600
		Data format	7N1 7N2 7E1 7E2 7O1 7O2 8N1 8N2 8E1 8E2 8O1 8O2 9N1 <i>The data format is specified in: Number of bits (7,8,9) Parity (N=none, E=even, O=odd) Number of stop bits (1,2)</i>	8N1
		Handshake	None RTS CTS XON XOFF	None
		Standard	RS232 RS422 RS485	RS232
	Framing protocol ^{a)}	RX	Prefix 1 ... 3 ^{b)} Postfix 1 ... 3 BCC mode <i>Control character definition for transmit data</i>	STX, NULL, NULL CR, LF, NULL None
		TX	Prefix 1 ... 3 Postfix 1 ... 3 BCC mode <i>Control character definition for received data</i>	STX, NULL, NULL CR, LF, NULL None
		Address format	No address Binary address ASCII address Automatic address	No address
		Address	Value from 0 to 31	0
BUS OUT	multiNet master	Maximum number of slaves	Value from 0 to 31 <i>If the device was configured as network master in the Operating mode menu item, the maximum number of slaves managed by the master must be entered here.</i>	1
	multiNet slave	Slave address	Value from 0 to 31 <i>If the device was configured as network slave in the Operating mode menu item, the slave address must be entered here.</i>	1

a) If the device is configured as stand-alone device or network master, the framing protocol defines how data is exchanged between the device and the host. The framing protocol is a character-based protocol for the transmission of ASCII characters. It groups the characters to be transmitted into a datablock and frames the block with control characters. Various block checking methods are optionally available for protecting the integrity of the data.

b) Enter the decimal value of the desired ASCII character here. For example, enter "13" for the "CR" character (Carriage Return). A table of ASCII characters can be found in Section 16.1.

8.3 Language selection menu

Currently, there are 6 display languages available:

- German
- English
- Spanish
- French
- Italian
- Chinese

The display language and the language of the webConfig user interface are synchronized. The setting in the display affects the webConfig tool and vice versa.

8.4 Service menu

Diagnosis

This menu item is used exclusively for service purposes by Leuze electronic.


Status messages

This menu item is used exclusively for service purposes by Leuze electronic.


8.5 Actions menu

Start decoding

Here, you can perform a single reading via the display.

☞ Activate the single reading with the button  and hold a bar code in the reading field of the device.

The laser beam is switched on and the following display appears:




Once the bar code is detected, the laser beam is switched off again. The read result **ZZZZZZZZ** is shown directly in the display for about 1 s. After that, the Actions menu is displayed again.

Start alignment

The alignment function makes it easy to align the device by optically displaying the read quality.

☞ Activate the alignment function with the button  and hold a bar code in the reading field of the device.

At first, the laser beam is switched on continuously, enabling you to position the bar code securely in the reading field. Once the bar code is read, the laser beam is switched off briefly and the following display appears:



xx Read quality in % (scans with info)
ZZZZZZ Contents of the decoded bar code

Once the bar code has been detected, the laser beam starts to flash.

The flash frequency provides visual information on the read quality. The faster the laser beam flashes, the higher the read quality.

NOTE


In this mode, the bar code reader must reach at least 100 identical readings to obtain the result. The more readings are required, the lower the read quality. The read quality is displayed via the bar graph.

Start auto setup

The auto setup function provides an easy option for configuring the code type and number of digits of **Decoder 1**.

Use the button to activate the auto-setup function and hold an unknown bar code in the reading beam of the device.

The following display appears:



The following information is displayed:

xx Code type of the detected code (sets the code type of Decoder 1)

'01'	2/5 Interleaved
'02'	Code 39
'03'	Code 32
'06'	UPC (A, E)
'07'	EAN
'08'	Code 128, EAN 128
'10'	EAN Addendum
'11'	Codabar
'12'	Code 93
'13'	GS1 Databar Omnidirectional
'14'	GS1 Databar Limited
'15'	GS1 Databar Expanded

yy Number of digits of the detected code (sets the number of digits of Decoder 1)


zzzzzz: Contents of the decoded label. A – appears if the label was not correctly read.

Start teach-in

The teach-in function can be used to conveniently read reference code 1.

Use the button to activate the teach-in function and hold a bar code which contains the content that you wish to store as the reference code in the reading beam of the device.

The following display appears:



The following information is displayed:





RC13 Means that **ReferenceCode** number 1 is stored in RAM. This is always output

xx Defined code type (see auto setup)

z Defined code information (1 ... 63 characters)


8.6 Operation


Shown here is an example describing important operating procedures in detail.


NOTE	
	<p>Use the navigation buttons   to move through the menu. Activate the desired selection with the enter button .</p>

Parameter enable



During normal operation parameters can be viewed only. If parameters need to be changed, the **ON** menu item in the **Parameter enabling** menu must be activated. To do this proceed as follows:




➤ In the Parameter menu, use the   buttons to select the **Parameter handling** menu item.






➤ Press the enter button to enter the **Parameter handling** menu.

➤ In the Parameter handling menu, use the   buttons to select the **Parameter enable** menu item.



➤ Press the enter button to enter the **Parameter enable** menu.

➤ In the Parameter enable menu, use the   buttons to select the **ON** menu item.



➤ Press the enter button to activate parameter enable.

➤ The PWR LED lights up red. You can now set individual parameters via the display.



➤ Press the ESC button twice to return to the main menu.

Network configuration

Information on network configuration can be found in chapter "Starting up the device - Configuration" on page 59.

8 Starting up the device – Leuze webConfig tool

With the **Leuze webConfig tool**, an operating-system independent, web-technology based, graphical user interface is available for configuring bar code readers of the BCL 500/series.

Through the use of HTTP as communication protocol and by using only standard technologies on the client side (HTML, JavaScript and AJAX), which are supported by all commonly used, modern browsers (e.g. **Mozilla Firefox** beginning with Version 2 or **Internet Explorer** beginning with Version 7.0), it is possible to operate the **Leuze webConfig tool** on any internet-ready PC.

8.1 Connecting the SERVICE USB interface

The connection to the SERVICE USB interface of the device is established via the PC-side USB interface using a special USB cable with 2 type A/A plugs.

8.2 Installing the required software

8.2.1 System requirements


NOTE	
	It is recommended to update the operating system regularly and to install the current Windows service packs.

Table 8.1: webConfig system requirements


Operating system	Windows 10 (recommended) Windows 8. 8.1 Windows 7
Computer	PC, laptop or tablet with USB interface, version 1.1 or higher
Graphics card	Min. resolution: 1280 x 800 pixels
Required disk space for USB driver	10 MB
Internet browser	Recommended is a current version of Mozilla Firefox Google Chrome Microsoft Edge Note: Other Internet browsers are possible but have not been tested with the current device firmware.

8.2.2 Installing the USB driver


In order for the device to be automatically detected by the connected PC, the **USB driver** must be installed **once** on your PC. To do this, you must have **administrator privileges**.

Please proceed according to the following steps:

- Start your PC with administrator privileges and log on.
- Load the CD included in the delivery contents of your device in the CD drive and start the setup.exe program.
- Alternatively, you can also download the setup program from the internet at www.leuze.com.
- Follow the instructions provided by the setup program.

Upon successful installation of the USB driver, an icon BCL 50xi  automatically appears on the desktop.

To check: In the Windows device manager, a device called "Leuze electronic, USB Remote NDIS Network Device" appears under the "Network adapter" device class following successful USB registration.

NOTE	
	If the installation failed, contact your network administrator: The settings of the firewall used may need to be adjusted.

8.3 Starting the webConfig tool

To start the **webConfig tool**, click the icon BCL 50xi located on the desktop. Make certain that the device is connected to the PC via the USB interface and that voltage is connected.

Or alternatively: Open a browser on your PC and enter the following address: **192.168.61.100**.

This is the default Leuze service address for communication with bar code readers of the BCL 500/series. In both cases, the following start page appears on your PC.




Figure 8.1: The start page of the webConfig tool

NOTE



The webConfig tool is completely contained in the firmware of the device. Depending on firmware version, the start page may vary from that shown above.

The individual parameters are – where useful – graphically displayed in order to better illustrate the meaning of the what are often perceived as abstract parameters.

The result is an easy-to-use and practically-oriented user interface!

8.4 Short description of the webConfig tool

The webConfig tool has 5 main menus:

- **Process**
with the current read bar code information.
- **Alignment**
for manually starting read processes and for aligning the bar code reader. The results of the read processes are displayed immediately. As a result, this menu item can be used to determine the optimum installation location.
- **Configuration**
for adjusting decoding, for data formatting and output, switching inputs/outputs, communication parameters and interfaces, etc. ...
- **Diagnostics**
for event logging of warnings and errors
- **Maintenance**
for updating the firmware.

The user interface of the webConfig tool is largely self-explanatory.

8.4.1 Module overview in the Configuration menu

The adjustable parameters of the device are clustered in modules in the Configuration menu.




Figure 8.2: Module overview in the webConfig tool

NOTE



The webConfig tool is completely contained in the firmware of the device. Depending on firmware version, the module overview may vary from that shown above.

The individual modules and their relationships to one another are graphically displayed in the module overview. The display is context sensitive, i.e. click a module to directly access the corresponding submenu.

An overview of the modules:

- **Decoder**
Definition of code types, code-type features and number of digits of the labels that are to be decoded
- **Data processing**
Filtering and processing of the decoded data
- **Output**
Sorting of the processed data and comparison with reference codes
- **Communication**
Formatting of the data for output via the communication interfaces
- **Control**
Activation/deactivation of decoding
- **Switching input**
Activation/deactivation of read processes
- **Switching output**
Definition of events which activate/deactivate the switching output
- **Display**
Formatting of the data for output on the display
- **Oscillating mirror** (optional)
Setting oscillating mirror parameters


The webConfig tool is available for all bar code readers of the BCL 500i series. During commissioning of the BCL 500*i*, it is recommended that the individual modules be configured in the order presented above. Further information on commissioning can be found in chapter "Starting up the device - Configuration" on page 49.

9 Starting up the device - Configuration

This chapter describes basic configuration steps which you can carry out either via the webConfig tool or the display.


Via the webConfig tool

The most convenient way to configure the device is via the webConfig tool. Only the webConfig tool gives you access to all settings of the device. To use the webConfig tool, you need to establish a USB connection between the device and a PC/laptop.

NOTE	
	Notes on use see chapter 8 "Starting up the device – Leuze webConfig tool".

Via display

The display offers basic configuration options for the device. Configuration via the display is appropriate if you want to configure simple reading tasks and you cannot or do not want to set up a USB connection between the device and a PC/laptop.


NOTE	
	Notes on use see chapter 3.5.2 "Status indicators and operation".

9.1 Measures to be performed prior to the initial commissioning

- ✎ Before commissioning, familiarize yourself with the operation and configuration of the device.
- ✎ Before connecting the supply voltage, recheck all connections and ensure that they have been properly made.
- ✎ Check the applied voltage. It must be in the range between +10V ... 30 V DC.

Connecting the functional earth FE

- ✎ Ensure that the functional earth (FE) is connected correctly.

NOTE	
	Unimpaired operation is only guaranteed when the functional earth is connected properly. All electrical disturbances (EMC couplings) are discharged via the functional earth connection.

9.2 Starting the device

- ✎ Connect the +10 ... 30VDC supply voltage (typ. +24VDC); the device starts up and the bar code reading window appears on the display.

By default, parameter enabling is deactivated and you cannot change any settings. If you wish to carry out the configuration via the display, you must activate parameter enabling (see chapter 8.6 "Operation", Parameter enable).

9.3 Operation of the device

- ✎ As a first step, you need to set the communication parameters of the device. The device can be operated as stand-alone device, multiNet plus master or multiNet plus slave.

You can make the necessary settings via the display or via the webConfig tool. The settings made by means of the webConfig tool are described here only briefly.

9.3.1 Operation as stand-alone device

Operation of the BCL 500/i is factory-set to stand-alone device.

If you want to operate the BCL 500/i as stand-alone device, you can skip the following points. For further settings see chapter 9.6.





9.3.2 Selecting the operating mode

To operate the BCL 500/i as multiNet master or slave, you must set the corresponding operating mode.

In the webConfig tool

✚ In the main menu, select **Configuration -> Communication -> Overview**.

Or alternatively in the display

NOTE	
	Use the navigation buttons   to move through the menu. Activate the desired selection with the enter button  .

✚ In the main menu, select the **Parameter menu**.

✚ Select the **Com** menu item.

✚ Press the enter button to enter the menu.

✚ Select the **Operating mode** menu item.

✚ Press the enter button to enter the menu.

✚ Select the desired menu item: **Stand-alone device**, **Network master** or **Network slave**.

✚ Press the enter button to activate the operating mode.

webConfig tool or display

✚ Set one of the following three operating modes:

- Stand-alone device:

BCL 500/i in stand-alone operation (see chapter 9.5)

- Network Master:

BCL 500/i as master in multiNet plus. Further settings are required for master operation (see chapter 9.3.3).

- Network Slave:

BCL 500/i as slave in multiNet plus. Further settings are required for slave operation. The configuration of the BCL 500/i as multiNet slave corresponds to the configuration of the BCL 501/i (see chapter 9.4).

9.3.3 Operation as multiNet plus master

For operation as multiNet plus master, you must inform the BCL 500/i of the maximum number of slaves to be managed. This is done via the Maximum number of slaves parameter.

Set the Maximum number of slaves parameter to the desired value:

Via webConfig:

✚ **Configuration -> Communication -> BUS OUT -> Protocol**

Or, alternatively, via the display:

BCL 500/i as slave in multiNet plus. Further settings are required for slave operation. The configuration of the BCL 500/i as multiNet slave corresponds to the configuration of the BCL 501/i (see chapter 9.4).

✚ In the main menu, select the **Parameter menu**.

✚ Select the **Com** menu item.

✚ Press the enter button to enter the menu.

✚ Select the **BUS OUT** menu item.

✚ Press the enter button to enter the menu.

✚ Select the **multiNet master** menu item.

✚ Press the enter button to enter the menu.

✚ Press the enter button to enter the menu for setting the maximum number of slaves.

✚ Displayed in the following screen is the preset number 1, which you can now change.

✚ Select the desired number of slaves. An accidental, incorrect entry can be corrected by selecting **<-|** and then pressing the enter button.

✚ Select **Save**.

✚ Press the enter button in order to save the set number of slaves.

Furthermore, you must configure the BCL 500/i in such a way that it can communicate with the superior host:

Interface standard and communication parameters of the host interface:

Select the desired interface standard (RS 232 / RS 422) and set the associated parameters:

Via webConfig:

↳ Configuration -> Communication -> HOST/BUS IN -> Data transmission

Or, alternatively, via the display:

↳ In the main menu, select the **Parameter menu**.

↳ Select the **Com** menu item.

↳ Press the enter button to enter the menu.

↳ Select the **HOST/BUS IN** menu item.

↳ Press the enter button to enter the menu.

↳ Select the **Interface** menu item.

↳ Press the enter button to enter the menu.

↳ Press the enter button to enter the menu for setting the interface parameters.

↳ Displayed in the following screen is the preset number 1, which you can now change.

↳ Successively select the parameters available and set the values you require. For a description of the various configuration options see table 8.4.

Communication protocol of the host interface:

Select the desired protocol and set the associated parameters:

Via webConfig:

First select:

↳ Configuration -> Communication-> HOST/BUS IN -> Protocol

Then select:

↳ Configuration -> Communication-> HOST/BUS IN -> Framing protocol

Or, alternatively, via the display:

First select:

↳ Parameter -> Com -> HOST/BUS IN -> Protocol type

Then select:

↳ Parameter -> Com -> HOST/BUS IN -> Framing protocol

Proceed with the device configuration (see chapter 9.5).

9.4 Operation of BCL 501/i

The communication parameters of the HOST/BUS IN and BUS OUT interfaces are permanently set for operation of the device as multiNet plus slave. To enable communication of the BCL 500/i/BCL 501/i with the multiNet plus master, you only need to set the device address.

NOTE



The BCL 501/i always automatically starts as slave participant in multiNet plus. The default address is 1.

The Leuze multiNet plus permits an address range from 0 to 31. Address 31 must not be used for data communication. It may only be used temporarily for commissioning.


Set the parameter of the slave address to a value > 0 and < 31. Start with address 01 for the first slave and assign the following addresses in ascending order and without gaps.


Via webConfig:

↳ Configuration -> Communication -> BUS OUT -> Protocol

Or, alternatively, via the display:

- ↵ In the main menu, select the **Parameter menu**.
- ↵ Select the **Com** menu item.
- ↵ Press the enter button to enter the menu.
- ↵ Select the **BUS OUT** menu item.
- ↵ Press the enter button to enter the menu.
- ↵ Select the **multiNet Slave** menu item.
- ↵ Press the enter button to enter the menu.
- ↵ Press the enter button to enter the menu for setting the slave address.
- ↵ Displayed in the following screen is the preset slave address 1, which you can now change.
- ↵ Select the desired number of slaves. An accidental, incorrect entry can be corrected by selecting <-| and then pressing the enter button.
- ↵ Select **Save**.
- ↵ Press the enter button in order to save the set number of slaves.

NOTE	
	Permissible values for the network address in the Leuze multiNet plus are 0 ... 31. Make certain that a different address is assigned to each multiNet plus participant.

NOTE	
	From the hardware address (device address > 0), the BCL 501 / detects that networking is required. It automatically switches to the Leuze multiNet plus network and waits for initialization by the master.

9.5 Further settings

After the basic configuration of the operating mode and the communication parameters, you need to carry out further settings:

- Decoding and processing the read data
- Control of the decoding
- Control of the switching outputs

9.5.1 Decoding and processing the read data

The device offers the following possibilities:

- Setting the number of labels to be decoded for each reading gate (0 ... 64). This is done via the Max. no. of labels parameter.
 - Definition of up to 8 different code types (4 different types if configured via the display). Labels that match one of the defined code types are decoded. Further parameters can be set for each code type:
 - Code type (symbology)
 - Number of digits: either up to 5 different numbers of digits (e.g., 10, 12, 16, 20, 24), or a range (Interval mode) and up to three additional numbers of digits (e.g., 2 ... 10, 12, 16, 26)
 - Reading reliability: the set value specifies how many times a label must be read and decoded with the same result before the result is accepted as valid.
 - Activation of the code reconstruction technology (CRT, in the webConfig tool only)
 - Additional code type specific settings (in the webConfig tool only)
 - Check digit method used for decoding as well as the type of check digit transmission for the output of the read result. The two possibilities for the latter are Standard (corresponds to the standard for the selected code type/symbology) and not Standard.
- ↵ Define at least one code type with the desired settings.

In the webConfig tool: **Configuration -> Decoder**

Or alternatively in the display: **Parameter -> Decoder table**

Data processing via the webConfig tool

In the Data and Output submenus of the Configuration main menu, the webConfig tool provides extensive data processing options to adapt the functionality of the device to the specific reading task:

- Data filtering and segmentation in the Data submenu:
 - Data filtering according to characteristics for handling identical bar code information
 - Data segmentation for differentiating between identifier and content of the read data
 - Data filtering according to content and/or identifier in order to suppress the output of bar codes with specific content/identifiers
 - Completeness inspection of the read data
- Sorting and formatting the output data in the Output submenu:
 - Configuration of up to 3 different sorting criteria. Sorting by physical data and content of the read bar codes.
 - Formatting of the data output for the HOST.
 - Formatting of the data output for the display.

9.5.2 Control of the decoding

In general, decoding is controlled via one or more of the configurable switching inputs/outputs. For this purpose, the respective connection to the **SW IN/OUT** and **POWER** interfaces must be configured as a switching input.


Via a switching input, you can:

- Start decoding
- Stop decoding
- Start decoding and then stop decoding after a configurable time period
- Read a reference code
- Start the automatic code type configuration (AutoConfig)

✚ Connect the required control devices (photoelectric sensor, proximity switch, etc.) to the device (see chapter 7).

✚ Configure the connected switching inputs according to your requirements. To do this, first set the I/O mode to Input and then configure the switching behavior.

- In webConfig: **Configuration -> Device -> Switching inputs/outputs**
- Or alternatively in the display: **Parameter -> Digital SWIO -> Switching input/output 1-4**

NOTE	
	Alternatively, one can also activate decoding via the online command '+' and deactivate it via the online command '-'. For further information on the online commands, see chapter 10 "Online commands".

Advanced decoder control in the webConfig tool

The webConfig tool provides advanced functions, in particular for deactivating decoding. These may be accessed via the Control submenu of the Configuration main menu. You can:

- Activate decoding automatically (delayed)
- Stop decoding after a maximum reading gate time
- Stop decoding via the completeness mode, if:
 - the maximum number of bar codes to be decoded has been decoded
 - A positive reference code comparison has taken place.

9.5.3 Control of the switching outputs

By using the switching inputs/outputs of the device, external event-controlled functions can be implemented without assistance from the superior process control. For this purpose, the respective connection at the SW IN/OUT and POWER interfaces must be configured as a switching output.

A switching output can be activated:

- At the start/end of the reading gate
- Depending on the read result:
 - Reference code comparison positive/negative

- Read result valid/invalid
 - Depending on the state of the device:
 - Ready/not ready
 - Data transmission active/not active
 - Active/standby
 - Error/no error
 - etc.
- ✚ Connect the required switching outputs (see chapter 7).
- ✚ Configure the connected switching outputs according to your requirements. To do this, first set the I/O mode to Output and then configure the switching behavior.
- In webConfig: **Configuration -> Device -> Switching inputs/outputs**
 - Or alternatively in the display: **Parameter -> Digital SWIO -> Switching input/output 1-4**

9.6 Transmitting configuration data

Instead of going through the tedious task of configuring every parameter of the device individually, you can also conveniently transfer configuration data.

In general, there are two possibilities for transferring configuration data between two bar code readers:

- Storage in a file and transfer using the webConfig tool
- Using the external parameter memory

9.6.1 Via the webConfig tool

With the webConfig tool, you can store entire configurations of the device on data carriers and transfer them from these to the device.

This storage of configuration data is especially useful if you want to store basic configurations which will require only minor changes.

In the webConfig tool, you store the configuration data via the buttons in the upper part of the middle window of all submenus of the Configuration main menu.

9.6.2 With the external parameter memory

The use of the external parameter memory permits the easy replacement of a defective device on site. This requires an external parameter memory to be installed permanently to the USB connection of the device.

The device stores a copy of the current configuration in the external parameter memory. This copy is immediately updated when the configuration is changed via the display or by a superior host system (PC/PLC) via online commands.

10 Online commands

10.1 Overview of commands and parameters

Online commands can be used to send commands directly to the device for control and configuration. For this purpose, the device must be connected to a host- or service computer via the interface. The commands described can be sent either via the host or the service interface.

Online commands

With the commands, you can:

- control/decode.
- read/write/copy parameters.
- carry out an automatic configuration.
- teach-in/set reference codes.
- call up error messages.
- call up statistical device information.
- carry out a software reset in order to reinitialize the device.

Syntax

Online commands consist of one or two ASCII characters followed by command parameters.

No separation characters may be entered between the command and the command parameter(s). Both small and capitalized letters can be used.

Example:

Command 'CA': autoConfig function
 Parameter '+': Activation
 Transmitted is: 'CA+'

Notation

Commands, command parameters and returned data are enclosed between single quotation marks ' ' in the text of this manual.

Most "online" commands are acknowledged by the device and any requested data returned. For commands that are not acknowledged, command execution can be observed or monitored directly on the device.

10.1.1 General online commands

Software version number

Command	'V'
Description	Requests device version information
Parameters	No
Acknowledgment	'BCL 500i SM 100 V 1.3.8 2008-02-15' The first line contains the device type, followed by the device version number and version date. (The data which is actually displayed may vary from the values given here.)

NOTE



This command returns the major release number of the software packet. This major release number also appears on the display during start-up.

This command can be used to check whether the connected host or service computer is properly connected and configured. If you do not receive an acknowledgment, please check interface connections, protocol and service switches.

Software reset

Command	'H'
Description	Carries out a software reset. The device is restarted and reinitialized, leaving it in the same state as when the supply voltage is switched on.
Parameters	No
Acknowledgment	'S' (start character)

Code recognition

Command	'CC'
Description	Detects an unknown bar code and outputs number of digits, code type, and code information to the interface, without storing the bar code in the parameter memory.
Parameters	No
Acknowledgment	<p>'xx yy zzzzz'</p> <p>xx: Number of digits of the read code</p> <p>yy: Code type of the read code</p> <p>'01' 2/5 Interleaved</p> <p>'02' Code 39</p> <p>'03' Code 32</p> <p>'06' UPC (A, E)</p> <p>'07' EAN</p> <p>'08' Code 128, EAN 128</p> <p>'10' EAN Addendum</p> <p>'11' Codabar</p> <p>'12' Code 93</p> <p>'13' GS1 Databar Omnidirectional</p> <p>'14' GS1 Databar Limited</p> <p>'15' GS1 Databar Expanded</p> <p>zzzzz: Contents of the decoded label. A – appears if the label was not correctly read.</p>

autoConfig

Command	'CA'
Description	Activates or deactivates the 'autoConfig' function. Certain label reading parameters are programmed automatically in the setup by the labels which the device reads while the autoConfig function is active.
Parameters	<p>'+' Activates 'autoConfig'</p> <p>'/' Rejects the last code read</p> <p>'-' Deactivates 'autoConfig' and stores the decoded data in the current parameter set</p>
Acknowledgment	<p>'CSx'</p> <p>x Status</p> <p>'0' Valid 'CA' command</p> <p>'1' Invalid command</p> <p>'2' autoConfig could not be activated</p> <p>'3' autoConfig could not be deactivated</p> <p>'4' Result could not be deleted</p>
Description	<p>'xx yy zzzzz'</p> <p>xx Number of digits of the read code</p> <p>yy Code type of the read code</p> <p>'01' 2/5 Interleaved</p> <p>'02' Code 39</p> <p>'03' Code 32</p> <p>'06' UPC (A, E)</p> <p>'07' EAN</p> <p>'08' Code 128, EAN 128</p> <p>'10' EAN Addendum</p> <p>'11' Codabar</p> <p>'12' Code 93</p> <p>'13' GS1 Databar Omnidirectional</p> <p>'14' GS1 Databar Limited</p> <p>'15' GS1 Databar Expanded</p> <p>zzzzz: Contents of the decoded label. A – appears if the label was not correctly read.</p>

Alignment mode

Command	'JP'
Description	<p>This command simplifies mounting and alignment of the device. After activating the function with JP+, the device continuously supplies status information to the serial interfaces.</p> <p>With this online command, the scanner is set to terminate the decoding after 100 successfully decoded labels and output the status information. Subsequently, the read process is reactivated automatically.</p> <p>In addition to the output of the status information, the laser beam is used to display the reading quality. Depending on how many read results could be extracted, the duration of the laser's "OFF" time increases.</p> <p>If the reading quality is high, the laser beam flashes in brief, regular intervals. The worse the decoder decodes, the longer the pauses become during which the laser is switched off. The flashing intervals become more and more irregular because the laser may, in total, be active for longer to extract more labels. The duration of the pauses has been stepped in such a way that they can be distinguished by the eye.</p>
Parameters	<p>'+' : Starts the adjustment mode.</p> <p>'-' : Ends the adjustment mode.</p>
Acknowledgment	<p>'yyy_zzzzzz'</p> <p>yyy: Read quality in %. A high process availability is ensured at read qualities > 75 %.</p> <p>zzzzz: Bar code information.</p>

Manual definition of the reference code

Command	'RS'
Description	This command can be used to define a new reference code in the device by means of direct input via the serial interface. The data is saved in the parameter set according to your input under reference code 1 through 2 and stored in the working buffer for direct further processing.
Parameters	<p>'RSyvxzzzzzz'</p> <p>y, v, x and z are placeholders (variables) for the actual input.</p> <p>y Defined reference code no.</p> <p>'1' (code 1)</p> <p>'2' (code 2)</p> <p>v Storage location for reference code:</p> <p>'0' RAM+EEPROM,</p> <p>'3' RAM only</p> <p>xx Defined code type (see command 'CA')</p> <p>z Defined code information (1 ... 63 characters)</p>
Acknowledgment	<p>'RSx'</p> <p>x Status</p> <p>'0' Valid 'Rx' command</p> <p>'1' Invalid command</p> <p>'2' Insufficient memory for reference code</p> <p>'3' Reference code has not been saved</p> <p>'4' Reference code invalid</p>
Example	Entry = 'RS130678654331' (Code 1 (1), RAM only (3), UPC (06), code information)

Reference code teach-in

Command	'RT'
Description	This command enables a reference code to be defined quickly by reading an example label.
Parameters	<p>'RTy'</p> <p>y Function</p> <p>'1' Defines reference code 1</p> <p>'2' Defines reference code 2</p> <p>'+' Activates the definition of reference code 1 up to the value of Parameter no_of_labels</p> <p>'-' Ends the teach event</p>

Command	'RT'
Acknowledgment	<p>The device first responds with the command 'RS' and corresponding status (see command RS). After a bar code has been read, it sends the result in the following format:</p> <p>'RCyvxzzzzz'</p> <p>y, v, x and z are placeholders (variables) for the actual input.</p> <p>y Defined reference code no. '1' (code 1) '2' (code 2)</p> <p>v Storage location for reference code '0' RAM+EEPROM, '3' RAM only</p> <p>xx Defined code type (see command 'CA')</p> <p>z Defined code information (1 ... 63 characters)</p>

NOTE

With this function, only code types are recognized that are identified using the 'autoConfig' function or which were set in the set-up.

↳ After each reading via an 'RTy' command, explicitly switch off the function again since failure to do so will interfere with other commands as well as prevent execution of a new 'RTx' command.

Reading a reference code

Command	'RR'
Description	The command reads out the reference code defined in the device. If no parameters are specified, all defined codes are output.
Parameters	<p><Reference code number> '1' ... '2' value range of reference codes 1 to 2</p>
Acknowledgment	<p>If no reference codes are defined, the device responds with the 'RS' command and corresponding status (see command RS). For valid codes, the output corresponds to the following format:</p> <p>RCyvxzzzzz</p> <p>y, v, x and z are placeholders (variables) for the actual input.</p> <p>y Defined reference code no. '1' (code 1) '2' (code 2)</p> <p>v Storage location for reference code '0' RAM+EEPROM, '3' RAM only</p> <p>xx Defined code type (see command 'CA')</p> <p>z Defined code information (1 ... 63 characters)</p>

10.1.2 Online commands for system control**Activating sensor input**

Command	'+'
Description	<p>The command activates decoding. This command is used to activate the reading gate. It remains active until it is deactivated by one of the following criteria:</p> <ul style="list-style-type: none"> • Deactivation by a manual command • Deactivation by a switching input • Deactivation upon reaching the specified read quality (equal scans) • Deactivation by timeout • Deactivation upon reaching a preset number of scans without information.
Parameters	No
Acknowledgment	None

Deactivating sensor input

Command	'L'
Description	The command activates decoding. This command can be used to deactivate the reading gate. Following deactivation, the read result is output. Because the reading gate was manually deactivated and, thus, no GoodRead criterion was met, a NoRead is output.
Parameters	No
Acknowledgment	None

System boot-up

Command	'SON'
Description	System boot-up: changes the device from standby mode back to operating mode. The polygon wheel motor is started, the device works as usual.
Parameters	No
Acknowledgment	'S' (start character)

System standby

Command	'SOS'
Description	System standby: puts the device in standby mode. The device cannot be triggered, and the polygon wheel motor is stopped.
Parameters	No
Acknowledgment	None

10.1.3 Online commands for configuring the switching inputs/outputs

Activate switching output

Command	'OA'
Description	The switching outputs 1 - 4 can be activated with this command. The respective port must have been configured as a switching output. The logic state is output, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output).
Parameters	'OA<a> <a> Selected switching output [1..4], unit [dimensionless]
Acknowledgment	None

Query the state of the switching outputs

Command	'OA'
Description	This command may be used to query the states of the switching inputs and outputs that are configured as a switching output and that have been set via commands. The logic state is output, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output).
Parameters	'OA?'
Acknowledgment	'OA S1=<a>;S2=<a>;S3=<a>;S4=<a>' <a> State of the switching outputs '0' Low '1' High 'I' Configuration as switching input 'P' Passive configuration

Set the state of the switching outputs

Command	'OA'
Description	This command is used to set the states of the switching inputs/outputs that are configured as a switching output. The logic state is specified, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output). The values of the switching inputs/outputs that are not configured as switching outputs are ignored. You may also use only a selection of the existing switching inputs/outputs as long as these are listed in ascending order.
Parameters	'OA [S1=<a>;S2=<a>;S3=<a>;S4=<a>' <a> State of the switching output '0' Low '1' High
Acknowledgment	'OA=<aa>'

Command	'OA'
	<aa> Status acknowledgment, unit [dimensionless] '00' Ok '01' Syntax error '02' Parameter error '03' Other error

Deactivate switching output

Command	'OD'
Description	The switching outputs 1 - 4 can be deactivated with this command. The respective port must have been configured as a switching output. The logic state is output, i.e., an inverted logic is taken into account (e.g., inverted logic and a state of High corresponds to a voltage of 0V at the switching output).
Parameters	'OD<a>' <a> Selected switching output [1..4], unit [dimensionless]
Acknowledgment	None

Query the configuration of the switching inputs/outputs

Command	'OF'
Description	This command is used to query the configuration of the switching inputs/outputs 1 to 4.
Parameters	'OF?'
Acknowledgment	'OF S1=<a>;S2=<a>;S3=<a>;S4=<a>' <a> Function of the switching input/ output, unit [dimensionless] 'I' Switching input 'O' Switching output 'P' Passive

Configure the switching inputs/outputs

Command	'OF'
Description	This command is used to configure the function of the switching inputs/outputs 1 to 4. You may also use only a selection of the existing switching inputs/outputs as long as these are listed in ascending order.
Parameters	'OF [S1=<a>;S2=<a>;S3=<a>;S4=<a>' <a> Function of the switching input/ output, unit [dimensionless] 'I' Switching input 'O' Switching output 'P' Passive
Acknowledgment	'OF=<bb>' <bb> Status acknowledgment '00' Ok '01' Syntax error '02' Parameter error '03' Other error

10.1.4 Online commands for the parameter set operations

Copying parameter set

Command	'PC'
Description	This command can only be used to copy parameter sets in their entirety. This can be used to replicate the three parameter sets default , permanent and operating parameters on the basis of one another. In addition, this command also be used to restore the factory settings.
Parameters	'PC<Source type><Target type>' <Source type> Parameter data set that is to be copied, unit [dimensionless] '0' Parameter data set in permanent memory '2' Default or factory parameter set

Command	'PC'
	<p>'3' Operating parameter data set in volatile memory</p> <p><Target type> Parameter set into which the data is to be copied, unit [dimensionless]</p> <p>'0' Parameter data set in permanent memory</p> <p>'3' Operating parameter data set in volatile memory</p> <p>Permissible combinations here include:</p> <p>'03' Copying the data set from the permanent memory to the operating parameter data set</p> <p>'30' Copying the operating parameter data set to the permanent parameter set memory</p> <p>'20' Copying the default parameters to the permanent memory and to the main memory</p>
Acknowledgment	<p>'PS=<aa>'</p> <p><aa> Status acknowledgment, unit [dimensionless]</p> <p>'00' Ok</p> <p>'01' Syntax error</p> <p>'02' Impermissible command length</p> <p>'03' Reserved</p> <p>'04' Reserved</p> <p>'05' Reserved</p> <p>'06' Impermissible combination, source type - target type</p>

Requesting parameter data set from device

Command	'PR'
Description	The parameters of the device are grouped together in a parameter set and permanently stored in memory. There is one parameter set in permanent memory and one operating parameter set in volatile memory; in addition, there is a default parameter set (factory parameter set) for initialization. This command can be used to edit the first two parameter sets (in permanent and volatile memory). A check sum can be used for reliable parameter transfer.
Parameters	<p>'PR<BCC type><PS type><Address><Data length>[<BCC>]'</p> <p><BCC type> Check-digit function during transmission, unit [dimensionless]</p> <p>'0' Not used</p> <p>'3' BCC mode 3</p> <p><PS type> Memory from which the values are to be read, unit [dimensionless]</p> <p>'0' Parameter values stored in the flash memory</p> <p>'1' Reserved</p> <p>'2' Default values</p> <p>'3' Operating values in RAM</p> <p><Address> Relative address of the data within the data set</p> <p>'aaaa' Four-digit, unit [dimensionless]</p> <p><Data length> Length of the parameter data to be transferred</p> <p>'bbbb' Four-digit, unit [length in bytes]</p> <p><BCC> Check sum calculated as specified under BCC type</p>

Command	'PR'
Acknowledgment positive	<p>PT<BCC type><PS type><Status><Start></p> <p><Address parameter value><Address+1 parameter value>...</p> <p>[;<Address><Address parameter value>][<BCC>]</p> <p><BCC type> Check-digit function during transmission, unit [dimensionless]</p> <p> '0' Not used</p> <p> '3' BCC mode 3</p> <p><PS type> Memory from which the values are to be read, unit [dimensionless]</p> <p> '0' Parameter values stored in the flash memory</p> <p> '2' Default values</p> <p> '3' Operating values in RAM</p> <p><Status> Mode of parameter processing, unit [dimensionless]</p> <p> '0' No further parameters</p> <p> '1' Additional parameters follow</p> <p><Start> Relative address of the data within the data set,</p> <p> 'aaaa' Four-digit, unit [dimensionless]</p> <p><P.value A.> Parameter value of the parameter stored at this address; the parameter set data 'bb' is converted from HEX format to a 2-byte ASCII-format for transfer.</p> <p><BCC> Check sum calculated as specified under BCC type</p>
Acknowledgment negative	<p>'PS=<aa>'</p> <p>Parameter reply:</p> <p><aa> Status acknowledgment, unit [dimensionless]</p> <p> '01' Syntax error</p> <p> '02' Impermissible command length</p> <p> '03' Impermissible value for checksum type</p> <p> '04' Invalid check sum received</p> <p> '05' Impermissible number of data requested</p> <p> '06' Requested data does not (any longer) fit in the transmission buffer</p> <p> '07' Impermissible address value</p> <p> '08' Read access after end of data set</p> <p> '09' Impermissible QPF data set type</p>

Determining parameter set difference to default parameters

Command			'PD'
Description			<p>This command outputs the difference between the default parameter set and the operating parameter set or the difference between the default parameter set and the permanent parameter set.</p> <p>Comment: The reply supplied by this command can e.g. be directly used for programming a device with factory settings, whereby this device receives the same configuration as the device on which the PD-sequence was executed.</p>
Parameters	<p>'PD<P.set1><P.set2>'</p> <p><P.set1> Parameter data set that is to be copied, unit [dimensionless]</p> <p> '0' Parameter data set in permanent memory</p> <p> '2' Default or factory parameter set</p> <p><P.set2> Parameter set into which the data is to be copied, unit [dimensionless]</p> <p> '0' Parameter data set in permanent memory</p> <p> '3' Operating parameter data set in volatile memory</p> <p>Permissible combinations here include:</p> <p> '20' Output of the parameter differences between the default and the permanently saved parameter set</p> <p> '23' Output of the parameter differences between the default parameter set and the operating parameter set saved in volatile memory</p> <p> '03' Output of the parameter differences between the permanent parameter set and the operating parameter set saved in volatile memory</p>		
Acknowledgment positive	<p>PT<BCC><PS type><Status><Adr.><P.value adr.><P.valueAdr.+1>... [:<Adr.><P.value adr.>]</p> <p><BCC></p> <p> '0' No check digits</p> <p> '3' BCC mode 3</p> <p><PS type></p> <p> '0' Values stored in flash memory</p> <p> '3' Operating values stored in RAM</p> <p><Status></p> <p> '0' No further parameters</p> <p> '1' Additional parameters follow</p> <p><Adr.></p> <p> 'aaaa' Four-digit, unit [dimensionless]</p> <p><P.value></p> <p> Parameter value of the -bb- parameter stored at this address. The parameter set data is converted from HEX format to a 2-byte-ASCII format for transfer.</p>		
Acknowledgment negative	<p>'PS=<aa>'</p> <p><aa> Status acknowledgment, unit [dimensionless]</p> <p> '0' No difference</p> <p> '1' Syntax error</p> <p> '2' Impermissible command length</p> <p> '6' Impermissible combination, parameter set 1 and parameter set 2</p> <p> '8' Invalid parameter set</p>		

Writing parameter set

Command	'PT'
Description	The parameters of the device are grouped together in a parameter set and permanently stored in memory. There is one parameter set in permanent memory and one operating parameter set in volatile memory; in addition, there is a default parameter set (factory parameter set) for initialization. This command can be used to edit the first two parameter sets (in permanent and volatile memory). A check sum can be used for reliable parameter transfer.
Parameters	<p>PT<BCC type><PS type><status><addr.><P. value addr.> <P. value addr+1>... [;<addr.><P. value addr.>][<BCC>]</p> <p><BCC type> Check-digit function during transmission, unit [dimensionless]</p> <p> '0' No check digits</p> <p> '3' BCC mode 3</p> <p><PS type> Memory from which the values are to be read, unit [dimensionless]</p> <p> '0' Parameter values stored in the flash memory</p> <p> '3' Operating values stored in RAM</p> <p><Status> Mode of parameter processing, without function here, unit [dimensionless]</p> <p> '0' No reset after parameter change, no further parameters</p> <p> '1' No reset after parameter change, additional parameters follow</p> <p> '2' With reset after parameter change, no further parameters</p> <p> '6' Set parameters to factory setting, no further parameters</p> <p> '7' Set parameters to factory settings, lock all code types; the code-type setting must follow in the command!</p> <p><Addr.> Relative address of the data within the data set, 'aaaa' Four-digit, unit [dimensionless]</p> <p><P.value> Parameter value of the -bb- parameter stored at this address. The parameter set data is converted from HEX format to a 2-byte-ASCII format for transfer.</p> <p><BCC> Check sum calculated as specified under BCC type</p>
Acknowledgment	<p>'PS=<aa>'</p> <p>Parameter reply:</p> <p><aa> Status acknowledgment, unit [dimensionless]</p> <p> '01' Syntax error</p> <p> '02' Impermissible command length</p> <p> '03' Impermissible value for checksum type</p> <p> '04' Invalid check sum received</p> <p> '05' Impermissible data length</p> <p> '06' Invalid data (parameter limits violated)</p> <p> '07' Invalid start address</p> <p> '08' Invalid parameter set</p> <p> '09' Invalid parameter type</p>

11 Care, maintenance and disposal

Usually, the bar code reader does not require any maintenance by the operator.

11.1 Cleaning

🔧 In the event of dust build-up, clean the device with a soft cloth; use a cleaning agent (commercially available glass cleaner) if necessary.

NOTE



Do not use aggressive cleaning agents such as thinner or acetone for cleaning the device. Use of improper cleaning agents can damage the optical window.

11.2 Repairs, servicing

Repairs to the device must only be carried out by the manufacturer.

🔧 Contact your Leuze distributor or service organization should repairs be required.
The addresses can be found in Chapter 13.

NOTE



When sending devices to Leuze electronic for repair, please provide an accurate description of the error.

11.3 Disposing

🔧 For disposal observe the applicable national regulations regarding electronic components.

12 Diagnostics and troubleshooting

12.1 General causes of errors

Table 12.1: General causes of errors

Error	Possible error cause	Measures
Status LED PWR		
Off	<ul style="list-style-type: none"> No supply voltage connected to the device Hardware error 	<ul style="list-style-type: none"> Check supply voltage Send device to customer service
Orange, continuous light	<ul style="list-style-type: none"> Device in service mode 	<ul style="list-style-type: none"> Reset service mode with webConfig tool or display
Red, flashing	<ul style="list-style-type: none"> Warning 	<ul style="list-style-type: none"> Query diagnostic data and carry out the resulting measures
Red, continuous light	<ul style="list-style-type: none"> Error: no function possible 	<ul style="list-style-type: none"> Internal device error, send in device
Status LED NET		
Off	<ul style="list-style-type: none"> No supply voltage connected to the device Hardware error 	<ul style="list-style-type: none"> Check supply voltage Send device to customer service
Orange, flashing	<ul style="list-style-type: none"> Timeout -> Error on interface 	<ul style="list-style-type: none"> Check interface wiring
Red, flashing	<ul style="list-style-type: none"> Communication error With slave: network error With master: network error following initialization 	<ul style="list-style-type: none"> Check interface Check interface, addressing and el. connection of the slave Check interface, addressing and el. connection of the slave
Red, continuous light	<ul style="list-style-type: none"> No communication Incorrect wiring Incorrect address 	<ul style="list-style-type: none"> Check interface Check wiring Check addressing

12.2 Interface errors

Table 12.2: Interface error

Error	Possible error cause	Measures
No communication via USB service interface	<ul style="list-style-type: none"> Incorrect interconnection cable Connected device is not recognized 	<ul style="list-style-type: none"> Check interconnection cable Install USB driver
No communication via RS 232 / RS 422 / RS 485	<ul style="list-style-type: none"> Incorrect wiring Different baud rates Different protocol settings 	<ul style="list-style-type: none"> Check wiring Check baud rate Check protocol settings
Sporadic errors on the RS 232 / RS 422 / RS 485 interface	<ul style="list-style-type: none"> Incorrect wiring Effects due to EMC Overall network expansion exceeded 	<ul style="list-style-type: none"> Check wiring <ul style="list-style-type: none"> In particular, check wire shielding Check the cable used Check shielding (shield covering in place up to the clamping point) Check grounding concept and connection to functional earth (FE) Avoid EMC coupling caused by power cables laid parallel to device lines. Check max. network expansion as a function of the max. cable lengths

13 Support

Service hotline

You can find the contact information for the hotline in your country on our website www.leuze.com under **Contact & Support**.

Repair service and returns


Defective devices are repaired in our service centers competently and quickly. We offer you an extensive service packet to keep any system downtimes to a minimum. Our service center requires the following information:

- Your customer number
- Product description or part description
- Serial number or batch number
- Reason for requesting support together with a description

Please register the merchandise concerned. Simply register return of the merchandise on our website www.leuze.com under **Contact & Support > Repair Service & Returns**.

To ensure quick and easy processing of your request, we will send you a returns order with the returns address in digital form.

What to do should servicing be required?

NOTE	
	<p>Please use this chapter as a master copy should servicing be required.</p> <p>✉ Enter the contact information and fax this form together with your service order to the fax number given below.</p>

Customer data (please complete)

Device type:	
Serial number:	
Firmware:	
Display messages:	
Status of LEDs:	
Error description	
Company:	
Contact person/department:	
Phone (direct dial):	
Fax:	
Street / no.:	
ZIP code / City:	
Country:	

Leuze Service fax number:

+49 7021 573 - 199

14 Technical data

14.1 General specifications of the bar code readers


14.1.1 Line scanner

Table 14.1: Technical data of the BCL 500*/* and BCL 501*/* line scanners without heating

Type	BCL 500 <i>/</i> Stand-alone or multiNet plus master	BCL 501 <i>/</i> multiNet plus slave
Design	Line scanner without heating	
Optical data		
Light source	Laser diode λ = 655nm (red light)	
Beam exit	At the front	
Max. output power (peak)	2 mW	
Pulse duration	<150 μ s	
Scanning rate	1000 scans/s (adjustable in the range 800 ... 1200 scans/s)	
Beam deflection	Via rotating polygon wheel	
Useful opening angle	Max. 60°	
Optics models / resolution	High Density (N): 0.25 ... 0.5mm Medium Density (M): 0.35 ... 0.8 mm Low Density (F): 0.5 ... 1.0 mm Ultra Low Density (L): 0.7 ... 1.0 mm	
Reading distance	See reading field curves	
Laser class	1 acc. to IEC 60825-1:2014 / EN 60825-1:2014+A11:2021 and U.S. 21 CFR 1040.10 with Laser Notice No. 56	
Bar code data		
Code types	2/5 Interleaved, Code 39, Code 128, EAN 128, EAN / UPC, Codabar, Code 93, GS1 DataBar Omnidirectional	
Bar code contrast (PCS)	\geq 60%	
Ambient light tolerance	2000 lx (on the bar code)	
Number of bar codes per scan	6	

Type	BCL 500/ Stand-alone or multiNet plus master	BCL 501/ multiNet plus slave
Design	Line scanner without heating	
Electrical data		
Interface type	1x RS 232/422 at M12 (B) and 1x RS 485 at M12 (B)	1x RS 485 at 2x M12 (B)
Protocols	Leuze Standard, Leuze multiNet plus, ACK / NAK, 3964 (R) RK 512, Xon/ XOff	Leuze Standard, Leuze multiNet plus
Baud rate	4800 ... 115400 Baud	
Data formats	Data bits: 7.8 Parity: none, even, odd Stop bits: 1.2	
Service interface	USB 1.1 compatible, A-coded	
Switching input / switching output	4 switching inputs/outputs, freely programmable functions - Switching input: 10 ... 30 V DC depending on supply voltage, I max. = 8 mA - Switching output: 10 ... 30VDC depending on supply voltage, I max. = 60mA (short-circuit proof) Switching inputs/outputs protected against polarity reversal!	
Operating voltage	10 ... 30 V DC (Class II, protection class III)	
Power consumption	Max. 10 W	
Operating and display elements		
Display	Monochromatic graphical display, 128 x 64 pixel, with background lighting	
Keyboard	4 buttons	
LEDs	2 LEDs for power (PWR) and bus state (NET), two-colored (red/green)	
Mechanical data		
Degree of protection	IP 65 (with screwed-on M12 connectors or mounted caps)	
Weight	1.1 kg	
Dimensions (H x W x D)	63 x 123.5 x 106.5 mm	
Housing	Diecast aluminum	
Environmental data		
Operating temperature range	0 °C ... -40 °C	
Storage temperature range	-20°C ... +70°C	
Air humidity	Max. 90% rel. humidity, non-condensing	
Vibration	IEC 60068-2-6, test Fc	
Shock	IEC 60068-2-27, test Ea	
Continuous shock	IEC 60068-2-29, test Eb	
Electromagnetic com- patibility	EN 55022; IEC 61000-6-2 (contains IEC 61000-4-2, -3, -4, -5 and -6) ^{a)}	

a) This is a Class A product. In a domestic environment this product may cause radio interference, in which case the operator may be required to take adequate measures.

⚠ CAUTION!	
	For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code). The bar code readers are designed in accordance with protection class III for supply by PELV (protective extra-low voltage with reliable disconnection).

14.1.2 Oscillating-mirror scanner

Technical data same as for line scanner without heating, however with the following differences:

Table 14.2: Technical data of the BCL 500*/* and BCL 501*/* oscillating-mirror scanners with heating

Type	BCL 500 <i>/</i> Stand-alone or multiNet plus master	BCL 501 <i>/</i> multiNet plus slave
Design	Oscillating-mirror scanner without heating	
Optical data		
Beam exit	Lateral zero position at an angle of 90°	
Beam deflection	Via rotating polygon wheel (horizontal) and stepping motor with mirror (vertical)	
Oscillation frequency	0 ... 10 Hz (adjustable, max. frequency is dependent on set swivel angle)	
Max. swivel angle	±20° (adjustable)	
Reading field height	See reading field curves	
Electrical data		
Power consumption	Max. 14 W	
Mechanical data		
Weight	1.5 kg	
Dimensions (H x W x D)	84 x 173 x 147 mm	

14.2 Heating models of the bar code readers

The bar code readers of the BCL 500*/* series are optionally available as models with integrated heating. In this case, heating is permanently installed ex works. Self-installation on-site by the user is not possible!

Features

- Integrated heating (permanently installed)
- Extends the application range of the device to -35 °C
- Supply voltage 24VDC ±20%
- Enabling the device through an internal temperature switch
(switch-on delay about 30 min for 24 V DC and minimum ambient temperature of -35 °C)
- Necessary conductor cross-section for the voltage supply: at least 0.75 mm²; the use of preassembled cables is, thus, not possible

Structure

The heating consists of two parts:


- The front cover heater
- The housing heater

Function

When the 24 V DC supply voltage is applied to the device, a temperature switch initially only connects the heating to electrical power (front cover heater and housing heater). During the heating phase (around 30 min), when the inside temperature rises above 15 °C, the temperature switch connects the device to the supply voltage. This is followed by the self test and the changeover to read operation. The "PWR" LED lights up showing overall readiness for operation.


When the inside temperature reaches approx. 18 °C, another temperature switch turns the housing heater off and, if necessary, back on again (if the inside temperature drops below 15 °C). This does not interrupt the read operation. The front cover heater remains activated until an inside temperature of 25 °C is reached. At temperatures above this, the front cover heater switches off and, with a switching hysteresis of 3 °C, back on again at an inside temperature below 22 °C.

Mounting location

NOTE	
	The mounting location is to be selected such that it does not expose the device with heating directly to a cold air stream. To achieve an optimal heating effect, the device should be mounted so that it is thermally isolated.

Electrical connection

The required wire cross section of the connection cable for the voltage supply must be at least 0.75 mm².

⚠ CAUTION!	
	The voltage supply must not be looped through from one device to the next.

Power consumption

The energy requirement depends on the model:

- the line scanner with heating typically consumes 40 W and a maximum of 50 W power.
- the line scanner with oscillating mirror and heating typically consumes 60 W and a maximum of 75 W.

These values are based on operation with unconnected switching outputs.

14.2.1 Line scanner with heater

Technical data same as for line scanner without heating, however with the following differences:

Table 14.3: Technical data of the BCL 500/ and BCL 501/ line scanners with heating

Type	BCL 500 <i>i</i> Stand-alone or multiNet plus master	BCL 501 <i>i</i> multiNet plus slave
Design	Line scanner with heater	
Electrical data		
Operating voltage	24 VDC ±20 %	
Power consumption	Max. 50 W	
Structure of the heating	Housing heating and separate heating of the optics glass	
Warmup time	Min. 30 min at +24 V DC and an ambient temperature of -35 °C	
Min. conductor cross section	Conductor cross section of at least 0.75mm² for the supply voltage supply line. Wiring through of the voltage supply to multiple heating devices is not permissible. Standard, M12 preassembled cable not usable (insufficient cable cross-section)	
Environmental data		
Operating temperature range	-35°C ... +40°C	
Storage temperature range	-20°C ... +70°C	

14.2.2 Oscillating-mirror scanner with heating

Technical data same as for line scanner without heating, however with the following differences:

Table 14.4: Technical data of the BCL 501/ and BCL 500/oscillating-mirror scanners with heating

Type	BCL 500 <i>/</i> Stand-alone or multiNet plus master	BCL 501 <i>/</i> multiNet plus slave
Design	Oscillating-mirror scanner with heating	
Optical data		
Useful opening angle	Max. 50°	
Max. swivel angle	±12° (adjustable)	
Electrical data		
Operating voltage	24VDC ±20%	
Power consumption	Max. 75 W	
Structure of the heating	Housing heating and separate heating of the optics glass	
Warmup time	Min. 30 min at +24 V DC and an ambient temperature of -35 °C	
Min. conductor cross section	Conductor cross section of at least 0.75mm² for the supply voltage supply line. Wiring through of the voltage supply to multiple heating devices is not permissible. Standard, M12 preassembled cable not usable (insufficient cable cross-section)	
Environmental data		
Operating temperature range	-35°C ... +40°C	
Storage temperature range	-20°C ... +70°C	

14.3 Dimensioned drawings

14.3.1 Line scanner with / without heating





Figure 14.1: Dimensioned drawing - line scanner

14.3.2 Oscillating-mirror scanner with/without heating



- 1 M4, 6 mm deep
 2 M4, 7mm deep
 A Optical axis
 B Optical swivel range
 C Opening angle


NOTE



The optical swivel range and the opening angle are reduced on devices with heating; see "Reading field curves for heating devices" on page 86.


Figure 14.2: Dimensioned drawing of oscillating-mirror scanner

14.4 Dimensioned drawings: Accessories



- A** Holder, turnable 360°
B Rods, \varnothing 16 ... 20 mm

Figure 14.3: BT 56 mounting device



- A** Holder, turnable 360°
B ITEM joint, adjustable $\pm 90^\circ$
C M8x16 screwable cylinder, M8 serrated washer, M8 sliding block, connectors for ITEM profile (2x)

Figure 14.4: BT 59 mounting device





Figure 14.5: External parameter memory

14.5 Reading field curves / optical data

Bar code characteristics

NOTE	
	Please note that the size of the bar code module influences the maximum reading distance and the width of the reading field. Therefore, when selecting a mounting location and/or the bar code label, take into account the different reading characteristics of the scanner with various bar code modules.




- M Module: The narrowest line or space of a bar code in mm
- Z_b Wide character: Wide bars and gaps are a multiple (ratio) of the module.
Module x Ratio = Z_b (Normal Ratio 1 : 2.5)
- B_z Quiet zone: The quiet zone should be at least 10 times the module, but not less than 2.5mm.
- L Code length: The length of the bar code in mm including the start and stop characters. The quiet zone is included depending on the code definition.
- S_L Bar length: height of the elements in mm

Figure 14.6: The most important characteristics of a bar code

The range in which the bar code can be read by the device (the so-called reading field) depends on the quality of the printed bar code and its dimensions.

Therefore, above all, the module of a bar code is decisive for the size of the reading field.

NOTE	
	A rule of thumb: The smaller the module of the bar code is, the smaller the maximum reading distance and reading field width will be.


14.6 Reading field curves

NOTE



Please notice that the real reading fields are also influenced by factors such as labeling material, printing quality, reading angle, printing contrast etc., and may thus deviate from the reading fields specified here.

The zero position of the reading distance always refers to the front edge of the housing of the beam exit and is shown in Figure 14.7 for the two housing types of the device.



- 1 Zero position
- x Distance acc. to reading field curves

Figure 14.7: Zero position of the reading distance

Reading conditions for the reading field curves

Bar code type	2/5 Interleaved
Ratio	1:2.5
ANSI specification	Class A
Reading rate	> 75%

Table 14.5: Reading conditions

14.6.1 High Density (N) - optics: BCL 500/\ BCL 501/SN 102




Figure 14.8: "High Density" reading field curve for line scanner

The reading field curve applies for the reading conditions stated in Table 14.5.

14.6.2 High Density (N) - optics: BCL 500/\ BCL 501/ON 100




Figure 14.9: "High Density" reading field curve for oscillating-mirror scanners




Figure 14.10: Lateral "High Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 14.5.

14.6.3 Medium Density (M) - optics: BCL 500 / BCL 501 / SM 102




Figure 14.11: "Medium Density" reading field curve for line scanner

The reading field curves apply for the reading conditions stated in Table 14.5.

14.6.4 Medium Density (M) - optics: BCL 500 / BCL 501 / OM 100




Figure 14.12: "Medium Density" reading field curve for oscillating-mirror scanners




Figure 14.13: Lateral "Medium Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 14.5.

14.6.5 Low Density (F) - optics: BCL 500 / BCL 501 / SF 102




Figure 14.14: "Low Density" reading field curve for line scanner

The reading field curves apply for the reading conditions stated in Table 14.5.

14.6.6 Low Density (F) - optics: BCL 500 / BCL 501 / OF 100




Figure 14.15: "Low Density" reading field curve for oscillating-mirror scanners




Figure 14.16: Lateral "Low Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 14.5.

14.6.7 Ultra Low Density (L) - optics: BCL 500 / BCL 501 / SL 102




Figure 14.17: "Ultra Low Density" reading field curve for line scanner

The reading field curves apply for the reading conditions stated in Table 14.5.

14.6.8 Ultra Low Density (L) - optics: BCL 500/\ BCL 501/OL 100




Figure 14.18: "Ultra Low Density" reading field curve for oscillating-mirror scanners




Figure 14.19: Lateral "Ultra Low Density" reading field curve for oscillating-mirror scanners

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7 Reading field curves for heating devices

The reading field curves of the heating devices differ to some extent from the normal reading curves due to the optics heating and are somewhat reduced in the reading field width as well as in the reading field height!

- **The maximum opening angle** for all oscillating mirror devices of the BCL 500/series is **reduced to $\pm 28^\circ$** (without heating = $\pm 30^\circ$).
- **In addition, the maximum swivel range** for all oscillating mirror devices of the BCL 500/series is **reduced to $\pm 12^\circ$** (without heating = $\pm 20^\circ$).
- The reading field curves and opening angles are unchanged for all line scanners with heating of the BCL 500/series.

For details, please refer to the following reading field curves for the heating devices.

14.7.1 High Density (N) - optics: BCL 500/ \ BCL 501/ SN 102 H




Figure 14.20: "High Density" reading field curve for line scanner with heating

The reading field curve applies for the reading conditions stated in Table 14.5.

14.7.2 High Density (N) - optics: BCL 500/\ BCL 501/ON 100 H




Figure 14.21: "High Density" reading field curve for oscillating-mirror scanners with heating




Figure 14.22: Lateral "High Density" reading field curve for oscillating-mirror scanners with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7.3 Medium Density (M) - optics: BCL 500 / BCL 501 / SM 102 H




Figure 14.23: "Medium Density" reading field curve for line scanner with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7.4 Medium Density (M) - optics: BCL 500 / BCL 501 / OM 100 H




Figure 14.24: "Medium Density" reading field curve for oscillating-mirror scanners with heating




Figure 14.25: Lateral "Medium Density" reading field curve for oscillating-mirror scanners with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7.5 Low Density (F) - optics: BCL 500 / BCL 501 / SF 102 H




Figure 14.26: "Low Density" reading field curve for line scanner with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7.6 Low Density (F) - optics: BCL 500/\ BCL 501/OF 100 H




Figure 14.27: "Low Density" reading field curve for oscillating-mirror scanners with heating




Figure 14.28: Lateral "Low Density" reading field curve for oscillating-mirror scanners with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7.7 Ultra Low Density (L) - optics: BCL 500 / BCL 501 / SL 102 H




Figure 14.29: "Ultra Low Density" reading field curve for line scanner with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

14.7.8 Ultra Low Density (L) - optics: BCL 500 / BCL 501 / OL 100 H




Figure 14.30: "Ultra Low Density" reading field curve for oscillating-mirror scanners with heating




Figure 14.31: Lateral "Ultra Low Density" reading field curve for oscillating-mirror scanners with heating

The reading field curves apply for the reading conditions stated in Table 14.5.

15 Order guide and accessories

15.1 Part number code

Table 15.1: Part number code

BCL	5	00	/	O	M	100	H	
								Heating option
								H = With heating
								Beam exit
								0 Lateral
								2 At the front
								Optics
								N High Density (close)
								M Medium Density (medium distance)
								F Low Density (large distance)
								L Ultra Low Density (very large distances)
								Scanning principle
								S Line scanner (single line)
								O Oscillating-mirror scanner
								/= integrated fieldbus technology
								Interface
								00 RS 232/RS 422/RS 485 (multiNet master)
								01 RS 485 (multiNet slave)
								04 PROFIBUS DP
								08 ETHERNET TCP/IP, UDP
								48 PROFINET-IO RT
								58 Ethernet/IP
								Series: BCL5xx/
								BCL Bar code reader

15.2 Overview of BCL 500/ types

15.2.1 BCL 500/

Stand-alone or multiNet plus master with 1x RS 232/RS 422 and 1x RS 485 interface

Table 15.2: Overview of BCL 500/ types

Type designation	Description	Part no.
High Density optics (m = 0.25 ... 0.5mm)		
BCL 500/SN 102	Line scanner, front beam exit	501 05454
BCL 500/ON 100	Oscillating-mirror scanner	501 05455
BCL 500/SN 102 H	Line scanner, front beam exit, with heating	501 05457
BCL 500/ON 100 H	Oscillating-mirror scanner with heating	501 05458
Medium Density optics (m = 0.35 ... 1.0mm)		
BCL 500/SM 102	Line scanner, front beam exit	501 05460
BCL 500/OM 100	Oscillating-mirror scanner	501 05461
BCL 500/SM 102 H	Line scanner, front beam exit, with heating	501 05463
BCL 500/OM 100 H	Oscillating-mirror scanner with heating	501 05464
Low Density optics (m = 0.5 ... 1.0mm)		
BCL 500/SF 102	Line scanner, front beam exit	501 05466
BCL 500/OF 100	Oscillating-mirror scanner	501 05467
BCL 500/SF 102 H	Line scanner, front beam exit, with heating	501 05469
BCL 500/OF 100 H	Oscillating-mirror scanner with heating	501 05470

Type designation	Description	Part no.
Ultra Low Density optics (m = 0.7 ... 1.0mm)		
BCL 500/SL 102	Line scanner, front beam exit	501 09911
BCL 500/OL 100	Oscillating-mirror scanner	501 09912
BCL 500/SL 102 H	Line scanner, front beam exit, with heating	501 09914
BCL 500/OL 100 H	Oscillating-mirror scanner with heating	501 09915

15.2.2 BCL 501/

multiNet plus slave with 1x RS 485 interface at 2x M12 B-coded connectors

Table 15.3: Overview of BCL 501/ types

Type designation	Description	Part no.
High Density optics (m = 0.25 ... 0.5mm)		
BCL 501/SN 102	Line scanner, front beam exit	501 05472
BCL 501/ON 100	Oscillating-mirror scanner	501 05473
BCL 501/SN 102 H	Line scanner, front beam exit, with heating	501 05475
BCL 501/ON 100 H	Oscillating-mirror scanner with heating	501 05476
Medium Density optics (m = 0.35 ... 1.0mm)		
BCL 501/SM 102	Line scanner, front beam exit	501 05478
BCL 501/OM 100	Oscillating-mirror scanner	501 05479
BCL 501/SM 102 H	Line scanner, front beam exit, with heating	501 05481
BCL 501/OM 100 H	Oscillating-mirror scanner with heating	501 05482
Low Density optics (m = 0.5 ... 1.0mm)		
BCL 501/SF 102	Line scanner, front beam exit	501 05484
BCL 501/OF 100	Oscillating-mirror scanner	501 05485
BCL 501/SF 102 H	Line scanner, front beam exit, with heating	501 05487
BCL 501/OF 100 H	Oscillating-mirror scanner with heating	501 05488
Ultra Low Density optics (m = 0.7 ... 1.0mm)		
BCL 501/SL 102	Line scanner, front beam exit	501 09890
BCL 501/OL 100	Oscillating-mirror scanner	501 09891
BCL 501/SL 102 H	Line scanner, front beam exit, with heating	501 09893
BCL 501/OL 100 H	Oscillating-mirror scanner with heating	501 09894

15.3 Accessories

Table 15.4: Accessories – Connectors

Type designation	Description	Part no.
KD 095-5A	M12 socket for voltage supply	50020501
KS 095-4A	M12 connector for SW IN/OUT	50040155
KD 02-5-BA	M12 socket for HOST or BUS IN	50038538
KD 02-5-SA	M12 connector for BUS OUT	50038537
KDS BUS OUT M12-T-5P	M12 T-connector for BUS OUT	50109834

Table 15.5: Accessories – Terminating resistor for BCL 500// BCL 501/

Type designation	Description	Part no.
TS 02-4-SA M12	M12 connector with integrated terminating resistor for BUS OUT	50038539

Table 15.6: Accessories – Cables

Type designation	Description	Part no.
KB USB-Service	USB service cable	50107726

Table 15.7: Accessories – External parameter memory

Type designation	Description	Part no.
USB Memory Set	External USB parameter memory	50108833

Table 15.8: Mounting device accessories

Type designation	Description	Part no.
BT 56	Mounting device for rod	50027375
BT 59	Mounting device for ITEM	50111224

16 Appendix

16.1 ASCII character set

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
NUL	0	00	0	ZERO	Zero
SOH	1	01	1	START OF HEADING	Start of heading
STX	2	02	2	START OF TEXT	Start of text characters
ETX	3	03	3	END OF TEXT	Last character of text
EOT	4	04	4	END OF TRANSMISS.	End of transmission
ENQ	5	05	5	ENQUIRY	Request for data trans.
ACK	6	06	6	ACKNOWLEDGE	Positive acknowledgment
BEL	7	07	7	BELL	Bell signal
BS	8	08	10	BACKSPACE	Backspace
HT	9	09	11	HORIZ. TABULATOR	Horizontal tabulator
LF	10	0A	12	LINE FEED	Line feed
VT	11	0B	13	VERT. TABULATOR	Vertical tabulator
FF	12	0C	14	FORM FEED	Form feed
CR	13	0D	15	CARRIAGE RETURN	Carriage return
SO	14	0E	16	SHIFT OUT	Shift out
SI	15	0F	17	SHIFT IN	Shift in
DLE	16	10	20	DATA LINK ESCAPE	Data link escape
DC1	17	11	21	DEVICE CONTROL 1	Device control character 1
DC2	18	12	22	DEVICE CONTROL 2	Device control character 2
DC3	19	13	23	DEVICE CONTROL 3	Device control character 3
DC4	20	14	24	DEVICE CONTROL 4	Device control character 4
NAK	21	15	25	NEG. ACKNOWLEDGE	Negative acknowledge
SYN	22	16	26	SYNCHRONOUS IDLE	Synchronization
ETB	23	17	27	EOF TRANSM. BLOCK	End of data transmission block
CAN	24	18	30	CANCEL	Invalid
EM	25	19	31	END OF MEDIUM	End of medium
SUB	26	1A	32	SUBSTITUTE	Substitution
ESC	27	1B	33	ESCAPE	Escape
FS	28	1C	34	FILE SEPARATOR	File separator
GS	29	1D	35	GROUP SEPARATOR	Group separator
RS	30	1E	36	RECORD SEPARATOR	Record separator
US	31	1F	37	UNIT SEPARATOR	Unit separator
SP	32	20	40	SPACE	Space character
!	33	21	41	EXCLAMATION POINT	Exclamation point
"	34	22	42	QUOTATION MARK	Quotation mark
#	35	23	43	NUMBER SIGN	Number sign
\$	36	24	44	DOLLAR SIGN	Dollar sign
%	37	25	45	PERCENT SIGN	Percent sign
&	38	26	46	AMPERSAND	Ampersand
'	39	27	47	APOSTROPHE	Apostrophe
(40	28	50	OPEN. PARENTHESIS	Open parenthesis
)	41	29	51	CLOS. PARENTHESIS	Closed parenthesis
*	42	2A	52	ASTERISK	Asterisk
+	43	2B	53	PLUS	Plus sign
,	44	2C	54	COMMA	Comma
-	45	2D	55	HYPHEN (MINUS)	Hyphen
.	46	2E	56	PERIOD (DECIMAL)	Period (decimal)
/	47	2F	57	SLANT	Slant
0	48	30	60	0	Number
1	49	31	61	1	Number
2	50	32	62	2	Number

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
3	51	33	63	3	Number
4	52	34	64	4	Number
5	53	35	65	5	Number
6	54	36	66	6	Number
7	55	37	67	7	Number
8	56	38	70	8	Number
9	57	39	71	9	Number
:	58	3A	72	COLON	Colon
;	59	3B	73	SEMICOLON	Semicolon
<	60	3C	74	LESS THAN	Less than
=	61	3D	75	EQUALS	Equals
>	62	3E	76	GREATER THAN	Greater than
?	63	3F	77	QUESTION MARK	Question mark
@	64	40	100	COMMERCIAL AT	Commercial AT
A	65	41	101	A	Capital letter
B	66	42	102	B	Capital letter
C	67	43	103	C	Capital letter
D	68	44	104	D	Capital letter
E	69	45	105	E	Capital letter
F	70	46	106	F	Capital letter
G	71	47	107	G	Capital letter
H	72	48	110	H	Capital letter
I	73	49	111	I	Capital letter
J	74	4A	112	J	Capital letter
K	75	4B	113	K	Capital letter
L	76	4C	114	L	Capital letter
M	77	4D	115	M	Capital letter
N	78	4E	116	N	Capital letter
O	79	4F	117	O	Capital letter
P	80	50	120	P	Capital letter
Q	81	51	121	Q	Capital letter
R	82	52	122	R	Capital letter
S	83	53	123	S	Capital letter
T	84	54	124	T	Capital letter
U	85	55	125	U	Capital letter
V	86	56	126	V	Capital letter
W	87	57	127	W	Capital letter
X	88	58	130	X	Capital letter
Y	89	59	131	Y	Capital letter
Z	90	5A	132	Z	Capital letter
[91	5B	133	OPENING BRACKET	Opening bracket
\	92	5C	134	REVERSE SLANT	Reverse slant
]	93	5D	135	CLOSING BRACKET	Closing bracket
^	94	5E	136	CIRCUMFLEX	Circumflex
_	95	5F	137	UNDERSCORE	Underscore
`	96	60	140	GRAVE ACCENT	Grave accent
a	97	61	141	a	Lower case letter
b	98	62	142	b	Lower case letter
c	99	63	143	c	Lower case letter
d	100	64	144	d	Lower case letter
e	101	65	145	e	Lower case letter
f	102	66	146	f	Lower case letter
g	103	67	147	g	Lower case letter
h	104	68	150	h	Lower case letter
i	105	69	151	i	Lower case letter

ASCII	Dec.	Hex.	Oct.	Designation	Meaning
j	106	6A	152	j	Lower case letter
k	107	6B	153	k	Lower case letter
l	108	6C	154	l	Lower case letter
m	109	6D	155	m	Lower case letter
n	110	6E	156	n	Lower case letter
o	111	6F	157	o	Lower case letter
p	112	70	160	p	Lower case letter
q	113	71	161	q	Lower case letter
r	114	72	162	r	Lower case letter
s	115	73	163	s	Lower case letter
t	116	74	164	t	Lower case letter
u	117	75	165	u	Lower case letter
v	118	76	166	v	Lower case letter
w	119	77	167	w	Lower case letter
x	120	78	170	x	Lower case letter
y	121	79	171	y	Lower case letter
z	122	7A	172	z	Lower case letter
{	123	7B	173	OPENING BRACE	Opening brace
	124	7C	174	VERTICAL LINE	Vertical line
}	125	7D	175	CLOSING BRACE	Closing brace
~	126	7E	176	TILDE	Tilde
DEL	127	7F	177	DELETE (RUBOUT)	Delete

16.2 Bar code samples

16.2.1 Module 0.3



Figure 16.1: Code type 01: Interleaved 2 of 5



Figure 16.2: Code type 02: Code 39



Figure 16.3: Code type 06: UPC-A



Figure 16.4: Code type 07: EAN 8




Figure 16.5: Code type 08: EAN 128




Figure 16.6: Code type 10: EAN 13 Add-on



Figure 16.7: Code type 11: Codabar



Figure 16.8: Code 128

16.2.2 Module 0.5




Figure 16.9: Code type 01: Interleaved 2 of 5




Figure 16.10: Code type 02: Code 39




Figure 16.11: Code type 06: UPC-A




Figure 16.12: Code type 07: EAN 8



Figure 16.13: Code type 08: EAN 128




Figure 16.14: Code type 10: EAN 13 Add-on



Figure 16.15: Code type 11: Codabar




Figure 16.16: Code 128

Level 1 ▲▼ : Selection	Level 2 ▲▼ : Selection ESC : Back	Level 3 ▲▼ : Selection ESC : Back	Level 4 ▲▼ : Selection ESC : Back	Level 5 ▲▼ : Selection ESC : Back	Selection/configuration option ▲▼ : Selection ↵ : Activate ESC : Back	Detailed information on
Device information						see page 46
Bar code reading window						see page 20
Parameter	↵ Parameter handling	↵ Parameter enable ↵ Parameters to default			OFF/ON All parameters are reset to their factory settings	see page 47
	↵ Decoder table	↵ Max. no. of labels ↵ Decoder 1-4	↵ Symbology		Set the number of labels to be decoded (0 to 64) Code type: no code / Code 2/5 Interleaved / Code 39 / Code 32 / Code UPC / Code EAN / Code 128 / EAN Addendum / Codabar / Code 93 / GS1 DataBar Omnidirectional / GS1 DataBar Limited / GS1 DataBar Expanded	see page 47
			↵ Number of digits	↵ Interval mode ↵ Number of digits 1-5	OFF / ON for specification of a range of the number of digits 0 ... 64 characters	
			↵ Reading reliability		2 ... 100	
			↵ Check digit method		When decoding used check digit methods	
			↵ Check digit transm.		Check digit transmission standard-compliant / non standard-compliant	
	↵ Digital SWIO	↵ Switching input / output 1-4	↵ I/O mode ↵ Switching input	↵ Inverted ↵ Debounce time ↵ Switch-on delay ↵ Pulse duration ↵ Switch-off delay ↵ Function	Input / Output / Passive OFF / ON 0 ... 1000ms 0 ... 65535ms 0 ... 65535ms 0 ... 65535ms Function executed when the switching input is activated	see page 49
			↵ Switching output	↵ Inverted ↵ Signal delay ↵ Pulse duration ↵ Activation function 1-4 ↵ Deactivation function 1-4	OFF / ON 0 ... 65535ms 0 ... 65535ms Specifies which event activates the switching output Specifies which event deactivates the switching output	
	↵ Com	↵ Operating mode ↵ HOST / BUS IN	↵ Protocol type ↵ Interface		Stand-alone device / network master / network slave To be set depending on the operating mode	see page 46
			↵ Framing protocol	↵ Baud rate ↵ Data format ↵ Handshake ↵ Standard ↵ RX ↵ TX ↵ Address format ↵ Address	110 ... 115200 baud 7N1 / 7N2 / 7E1 / 7E2 / 7O1 / 7O2 / 8N1 / 8N2 / 8E1 / 8E2 / 8O1 / 8O2 / 9N1 None / RTS CTS / XON XOFF RS232 / RS422 / RS485 Prefix 1 ... 3 / Postfix 1 ... 3 / BCC mode Prefix 1 ... 3 / Postfix 1 ... 3 / BCC mode No address / binary address / ASCII address / automatic address Address of the BCL 500i \ BCL 501i	
		↵ BUS OUT	↵ multiNet Master	↵ Maximum number of slaves	0 ... 31, number of slave participants in the Leuze multiNet	
			↵ multiNet slave	↵ Slave address	0 ... 31, station number of the slave	
Language selection	↵				Deutsch / English / Español / Français / Italiano / Chinese	see page 53
Service	↵ Diagnosis				Number of readings, reading gates, reading rate / non-reading rate etc.	see page 53
	↵ Status messages				Only for use by Leuze personnel for service purposes	
Actions	↵ Start decoding	Stop decoding			Performs a single read operation	see page 53
	↵ Start alignment	Stop alignment			Alignment aid (alignment mode)	
	↵ Start auto setup	Stop auto setup			Automatic determination of code type and number of digits	
	↵ Start teach-in	Stop teach-in			Teach-in one reference code	