


Application Note Through-Beam-Sensors with activation input

General Information

Through beam photoelectric sensors



Remarks:

A light axis consists of a transmitter and a receiver.

If you substitute only the transmitter or the receiver please only substitute the sensor with exactly the same part no.


If the original sensor is discontinued, please exchange the whole axis (transmitter and receiver).



Activation Input

The successor has an input for test-activation. The transmitter only emits light if the input is connected to 24V (see diagram for electrical connection).

Picture electrical connection



SMART
SENSOR
BUSINESS

Headquarters
Leuze electronic GmbH + Co. KG
In der Braike 1, 73277 Owen, Germany
www.leuze.com

 **Leuze electronic**

the **sensor** people