

IO-Link interface description

ODT25CL1

Distance diffuse sensor



© 2025

Leuze electronic GmbH + Co. KG

In der Braike 1

73277 Owen / Germany

Phone: +49 7021 573-0

Fax: +49 7021 573-199

www.leuze.com

info@leuze.com

1	IO link interface	4
1.1	IO-Link identification	4
1.2	IO-Link process data	4
1.3	Device-specific IODD	5
1.4	IO-Link parameters documentation.....	5
1.5	Device-specific information	5
2	Functions configurable via IO-Link.....	7

1 IO link interface

Sensors in the ODT25CL1 variant have a dual channel architecture. Pin 4 provides the IO-Link interface in accordance with specification 1.1.4 (June 2024) with support for the Smart Sensor Profile 2nd Ed. 1.2 (January 2024) with profile type SSP 4.1.1 (Measuring and Switching Sensor, 1 Channel). You can configure the devices via the IO-Link interface quickly, easily and cost-effectively. Furthermore, the sensor transmits the process data via the IO-Link interface and makes diagnostic information available through it.

In parallel with the IO-Link communication, the sensor can output the continuous switching signal for object detection on pin 2 (SSC2 by default) by means of the dual channel architecture. The IO-Link communication does not interrupt this signal.

1.1 IO-Link identification

VendorID dec/hex	DeviceID dec/hex	Device
338/0x152	2221/0x8ad	ODT25CL1-3M.3/L6-M8
	...	...
	2222/0x8ae	ODT25CL1-3M.3/LT-M8
	...	...

Please refer to the respective product data sheet for the identification data of other IO-Link devices.

1.2 IO-Link process data

Device input data (PDOut – 1-bit data length)

Bit offset	Data width in bits	Assignment	Meaning
0	1	CSC – Sensor control	0: Transmitter active 1: Transmitter not active

Byte 0	x	x	x	x	x	x	x	CSC
	7	6	5	4	3	2	1	0

Device output data (PDIn) – 32-bit data length

Bit offset	Data width in bits	Assignment	Meaning
16	16	MDC - Measurement Value	Current measurement value -32760: Outside measurement range (-) 0, 32760: Outside measurement range (+) 32764: No measurement value available 50 – 3500: Measurement value
8	8	MDC – Scale	Display of the multiplier associated with the measurement value as a power of ten
0	1	SSC.1 – Switching signal	0: Switching output 1 not active 1: Switching output 1 active
1	1	SSC.2 – Switching signal	0: Switching output 2 not active 1: Switching output 2 active
3	1	Measure	0: Measurement not active 1: Measurement active
4	1	Signal	0: No valid reception signal 1: Reception signal available
5	1	Warning	0: No warning 1: Warning

Bit offset	Data width in bits	Assignment	Meaning
6	2	Quality	Strength of the reception signal 0: Insufficient 1: Low 2: Sufficient 3: Good

Byte 0	MDC – Measurement Value							
	15	14	13	12	11	10	9	8

Byte 1	MDC – Measurement Value							
	7	6	5	4	3	2	1	0

Byte 2	MDC – Scale							
	7	6	5	4	3	2	1	0

Byte 3	Quality		Warning	Signal	Measure	x	SSC.2	SSC.1
	7	6	5	4	3	2	1	0

1.3 Device-specific IODD

At www.leuze.com in the download area for IO-Link sensors you will find the IODD zip file with all data required for the installation.

On the IODDfinder platform (<https://ioddfinder.io-link.com/#/>), a central cross-manufacturer database, you can also find the description files (IODDs) of the IO-Link sensors.

1.4 IO-Link parameters documentation

The complete description of the IO-Link parameters can be found in the *.html files. Double-click on a language variant in the directory containing the extracted files:

- German: *IODD*-de.html
- English: *IODD*-en.html

If the html file within the ZIP archive is opened, the image files are not displayed.

📁 Extract the ZIP file first.

1.5 Device-specific information

- This is a device of data storage class 1 (automatic DS), i.e., device exchange is possible without additional measures (such as teaching).
- In the PREOPERATE state, this device uses TYPE_0.
- Because this device is not an actuator, no special failsafe behavior in the event of failure of PDOOut is necessary. In the context of deactivation, there are, however, the following special situations:
 - Changes to the transferred PDOOut information are ignored if they are marked as invalid. On the sensor side, the replacement value 0 (= activation) is assumed: If the device was previously activated, it thus remains activated. If the device was previously deactivated, it changes to the activated state.
 - If there is a lack of communication, the last setting (activation or deactivation) remains unchanged.

Fundamentals:

- IO-Link Interface and System Specification Version 1.1.4 June 2024
- IO-Link Test Specification Version 1.1.4 June 2024

2 Functions configurable via IO-Link

PC configuration and visualization is performed conveniently with the USB-IO-Link Master SET MD12-US2-IL1.1 (part no. 50121098) and the *Sensor Studio* configuration and diagnosis software (in the download area of the sensor at www.leuze.com).

System commands

NOTICE							
 The system commands trigger an action in the device.							

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
System command	2	0	UIntegerT, 1	WO	65, 66, 128, 129, 130, 131, 176, 177, 178, 180		65: Teach SP1 66: Teach SP2 128: Reset device 129: Reset application 130: Reset to factory settings 131: Back-to-box 176: Activate transmitter (has priority over PDOOut) 177: Deactivate transmitter (has priority over PDOOut) 178: Reset priority (PDOOut has priority) 180: Start/Stop object test

General configuration

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
Device Access Locks	12	0	UIntegerT, 2	RW	0, 8	0	0: Teach button not locked 8: Teach button locked
Application Specific Tag	24	0	String, max. 32	RW		***	Application-specific marking
Function Tag	25	0	String, max. 32	RW		***	Function identifier
Location Tag	26	0	String, max. 32	RW		***	Location indicator
Teach Select	58	0	UIntegerT, 1	RW	0, 1, 2, 255	1	0: Default channel (SSC.1) 1: SSC.1 2: SSC.2 255: All channels

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
Teach Result	59	1	UIntegerT, 4 bit	RO	0, 1, 4, 5, 7		Teach event status: 0: deactivated 1: Successful 4: Waiting for command 5: Working 7: Error
		2	Boolean	RO	0, 1		Teach-in-ok-Signal SP1: 0: Teach point 1 not Ok 1: Teach point 1 Ok
		3	Boolean	RO	0, 1		Teach-in-ok-Signal SP1: 0: Teach point 2 not Ok 1: Teach point 2 Ok
		4	Boolean	RO	0, 1		Teach-in-ok-Signal SP2: 0: Teach point 1 not Ok 1: Teach point 1 Ok
		5	Boolean	RO	0, 1		Teach-in-ok-Signal SP2: 0: Teach point 2 not Ok 2: Teach point 1 Ok
SSC.1 parameter	60	1	IntegerT, 4	RW	0 – 3500	1000	Numerical input of switching point SP1
		2	IntegerT, 4	RW	0 – 3500	500	Numerical input of switching point SP2
SSC.1 Configuration	61	1	UIntegerT, 1	RW	0, 1	0	Logic: 0: High active 1: Low active
		2	UIntegerT, 1	RW	0 – 3	1	Evaluation mode: 0: Deactivated 1: Single-point mode 2: Window mode 3: Two-point mode
		3	IntegerT, 4	RW	0	0	Determines the hysteresis at the switching point. A higher hysteresis can help increase the stability in critical applications. 0: Automatic
SSC.2 parameter	62	1	IntegerT, 4	RW	0 – 3500	1000	Numerical input of switching point SP1
		2	IntegerT, 4	RW	0 – 3500	500	Numerical input of switching point SP2
SSC.2 Configuration	63	1	UIntegerT, 1	RW	0, 1	0	Logic: 0: High active 1: Low active
		2	UIntegerT, 1	RW	0 – 3	1	Evaluation mode: 0: Deactivated 1: Single-point mode 2: Window mode 3: Two-point mode
		3	IntegerT, 4	RW	0	0	Determines the hysteresis at the switching point. A higher hysteresis can help increase the stability in critical applications. 0: Automatic

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
Teaching Reserve Factor SSC.2	82	0	IntegerT, 2	RW	-200 – 200	20	Adds a certain distance in mm to the teach point to ensure an active SSC.2. This only applies when performing a teach for SP1 in single-point mode.
Teaching Reserve Factor SSC.1	92	0	IntegerT, 2	RW	-200 – 200	20	Adds a certain distance in mm to the teach point to ensure an active SSC.1. This only applies when performing a teach for SP1 in single-point mode.
Average Count	130	0	IntegerT, 1	RW	0 – 100	0	Average calculation: The distance signal is averaged over this number of measurement values as a switching signal before evaluation. The default setting in the factory settings refers to the specified response time in the device data sheet.
Analysis Depth SSC.2	180	0	IntegerT, 1	RW	1 – 100	2	Analysis depth: to suppress interference, changing of the switching output is delayed by this number of identical measurement results. The default setting in the factory settings refers to the specified response time in the device data sheet.
Timer Unit SSC.2	182	0	UIntegerT, 1	RW	0, 255	0	0: Time module not active 255: Time module active Time module: <i>On</i> (255) activates the internal time function.
Function of Timer Unit SSC.2	183	0	UIntegerT, 1	RW	0 – 3	0	Function selection of switching delay SSC.2: 0: Switch-on delay 1: Switch-off delay 2: Pulse stretching 3: Pulse suppression Function selection of the switching delay: activation of a suitable switching delay is possible. It is not possible to combine switching delays.
Time SSC.2	184	0	UIntegerT, 2	RW	1 – 50000	200	Definition of the time basis in 100 µs increments, configurable from 100 µs to 5000 ms.
Number of Objects SSC.2	185	0	UIntegerT, 4	RW	0 – 4294967295		Object counter: The device has an internal, volatile object counter. This counts the switching events and can be freely read out, edited and reset. This function enables a simple validation of the process. As soon as the object counter has reached the maximum end value, the count process starts over again at 0.
Analysis Depth SSC.1	190	0	IntegerT, 1	RW	1 – 100	2	Analysis depth: to suppress interference, changing of the switching output is delayed by this number of identical measurement results. The default setting in the factory settings refers to the specified response time in the device data sheet.

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
Timer Unit SSC.1	192	0	UIntegerT, 1	RW	0, 255	0	0: Time module not active 255: Time module active Time module: <i>On</i> (255) activates the internal time function.
Function of Timer Unit SSC.1	193	0	UIntegerT, 1	RW	0 – 3	0	Function selection of switching delay SSC.1: 0: Switch-on delay 1: Switch-off delay 2: Pulse stretching 3: Pulse suppression Function selection of the switching delay: A suitable switching delay can be activated. It is not possible to combine switching delays.
Time SSC.1	194	0	UIntegerT, 2	RW	1 – 50000	200	Definition of the time basis in 100 µs increments, configurable from 100 µs to 5000 ms.
Number of Objects SSC.1	195	0	UIntegerT, 4	RW	0 – 4294967295		Object counter: The device has an internal, volatile object counter. This counts the switching events and can be freely read out, edited and reset. This function enables a simple validation of the process. As soon as the object counter has reached the maximum end value, the count process starts over again at 0.
Wire function level 1-12	201-212	0	IntegerT, 1	RW	0, 2, 4, 19, 20, 22, 23, 46, 47, 48, 49	2, 4, 20, 19, 47, 48, 0, 0, 0, 0, 0, 0	Selection of the function to be performed during a teach via cable at level 1-12 (valid only for DeviceID 2222) 0: No cable function 2: Teach SP1 of SSC.1 with defined off-set 4: Teach SP2 of SSC.1 with defined off-set 19: SSC.1 not inverted 20: SSC.1 inverted 22: SSC.1 time module activated 23: SSC.1 time module deactivated 46: SSC.1 mode deactivated 47: SSC.1 mode single-point 48: SSC.1 mode window 49: SSC.1 mode two-point
Temperature	220	0	IntegerT, 2	RO			The device is equipped with an integrated temperature sensor for transmitting the internal temperature in 1/10 °C.
Operation hours counter	234	0	UIntegerT, 4	RO			The device has an integrated operating hours counter for transmitting the operating hours.

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
Button function level 1	241	0	IntegerT, 1	RW	0, 2, 3, 4, 5, 19, 20, 21, 22, 23, 24, 31, 32, 33, 34, 35, 36, 43, 44, 45	2	Selection of the function to be executed after pressing the button for 2 to 6 seconds. 0: No button function 2: Teach SP1 of SSC.1 with defined offset 3: Teach SP1 of SSC.2 with defined offset 4: Teach SP2 of SSC.1 with defined offset 5: Teach SP2 of SSC.2 with defined offset 19: SSC.1 not inverted 20: SSC.1 inverted 21: SSC.1 logic toggle 22: SSC.1 time module activated 23: SSC.1 time module deactivated 24: Toggle time module SSC.1 (on/off) 31: SSC.2 not inverted 32: SSC.2 inverted 33: SSC.2 logic toggle 34: SSC.2 time module activated 35: SSC.2 time module deactivated 36: Toggle time module SSC.2 (on/off) 43: SSC.1 and SSC.2 not inverted 44: SSC.1 and SSC.2 inverted 45: SSC.1 and SSC.2 logic toggle
Button function level 2	242	0	IntegerT, 1	RW	0, 2, 3, 4, 5, 19, 20, 21, 22, 23, 24, 31, 32, 33, 34, 35, 36, 43, 44, 45	4	Selection of the function to be executed after pressing the button for 7 to 11 seconds. 0: No button function 2: Teach SP1 of SSC.1 with defined offset 3: Teach SP1 of SSC.2 with defined offset 4: Teach SP2 of SSC.1 with defined offset 5: Teach SP2 of SSC.2 with defined offset 19: SSC.1 not inverted 20: SSC.1 inverted 21: SSC.1 logic toggle 22: SSC.1 time module activated 23: SSC.1 time module deactivated 24: Toggle time module SSC.1 (on/off) 31: SSC.2 not inverted 32: SSC.2 inverted 33: SSC.2 logic toggle 34: SSC.2 time module activated 35: SSC.2 time module deactivated 36: Toggle time module SSC.2 (on/off) 43: SSC.1 and SSC.2 not inverted 44: SSC.1 and SSC.2 inverted 45: SSC.1 and SSC.2 logic toggle

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Explanation
Button function level 3	243	0	IntegerT, 1	RW	0, 2, 3, 4, 5, 19, 20, 21, 22, 23, 24, 31, 32, 33, 34, 35, 36, 43, 44, 45	45	Selection of the function to be executed after pressing the button for 12 to 16 seconds. 0: No button function 2: Teach SP1 of SSC.1 with defined offset 3: Teach SP1 of SSC.2 with defined offset 4: Teach SP2 of SSC.1 with defined offset 5: Teach SP2 of SSC.2 with defined offset 19: SSC.1 not inverted 20: SSC.1 inverted 21: SSC.1 logic toggle 22: SSC.1 time module activated 23: SSC.1 time module deactivated 24: Toggle time module SSC.1 (on/off) 31: SSC.2 not inverted 32: SSC.2 inverted 33: SSC.2 logic toggle 34: SSC.2 time module activated 35: SSC.2 time module deactivated 36: Toggle time module SSC.2 (on/off) 43: SSC.1 and SSC.2 not inverted 44: SSC.1 and SSC.2 inverted 45: SSC.1 and SSC.2 logic toggle
Pin 4 function	251	0	UIntegerT, 1	RW	0, 1, 2, 3, 4, 7, 8	1	Setting the functionality of pin 4. 0: Pin without function 1: Pin as SSC.1 2: Pin as SSC.1 inverted 3: Pin as SSC.2 4: Pin as SSC.2 inverted 7: Pin as warning output 8: Pin as warning output inverted
Pin 2 function	252	0	UIntegerT, 1	RW	0, 1, 2, 3, 4, 7, 8, 14	3/14	Setting the functionality of PIN 2: 0: Pin without function 1: Pin as SSC.1 2: Pin as SSC.1 inverted 3: Pin as SSC.2 (default value for DeviceID 2221) 4: Pin as SSC.2 inverted 7: Pin as warning output 8: Pin inverted as warning output 14: Pin as Teach input (default value for DeviceID 2222)

Tab. 2.1: Impulse duration index 201 – 212

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Impulse duration (Low signal duration)
Wire function level 1	201	0	UIntegerT, 2	RW	See above	2	20 – 80 ms
Wire function level 2	202	0	IntegerT, 1	RW	See above	4	120 – 180 ms

Parameter	Index	Sub-index	Data type, octets	Access	Value range	Default	Impulse duration (Low signal duration)
Wire function level 3	203	0	IntegerT, 1	RW	See above	20	220 – 280 ms
Wire function level 4	204	0	IntegerT, 1	RW	See above	19	320 – 380 ms
Wire function level 5	205	0	IntegerT, 1	RW	See above	47	420 – 480 ms
Wire function level 6	206	0	IntegerT, 1	RW	See above	48	520 – 580 ms
Wire function level 7	207	0	IntegerT, 1	RW	See above	0	620 – 680 ms
Wire function level 8	208	0	IntegerT, 1	RW	See above	0	720 – 780 ms
Wire function level 9	209	0	IntegerT, 1	RW	See above	0	820 – 880 ms
Wire function level 10	210	0	IntegerT, 1	RW	See above	0	920 – 980 ms
Wire function level 11	211	0	IntegerT, 1	RW	See above	0	1020 – 1080 ms
Wire function level 12	212	0	IntegerT, 1	RW	See above	0	1120 – 1180 ms